

INSTRUCTION BOOK

No. 32A-2

FOR

INSTALLING AND OPERATING

ATLAS IMPERIAL

FOUR CYCLE

MECHANICAL INJECTION

DIESEL ENGINES

DUST PROOF TYPE

PRICE \$1.00

ATLAS IMPERIAL DIESEL ENGINE CO.

MAIN OFFICE AND FACTORY

OAKLAND, CALIFORNIA, U. S. A.

INSTRUCTION BOOK

No. 32A-2

FOR

INSTALLING AND OPERATING

ATLAS IMPERIAL

FOUR CYCLE

MECHANICAL INJECTION

DIESEL ENGINES

DUST PROOF TYPE

ATLAS IMPERIAL DIESEL ENGINE CO.

MAIN OFFICE AND FACTORY

OAKLAND, CALIFORNIA, U. S. A.

CABLE ADDRESS

"ATGAS"

CODES


BENTLEY'S

WESTERN UNION (UNIVERSAL EDITION)

A. B. C. FIFTH EDITION

PRIVATE

PRINTED IN THE U. S. A.



ATLAS IMPERIAL, THE PROVEN DIESEL ENGINE

Some of the Characteristics of Atlas Imperial Mechanical Injection Diesel Engines

TYPE OF FUEL USED:

Diesel Fuel Oil.

INJECTION OF FUEL:

By pressure without the aid of compressed air.

IGNITION:

Accomplished by heat of compression only.

FUEL CONSUMPTION:

Four-tenths pounds per horse-power hour, or about 20 horse-power hours per gallon.

COST OF LUBRICATING OIL FOR 100 H. P., PER HOUR:

Approximately 6c.

COMPRESSION:

375 pounds per square inch.

STARTS:

By compressed air (maximum pressure is 200 pounds) in 20 seconds from stone cold to full load. No priming or pre-heating is required.

SLOW SPEED:

Heavy duty.

APPROXIMATE WEIGHT PER RATED HORSE-POWER:

150 to 170 pounds.

LUBRICATION:

Is by force feed system.

CYLINDERS ARE LUBRICATED:

By means of a mechanical force feed cylinder oiler. Quantity of lubricating oil required, about one gallon in ten hours for each 100 horse-power.

CIRCULATING WATER REQUIRED:

Only one-half of the amount necessary for a heavy duty gas engine of the same power.

GOVERNOR:

The engines govern closely from full load to no load. Governor controls the amount of fuel injected into the cylinder. The speed of the engine can be increased or decreased by use of the control handle.

PRACTICAL CONSTRUCTION:

Simple in construction, all parts easily accessible and all parts as far as possible, interchangeable. Engine can be operated by any ordinary intelligent individual. All parts where practical, are hardened and ground to precision gauges.

ENGINE SPEEDS:

The speed of the engine may be varied from slow to fast and vice versa, to suit the work that is to be performed, in the same manner as an automobile engine is slowed down or speeded up, but the engine should NEVER be allowed to run at an excessive speed as it is essentially a heavy duty engine with heavy reciprocal parts which are not adapted to high speeds, therefore should not be operated above its normal running speed.

ENGINE FUEL:

Is pumped through a small steel tube that leads to the spray valves in the cylinder heads. This pump is a simple plunger pump driven from off of the cam shaft. The excessive amount of fuel which is pumped into the fuel line is by-passed back to the supply tank through a relief valve set at the proper pressure adjustment.

GOVERNING:

Is by regulating the length of time the spray valve is kept open. This is accomplished by a sensitive gear-driven flyball governor which functions by regulating the duration of the spray valve opening, as well as the amount which the spray valve is being lifted. Attached to the governor is a speed regulating device whereby the speed of the engine may be altered by the operator to suit requirements. This governor is very quick in action and responds immediately when loads are suddenly applied or released.

Explanation of the Diesel Principle

FACTS:

1. Air becomes hot by being compressed. The degree of heat depends on the amount of compression.
2. Three hundred and seventy-five pounds compression creates sufficient heat to ignite fuel oil when properly sprayed into the compression chamber at the proper time.
3. Fuel oil, if sufficiently atomized, will ignite when injected into a cylinder of compressed air, the temperature of which has been raised above the fire test of the fuel by means of compression.
4. The expansion of the burning fuel oil is the power-creating force within the cylinder of the engine.

The Diesel engine differs from a gas engine from the fact that it is a constant pressure engine. That is, the injection of fuel into the cylinder is timed and controlled to maintain constant pressure during its introduction, while in a gas engine a constant volume of mixture is taken into the cylinder and after compressing same to a safe limit (about 50 pounds) the mixture is ignited by some auxiliary mechanism and the pressure instantly rises in the nature of an explosion to a degree depending on the volume of the mixture.

While the terminal pressures are about the same in both types of engines, the efficiency of the Diesel is twice that of the gas engine, due to compressing the air to a high temperature before injecting the fuel, then controlling this injection so that combustion continues for a predetermined time, varying with the load.

This process enables the Diesel engine to maintain a much higher mean effective pressure with a corresponding greater horse-power for the same cylinder dimensions.

In order to obtain perfect combustion within the cylinder it is necessary to inject the fuel oil in the form of a very fine spray which is done by the specially designed spray nozzle.

By understanding these fundamental requirements of a Diesel engine it is readily seen that the mechanical injection Diesel engine is very simple and not a complicated mass of machinery.

CYCLE:

Atlas-Imperial Diesel engines operate on the four-cycle principle. The four cycle implies that the work in the cylinder is accomplished in four strokes of the piston, or two revolutions of the engine.


The function of each cycle or stroke of the piston is as follows:

1. INTAKE:

When the piston goes down on the intake stroke, the intake valve being open, the cylinder becomes filled with air from the atmosphere.

2. COMPRESSION STROKE:

On the upward stroke of the piston, the inlet valve is closed and the air in the cylinder is compressed to about 375 pounds pressure per square inch. At this pressure (as explained before) the temperature of the compressed air is raised sufficiently to ignite the fuel. A few degrees before



the piston reaches the top of the compression stroke the fuel spray valve is opened by a cam and the fuel sprayed into the heated air. A constant pressure of fuel oil is maintained in the spray nozzles at all times by means of small plunger pumps which are more fully described later in the book.

3. EXPANSION STROKE:

The fuel oil burning and expanding in the cylinder maintains pressure on the piston during the downward stroke. Near the end of the power stroke the exhaust valve opens and allows the burned gases to escape.

4. SCAVENGING STROKE:

As the piston returns to the top of the cylinder with the exhaust valve open, the piston pushes all the burned gases out of the cylinder through the exhaust valve. When the piston has reached the top the exhaust valve is closed and the intake valve again is opened.

This completes the four cycles or four strokes of the MECHANICAL INJECTION DIESEL engine and describes the method of its functioning.

COMMENT:

It will be noted that while the sequence of the strokes forming this cycle is similar to that of the gas engine, the functions performed during the cycle (except on the exhaust stroke) are materially different.

On the first stroke, by taking into the cylinder pure air only, we are enabled to compress this charge sufficiently to secure a very high temperature, which would be impossible with a charge of gas mixture, because of liability to preignition.

This high temperature secured allows the use of a cheap, low grade fuel oil of high fire test which is safe to handle and increases both the thermal and commercial efficiency of the engine.

On the third stroke the fuel is introduced under absolute control, as to timing and quantity, the constant pressure in the column of fuel oil being sufficient so that when the valve opens the fuel is completely atomized and ready for instant firing at the moment it reaches the heated interior of the cylinder, and we reiterate, no high pressure air is used to force this fuel oil into the cylinder.

With some methods (not the true solid injection type) fuel is introduced under low pressure into a recessed casting projection into the firing chamber while there is no pressure, and on the up stroke of the piston the pressure increases until sufficient heat is developed to ignite the little cartridge of fuel (previously injected under no pressure) and when it ignites it blows the fuel oil out through small holes provided for that purpose. No control of the exact moment of firing is possible, as in our method where the fuel is mechanically injected into the cylinder at the proper time.

As stated above, this combustion is not in any sense an explosion, but takes place during a well defined, predetermined portion of the power stroke and at constant pressure, and because of the nature of its introduction into the cylinder and the large volume of pure air into which it is forced, the combustion is perfect within the range of cylinder power rating, hence the high thermal efficiency of the Diesel engine on low grade fuel oils.

The foregoing description of the engine is, of course, general in character, intended to cover only the principles around which the physical construction is assembled.

In General

IN issuing this instruction book we have tried to present to the reader the principal points to be observed in the care, operation and maintenance of the Atlas Imperial Diesel engine in a clear and concise manner.

This information is extended not only for use by the operator but also for those responsible for the performance of the engine. It is impractical to cover the exceptional conditions which might occur and therefore we have only covered those with which each operator should be thoroughly familiar.

Along these lines we offer as a satisfactory suggestion: **WHEN THE ENGINE IS RUNNING SATISFACTORILY AND SMOOTHLY LEAVE IT ALONE, DO NOT BE CONTINUALLY TRYING TO BETTER THE OPERATION WITH MINOR ADJUSTMENTS.**

FIRST: NEVER ALLOW YOUR ENGINE TO SMOKE:

A Diesel engine, oil engine, gas engine, kerosene lamp or a candle perform the same operation, namely: Each burns a certain amount of fuel when mixed with proper proportions of air, and when the proportions are such that there is not enough air for the fuel to burn clean, in other words, too much fuel for the amount of available air—you will have smoke. Whether it be a candle, kerosene lamp, gas engine, oil engine, or diesel engine, smoke indicates that the proportions of air and fuel are not correct. These proportions must be adjusted to a point at which smoke is eliminated—combustion perfect, and the exhaust clear.

In a Diesel engine there are two things that will cause the engine to smoke; first, as above stated, too much fuel for the amount of air; and secondly, not the right distribution of broken up fuel in the combustion chamber. If the spray nozzle should be out of order or partly clogged, the fuel may enter the combustion chamber in a solid liquid form, in which case it does not properly mix with the air in the cylinders and consequently will cause smoke, even if the amount of fuel is not in excess of the amount required to properly mix with the air in the cylinders. When the exhaust from an engine is smoky it clearly indicates that combustion is not perfect and that the residue, in shape of smoke, is clinging to the oily surfaces of the cylinders, pistons, piston rings, valves, etc., and when this happens you are creating trouble for yourself and doing an injustice to the engine. Therefore, the first thing in consideration of the operation of a diesel engine is, **NOT TO ALLOW YOUR ENGINE TO SMOKE.**

SECOND: DO NOT OVERLOAD YOUR ENGINE:

A Diesel engine is unlike a gas engine in that it can be overloaded. You can continue increasing the power of a Diesel engine to a great extent by admitting too much fuel which increases the heat within the cylinders and increases the pressure in the cylinder. One cannot continually overload an engine any more than you can continually overload any other thing, thinking that you can go on successfully carrying the overload without bad results. Atlas Imperial Diesel engines are of such liberal dimensions that they will pull a considerable overload without smoking; but if one attempts to overload his engine too much it will naturally smoke, and smoke means trouble.

There is no harm in running the engine continually up to its full power as long as its exhaust is clear and combustion perfect. Do not allow spray valves, air starting valves, inlet or exhaust valves to be leaky. If an engine has been allowed to smoke for some time, carbon will be deposited on the valve seats in spots and allow the valves to leak. As soon as a valve is leaky a blast of fire will pass through the leaky valve and start to cut the valve seats or valves, thereby causing much trouble.

THIRD: LUBRICATION:

Any piece of machinery needs proper lubrication and a Diesel engine is not an exception. Always see that lubricating systems are always in proper working order. We have attempted to make the lubricating systems in our engines as near fool proof as possible, but it still remains for human intelligence to watch it from time to time to ascertain that it functions in the way that it should.

Atlas Imperial Diesel engines are lubricated by a dual system; a primary and secondary system. The primary system consists of a mechanical force feed oiler, ratchet drive. New oil is used in this mechanical oiler at all times. There is always a small amount of waste oil from the cylinder lubrication, which after being caught up in the oil tight base, becomes part of the "make up" of the secondary system.

The secondary system supplies oil under pressure to all main bearings, crank bearings and wrist pins. The pressure of the oil is maintained by a lubricating rotary pump, located on the rotary pump door attached to centerframe on the operating side of the engine.

The lubricating oil consumption is a variable factor, depending somewhat on the grade of oil used, but principally on the care given the engine in its operation, ordinarily about 1500 to 2000 horse-power hours per gallon.

CYLINDERS:

Oil is supplied to the cylinder walls by means of the force feed lubricator oiler, through a small pipe connected to the inlet and exhaust side of the cylinder wall. It requires not more than three or four drops of oil to the cylinder wall per minute. It is very important that this lubrication be constant and not vary in any way. This may be detected very readily by counting the drops as they drop past the sight glasses located on top of the oiler and should be checked at regular intervals.

BEARINGS:

The lubrication of the main bearings is accomplished by means of a force feed system, so arranged that the oil is being forced, by means of a pump at a pressure varying from five to ten pounds, according to that which has been regulated by the pressure lubricating oil relief valve. The oil is pumped from the oil reservoir or supply tank through oil pipes in the base to the bottom of the main bearings. This is not done through the top of the bearing caps, thus permitting a simple arrangement of the oil piping and obviating the necessity of breaking the pipe connections, etc. The crank shaft revolving in the main bearing is provided with a hole drilled angular through to the crank pin, through which the oil is forced (by centrifugal force) thereby lubricating the connecting rod bearings or crank pins.

It is important that sufficient oil is always maintained in the oil reservoir to insure the proper function of the pumps so that the oil will circu-

late freely, unhampered by air bubbles and the like. A pressure gauge is connected to the lubricating oil pipe line, which indicates the oil pressure on the bearings at all times. If no pressure is registered on this gauge, it will indicate one of three things: ONE—that there is not sufficient oil in the reservoir; TWO—that the lubricating oil pumps are not functioning properly. THIRD—That some bearing has become sufficiently loose to allow the lubricating oil to flow out too freely.

All the oil pumped through these bearings is collected in the crank pits, flows to a sump through a strainer, is pumped from the sump through to a filtering tank and back to the main bearings.

WRIST PINS:

In the top half of the crank bearing at the center of the groove is a hole for the oil to leave the crank bearing and enter the connecting rod. The connecting rod is drilled hollow and is fitted with a check valve at its lower end, (which checks any attempt of the oil to return back to the crank) so that the oil which is forced through the crankshaft and through the hole in the bearing will pass through the check valve and then up through the hollow connecting rod to lubricate the wrist pin in the piston.

OIL RETURN:

During its course the oil is being gradually squeezed out, partly through the main bearings, partly through the crank bearings, and the balance out through the wrist pin bearings, from where the oil returns by gravity to the sump in the bottom of the base.

The lubricating oil distributing pipe is provided with a spring loaded relief valve, so arranged as to allow the surplus oil to be delivered back into the lubricating oil reservoir, and thereby preventing the pressure from becoming too excessive.


CHOICE OF OIL:

When the engine warms up after running for some time, the oil pressure may not register as high as when the engine was first started, due to the fact that the oil becomes thin with heat, and therefore flows more freely out through the sides of the bearings.

The choice of lubricating oil for the power cylinders and bearings of a Diesel engine is a matter involving many operating factors of which the most important are the temperature and pressures within the power cylinders, the thoroughness of oil distribution over the working surfaces, the amount of carbon formation and the method of lubrication.

Fairly high temperatures and pressures are to be contended with in a Diesel engine. The oil film formed, therefore, must have sufficient body to support the piston and piston rings, preventing metallic contact with the cylinder. Heat will naturally thin out the oil and therefore in the selection of the lubricant the body of the oil at the operating temperatures must be considered. High quality, correctly refined Diesel engine cylinder oils retain their body better than the low grade, inferior oils.

Unsuitable or inferior oil fails to provide satisfactory lubrication. It chars freely, combines easily with fuel impurities, the products of incomplete combustion and dust or dirt in the intake air, forming a hard crust-like deposit. In an attempt to supply lubrication with such an oil excessive



METHOD OF LUBRICATING CRANK AND PISTON PIN BEARINGS, BY FORCE FEED

feeds to the cylinders are generally employed. This aggravates the difficulties. The oil then works itself in between and behind the piston rings where it gradually bakes and decomposes forming deposits that cause the rings to stick in their grooves.




The trade names of oils suitable for lubricating ATLAS IMPERIAL DIESEL ENGINES and the names of the companies marketing them are far too numerous to mention in the limits of this book. We have found from our experience that a high grade oil of the following characteristics usually meets all the requirements.

SPECIFICATIONS

Flash Point	360°F or over
Fire Point	425°F or over
Viscosity (Saybolt) @ 210°F—	65 Secs. or over

In the selection of a lubricating oil it must be remembered that only oils of the highest grade should be used. In order to assure yourself on this point, deal with a reputable oil company. Most oil companies maintain lubricating engineers on their staffs and these men should be consulted freely as they can make recommendations on the ground with the full knowledge of the conditions under which the engine is to work.

On 4 cyl. 6½x8½ only
18° and 6°



VALVE TIMING:

Referring to the diagrams:

Diagram A shows the portion of the revolution relative to top center for the opening and closing of spray valves. Remember that this valve setting is based on the governor being set at full speed position, which in turn will permit the maximum lift of the spray valve.

Diagram B—Has reference to the intake valve which admits air to the cylinders during the intake stroke. This diagram shows approximately the time that the intake valve should remain open. When the proper time for closing has been adjusted, which is 215 degrees past scavenging top center then the time of the opening of the intake valve will take care of itself, the same as the exhaust valve.

Diagram C—Exhaust valve—shows approximately the period that the exhaust valve should remain open. In timing the exhaust valve only pay attention to the opening time. If the cams are so set as to open the exhaust valve at approximately the correct position, which is 145 degrees past top firing center as shown on diagram, then the closing time will take care of itself, due to the size of the lobe of the cam.

It is not essential that the air intake and exhaust valve settings should be exactly on the degree as they may vary two or three degrees either way without interfering with either power, economy or running condition of the engine.

In adjusting the valve setting at any time do so by lengthening or shortening the valve lifter rods by screwing them in or out of the rocker fork which is attached to the outer end of the rockers.

TIMING OF AIR STARTING VALVE:

See that the Globe valve on the air line is closed.

Place the air starting lever No. 570 (See page 40) over to the front side of the engine which is the starting position. Then turn the flywheel around until 5° before top center on compression stroke of the particular cylinder being adjusted. Then adjust the air starting pushrod by screwing the pushrod socket in or out so that the valve will just begin to open. Then tighten jam nut on pushrod to insure against the valve adjustment's changing. The time of closing of the air starting valve will take care of itself, as it is determined by the lobe of the cam.

ADJUSTMENT AND TIMING OF ALL THE VALVES:

When an engine is shipped from the factory all valve timings are adjusted properly for running. If, however, for any reason the engine has been partly dismantled during installation or shipment, or if some one has interfered with the valve settings (while crating and shipping) then it may become necessary to retime the valves before starting the engine. The most important valve to have correctly timed is the spray or fuel valve, located in the center of the cylinder head.

FIRING ORDER OF THE ENGINES:

Number ONE cylinder is the one located next to the flywheel, or the governor end of the center frame. The firing order for the three cylinder engine is 1-2-3, and for the four cylinder engine is 1-2-4-3.

Turning the engine "towards you" means turning the flywheel counter clockwise, the flywheel being viewed from the flywheel end of the engine looking towards the rear of fan spindle end of the engine.

SPRAY VALVE NOZZLE OR TIP:

The spray valve nozzle or tip is an important factor in the proper running of the Atlas-Imperial Diesel engines. The correct size tip used on the various engines is of great importance, as it regulates the spray of the injected fuel oil or vapor into the cylinder. To insure proper functioning of the spray valve it is paramount that the holes of the tip be kept clean at all times. It is very important that the spray valve be tight and does not leak.

The size tips used on the engines according to their bore and stroke is shown in the table below:

	SIZE OF HOLE	NO. OF HOLES	STAMPED
4 Cyl. 6½" x 8½"	8	5	8
3 and 4 Cyl. 7½" x 10½"	8	5	8
4 Cyl. 9" x 12"	10	5	10

SPRAY VALVE:

The function of the spray valve is to admit the fuel to the cylinders at the proper time and at the same time deliver the fuel oil in the form of a very finely atomized spray so that the fuel is readily ignited and properly burned within the cylinder. The spray valve is located in the center of the cylinder head and extends clear through the head, with the spray valve tip projecting slightly below the bottom of the cylinder head. It is provided with a needle valve held in position by a strong spring, the tension of which is slightly adjustable. The fuel oil is admitted below the stuffing box at a pressure anywhere from 1000 to 3500 pounds per square inch (depending on the adjustment of the pressure regulating valve). This spray valve is held in position by a clamp arrangement having a single stud thus making it easily removable for inspection or cleaning. It is operated by a lifting rocker arm which lifts the valve approximately 2/100 of an inch when the engine is pulling its full load. The governor controls the lift of these valves so that when the engine is running idle the lift is very little and only sufficient to admit enough fuel to turn over the engine. As the load increases the engine governor causes these valves to raise slightly more and consequently admit additional fuel in direct proportion to the power developed.

CARE AND MAINTENANCE:

To insure proper functioning of the spray valve it is paramount that

it be kept clean and the holes in the tips be absolutely clear of any impurities. The packing on the stem should be screwed up just tight enough to hold the pressure, for if too tight it will cause excessive wear on the valve stem, thereby causing the valve to work in a very sluggish manner or to remain open allowing too much fuel to enter the cylinder. When such a condition exists the cylinder relief valve will begin to blow off due to the excessive pressure which arises in the cylinder under such conditions.

If any of the tips become clogged with dirt or any other matter, the fuel is thereby unable to enter the combustion chamber in its usual manner and will cause a reduction in the revolutions of the engine, also its power, for the lack of enough fuel. This condition is more apt to occur in a new installation due to dirt and the likes that is in the piping and the tips will have to be cleaned until this disappears or is worked out. If clean pure fuel is used the tips will only have to be cleaned on very few occasions.

When the valves have been disassembled to be cleaned care must be taken to readjust them properly when placing them back in the cylinder heads. The maximum lift of the spray valve spindle should never be more than 2/100 of an inch in any case. Excessive lift will only be an unnecessary waste of the fuel, while not sufficient lift will cause the lifters and cams to make excessive and unnecessary noise. The screw strainer in the side of the spray valve should be checked to see that it is not striking the spray valve stem and is also screwed in the strainer far enough to miss the nipple part of the union.

ADJUSTING AND TIMING OF SPRAY VALVES:

Put the governor control handle in full speed position, place the engine starting lever in running position. Close all isolating valves on the fuel rail. Open all cylinder relief or snifter valves. Bar over flywheel in running direction until pointer on engine frame corresponds to a few degrees before mark on flywheel showing opening of spray valves. Then open isolating valve corresponding to cylinder you are timing. Be sure that the piston in that particular cylinder is nearing the top of its compression stroke, which is easily ascertained by the fact that both the inlet and exhaust valves remain closed during that stroke. **CAUTION: NEVER ATTEMPT TO TURN THE FLYWHEEL WITH THE BAR UNLESS ALL CYLINDER SNIFFER VALVES ARE ENTIRELY OPENED.**

Pump up fuel pressure by hand fuel pump to about two thousand (2000) pounds pressure. Then continue barring the flywheel over SLOWLY until the pointer on the engine frame registers with mark on flywheel, showing opening of the spray valve. (Referring to Diagram A, on Page 15.) If at that point the fuel pressure on gauge does not release, then loosen jam nut under push rod fork for that particular spray valve, and adjust the push rod by screwing it in or out as the case may be until the pressure is released at that particular point. If the pressure is released before the flywheel is turned to the proper point indicated on the flywheel, then the rod is too long and must be shortened by screwing it into the fork slightly; and if the pressure does not release when the flywheel has been turned to the proper point as above referred to, then the rod should be unscrewed and thereby lengthened until it releases at the exact point.

When this has been accomplished lock the jam nut tight under the fork, turn the flywheel back again to see if the tightening of the jam nut has slightly altered the timing, in which case it must be loosened again,

and the rod screwed into the fork slightly farther, and the jam nut tightened again. Turn the flywheel backwards again a few degrees, then turn ahead very slowly to see that the pressure releases exactly at the desired point.

It will be necessary to pump up pressure with the hand pump each time.

In order to ascertain the time of closing of the spray valve, turn the engine ahead until the mark on flywheel showing closing of spray valve is past the point. Then pump up pressure, bar the flywheel backwards again until the pressure is released. This will determine the exact point of the flywheel where the spray valve closes.

If this varies a little from 18 degrees DO NOT change push rod, as time of opening of the valve is most important. If it closes earlier than 15 degrees or later than 20 degrees then the cam on the cam shaft must be turned away from you to make the closing come later and toward you to make the closing come earlier. After moving the cam the push rod must again be adjusted. Changing the location of the cam should only be necessary at very infrequent intervals.

After timing of the spray valves it is good practice to open all snifter valves, and turn engine over a few times by air, this will remove any excess fuel oil that may have accumulated in the cylinders.

Once a week the timing should be checked over and the valve corrected.

Proceed in this same manner with the spray valves on each cylinder in which timing needs checking up. It is important that the valve timing in the spray valves be correct on all cylinders in order that they all may be working equal when the engine is running.

If black smoke issues from the exhaust pipe ascertain which cylinder is smoking, the cause of the smoke being either due to too much fuel entering that cylinder, or that some of the spray tips are partly plugged up, spreading the fuel unequally into the cylinder, or admitting so little fuel to some of the cylinders that an excessive load is put on some one individual cylinder; or, that the spray valve may be leaking either at the valve seat or at the joint between spray tip and spray valve body. It is of utmost importance that the spray valve be absolutely tight so that no fuel can enter the cylinder at any other time excepting during the period when the valve is opened by the spray cam, which should be at all times kept in proper adjustment.

Whenever a spray valve is removed from the head for the purpose of cleaning, grinding, or adjusting, then upon replacing the spray valve the timing of that valve must be checked up again as a slight alteration may be caused by the replacement.

INSTRUCTIONS FOR REMOVING AND CLEANING SPRAY VALVE:

Take out cotter pin and pin No. 873 from spray rocker fulcrum. Slip out horseshoe collar from under spray valve stem nut. Unscrew high pressure fuel union nut and pull tube away a little from spray valve. Loosen spray valve clamp nut enough to slide spray valve clamp back and remove spray valve. In case spray valve gasket remains on spray valve in removing, make sure it is replaced in cylinder head.

REMOVING SPRAY VALVE TIP:

Unscrew spray valve seat nut and, if tip remains in seat nut, a small

brass punch is provided for removing and a few light taps are sufficient to loosen tip. In doing this care should be taken not to mar the tip.

CLEANING SPRAY TIP:

A wire spray valve tip cleaning needle, is provided, to be used when the spray tip is plugged or clogged with any foreign substance. This needle should be inserted into the small holes at the proper angle which is about 30° from horizontal. Do not twist or turn needle in holes as this may cause reaming and would make an uneven spray. Clean tip with gasoline and a small plunger is also provided to be used to force gasoline through the small holes to determine if all the holes are entirely free and open. Assemble tip and place in testing clamp.

SPRAY VALVE TEST CLAMP:

There is a connection located on the high pressure fuel rail for the purpose of testing out the spray valves after cleaning them, to see that the spray holes are clean.

A bracket located on the base directly beneath this connection to which a stand is attached for holding the spray valve and also has a lever for lifting the valve in the same manner as the rocker on the head does.

HOW TO USE THE TEST CLAMP:


First close all the isolating valves on the fuel rail. Then after spray valve has been fastened in the stand attached to the base, connect the spray valve with its connection to the connection on the fuel rail. After all connections have been inspected and tight, pump up the fuel pressure by the hand priming pump. Then open the valve by hitting the end of the test stand handle with a quick short tap, watch closely to ascertain if a fine spray of fuel comes out of EACH separate hole in the tip.

When assembling the spray valve make sure that all of the parts have been put together tight and do not leak, for a leaky spray valve is one of the greatest reasons why the engine will not run properly.

Care should be taken not to forget to close the isolating valves on all of the cylinder heads for if they are left open a large amount of oil will gather on the top of the piston head, and when the engine is started there is liable to be lots of trouble, due to the excessive amount of oil being compressed in the cylinder.

GRINDING THE SPRAY TIP AND STEM:


Loosen spray valve spring plug No. 857 until spring tension is released. Pull spray valve stem back a little and not beyond the end of spray valve body as this may disturb packing. Apply a little fine grinding compound on shoulder of tip and grind seat on spray valve body. Apply a little fine grinding compound on tip of stem and grind seat in tip. Wash tip in gasoline using plunger to clear holes. If occasion arises to pull stem from body the packing should be removed and the body cleaned to prevent small particles of packing working down and clogging tip. Repack stem. After final test of spray valve the lift should not be more than 1/16 of an inch. This is adjusted by either loosening or tightening the spray valve spring plug.



CENTRIFUGAL PUMP

- | | | | |
|------|--|------|---|
| G370 | Centrifugal pump, complete: Part Nos. 370, 370B, 370C, 370D, 370E, 371, 371A, 371B, 371F, 372, 373, 373A, 373B, 374, 374A, 379, 381, 381A, 381C, 383, 386, 386A. | 373B | Cent. pump shaft gland stud nut |
| 370 | Cent. pump body | 374 | Cent. pump shaft bushing |
| 370A | Cent. pump inlet or outlet flange | 374A | Cent. pump shaft flax packing |
| 370B | Cent. pump grease cup | 379 | Cent. pump runner shaft |
| 370C | Cent. pump inlet or outlet flange gasket | 381 | Cent. pump steady bearing |
| 370D | Cent. pump holding down cap screw | 381A | Cent. pump steady bearing cap screw |
| 370E | Cent. pump body drain cock nipple | 381C | Cent. pump steady bearing clamp screw |
| 370F | Cent. pump body drain cock | 383 | Cent. pump radial thrust ball bearing |
| 370G | Cent. pump flange cap screw | 384 | Cent. pump shaft coupling |
| 371 | Cent. pump cover | 386 | Cent. pump ball bearing housing |
| 371A | Cent. pump cover screw | | Cent. pump ball bearing housing clamp screw |
| 371C | Cent. pump cover gasket | 386A | Cent. pump ball bearing retainer |
| 372 | Cent. pump runner with shaft No. 379 | | Cent. pump ball bearing retainer lock set screw |
| 373 | Cent. pump shaft gland | | Cent. pump shaft guard |
| 373A | Cent. pump shaft gland stud | | Cent. pump shaft guard bracket |
| | | | Cent. pump shaft guard bracket screw |
| | | | Cent. pump shaft guard bracket cap screw |

Always Give Part Name, Part Number and ENGINE NUMBER




CYLINDER HEAD

- | | | | |
|-------|---|------|--|
| G500 | Cylinder head complete; except spray valve | 550A | Exhaust rocker bushings (set of 2) |
| GA500 | Cylinder head, with valves and springs only | 565 | Rocker shaft |
| 500 | Cylinder head | 566 | Rocker shaft bearing |
| 501 | Cylinder head stud | 567 | Rocker shaft bearing stud |
| 501A | Cylinder head stud, special for lifting head | 567A | Rocker shaft bearing stud nut; top |
| 501B | Cylinder head stud nut | 567B | Rocker shaft bearing stud lock nut |
| 502 | Cylinder head gasket | 567C | Rocker shaft bearing stud, long |
| 505 | Cylinder head cover | G580 | Air starting valve, complete; Part Nos. 579, 580, 582, 583, 584, 585, 586, 588 |
| 505A | Cylinder head cover stud with handle | 590 | Air starting rocker, with roller and pins |
| 510 | Valve and stem, inlet or exhaust | 590A | Air starting rocker bushings (set of 2) |
| 512 | Valve stem bushing, inlet or exhaust | 764 | Exhaust elbow stud |
| 513 | Valve spring, inlet or exhaust | G849 | Spray valve complete |
| 514 | Valve spring bushing, inlet or exhaust—top | 854 | Spray valve clamp |
| 514A | Valve spring bushing, inlet or exhaust—bottom | 854A | Spray valve clamp stud |
| 514B | Valve stem nut | 855 | Spray valve clamp bridge |
| 520 | Inlet rocker, with buttons | 855A | Spray valve clamp bridge nut |
| 520A | Inlet rocker bushings (set of 2) | 870 | Spray valve rocker and pins |
| 526 | Push rod socket, inlet, exhaust, air, or fuel | 872 | Spray valve rocker fulcrum |
| 527 | Push rod button, inlet, exhaust, air and fuel | 873 | Spray valve rocker pin |
| 550 | Exhaust rocker with buttons | 877 | Spray valve horse shoe collar |
| | | 1171 | H. P. fitting through head |

Always Give Part Name, Part Number and ENGINE NUMBER

FORCE FEED OILER




The force feed oiler used for oiling the cylinder walls of the engine is driven off of the cam shaft by means of a crank disc.


- 1060 Force feed lubricator
- 1060A Force feed lubricator drive arm
- 1060B Force feed lubricator connecting rod eye
- 1065 Force feed lubricator drive rod.
- 1065A Force feed lubricator drive rod pin.

Air Starting Valve

THE air starting valve shown below is used for starting the engine. It is of the 4 cycle type, operated by the air starting rocker, which in turn is actuated by air starting cam on the cam shaft. The starting lever is in running position when it is leaning toward the exhaust side of the engine. When it is leaning toward the operator's side of the engine then it is in starting position.




- 579 Spring bushing
- G580 Valve, complete; Part Nos. 579, 580, 582, 583, 584, 585, 586, 588.
- 580 Valve
- 582 Spring
- 583 Spring washer, top
- 584 Nut
- 585 Balance bushing
- 586 Balance bushing ring
- 588 Spring washer, lower



FLY WHEEL

Used on 8½" and 9" Bore

- 750 Flywheel
- 751 Flywheel coupling
- 752 Flywheel friction bolt (special).
- 753 Flywheel clamp bolt




FLY WHEEL

Used on 6½" and 7½" Bore

- 753 Flywheel clamp stud
- 753A Flywheel clamp stud washer
- 753B Flywheel clamp stud nut


Always Give Part Name, Part Number and ENGINE NUMBER

Cylinder Lubricating Pipe





The cylinder lubricating oil pipe shown here for lubricating the piston and cylinder walls of our engines requires but three or four drops of oil per minute. It is fed from a force feed oiler through a small copper pipe. A gland and packing keep the water from leaking out of the cylinder jacket.

- 600 Cylinder
- 611 Cylinder lubricating pipe
- 612 Gland
- 613 Packing
- 614 Elbow



AIR COMPRESSOR


- | | | | |
|------|---------------------------------------|------|---|
| 630 | Engine connecting rod | 929 | Air compressor connecting rod |
| 636 | Crank pin box | 930 | Air compressor eccentric strap |
| 640 | Crank shaft | 932 | Air compressor eccentric strap bolt |
| 646 | Crank shaft bushing, center | 933 | Air compressor eccentric |
| 713 | Base cap, center | 935 | Air compressor relief valve |
| 900 | Air compressor cylinder | 936 | Air compressor pass over pipe to head |
| 900B | Air compressor splash plate | 937 | Air compressor gauge (300 lbs.) |
| 901 | Air compressor head | 1306 | Centrifugal pump chain sprocket, driver |
| 925 | Air compressor piston | | |
| 926 | Air compressor piston ring | | |
| 927 | Air compressor piston pin | | |
| 928 | Air compressor connecting rod bushing | | |



INTERMEDIATE GEAR

- 640 Crankshaft
- 660 Crankshaft pinion
- 664 Intermediate gear
- 664A Intermediate gear ring
- 665 Intermediate gear pin
- 665A Intermediate gear pin bolt
- 665B Intermediate gear pin bolt washer

- 665C Intermediate gear bearing pin bolt washer
- 665D Intermediate gear pin bolt nut
- 666 Intermediate gear bearing
- 666A Intermediate gear bearing cap screws
- 666B Intermediate gear bearing lock screw



AIR COMPRESSOR

- G901 Head, complete; Part Nos. 901, 905, 907, 908, 908A, 915, 915A, 918, 918A, 919, 920, 922, 922A, 923, 924
- 901 Head
- 902 Stud
- 905 Inlet valve
- 906 Grid
- 907 Inlet valve bushing
- 908 Inlet valve spring
- 908A Inlet valve nut
- 908B Air compressor inlet valve washer
- 915 Discharge valve

- 915A Discharge valve adjusting screw
- 918 Discharge valve flange
- 918A Discharge valve relief handle nut
- 918C Air compressor discharge valve flange stud
- 919 Discharge valve spring
- 920 Discharge valve guide
- 922 Discharge valve cap nut
- 922A Discharge valve relief handle
- 923 Discharge valve guide cap
- 924 Discharge valve spring bushing

Fuel Oil

Theoretically, a Diesel engine should burn any petroleum product if properly prepared. However, there are certain impurities in almost all fuel oils which determine to a large extent the suitability of those oils for operation in a Diesel engine. The following brief description of the various impurities, with their effect upon the engine, is given to guide the purchaser and the oil supplier in the selection of a proper fuel oil.

GRAVITY

Specific gravity is in itself no indication of the suitability of a Diesel fuel oil.

VISCOSITY

The viscosity of a fuel oil will determine its suitability by the effect that it has on the flow of the fuel oil through the pipes, valves and so forth. An oil of high viscosity that may be in all other respects satisfactory will require heating to enable it to flow satisfactorily through the fuel lines, valves and so forth. Another effect of high viscosity is the resistance that it offers to vaporization, requiring variation in the size of the burner tips.

MECHANICAL IMPURITIES

Under this heading come such elements as dirt, grit, fiber and water. The small holes in the spray valve tips, strainers and so forth are liable to become clogged if there is too large an amount of mechanical impurities. Besides this, they have the effect of cutting out the seats of the valves.

CARBON RESIDUE

This is a characteristic of fuel oil which has only recently received attention, at least in Diesel fuel oil specifications, and one which has quite an effect on the operation of an engine. This carbon residue (Conradson carbon) is a measure of the proportion of carbon deposits that are likely to occur on the piston, cylinder head, valves and so forth. A high percentage of Conradson carbon is usually associated with carbon formation within the cylinders, as well as gumming up of the valves and stems.

LUBRICATING VALUE

All petroleum products have a certain amount of oiliness and the higher this oiliness is in a fuel oil the less wear will be noticed on the pump plungers, spray valve stems and such similar parts. Very light oils, such as kerosene, contain little or no lubricating value and therefore their use will usually result in excessive wear on the pump plungers, spray valve stems and so forth.

The following are the general characteristics of a suitable Diesel fuel:

Viscosity (Saybolt Universal) at 100° F.....	35 to 60 seconds
Sulphur content	1.5% maximum
Conradson carbon	1% maximum
Moisture and sediment.....	.5% maximum
Ash05% maximum

Legal regulations usually limit the flash to a minimum of 150° F.

Diesel fuels from California crudes are readily obtainable, meeting the above specifications in gravities between 24 and 30° API. Midcontinent fields produce so-called gas oils with gravities ranging from 32 to 33° API. European oils likewise come within this same range.

We cannot place too much emphasis upon the importance of getting oil which is free from impurities to avoid the clogging of valves, strainers, spray valve tips and so forth and upon the desirability of securing an oil with as much oiliness as possible to avoid wear on some of the vital parts of the engine.

DO NOT CONFUSE DIESEL FUEL WITH ORDINARY BOILER OIL. THE LATTER CONTAIN DIRT AND SEDIMENT WHICH MAKE THEM UNSUITABLE FOR A DIESEL ENGINE.

A heavy fuel oil thinned down by the addition of a lighter oil is not a satisfactory fuel, as the lighter oils in such a mixture burn off rapidly and leave the heavier oil to gum up piston rings and valves and cause excessive cylinder wear. Insist on getting a straight run distillate for your fuel.

CARE OF FUEL OIL

The best fuel oil can be ruined if not properly handled. Store and transport your fuel in clean container and use your containers for fuel oil only. Flush out the container frequently to remove any dirt, rust or scale that may accumulate.

Keep your containers closed to prevent dust, dirt and water getting in the fuel oil, as these impurities in the fuel are bound to cause you more trouble and annoyance than required to keep your fuel clean. Provide means in your storage tanks for draining off any water that may be present.

Draw fuel from storage tank through a pipe inserted in top of tank. Be sure the lower end of suction pipe is 3 or 4 inches above the bottom of tank. This allows dirt and water to settle to bottom of tank where they can be occasionally drawn off.

An engine supply tank should be provided big enough to hold at least a day's supply of fuel.

Strain the fuel oil when transferring it from storage tanks to engine supply tank. A good strainer can be made from a five-gallon can by cutting off the top and inserting therein a conical strainer made from 150-inch bronze gauze. Cut the gauze into 4 triangles and solder the upper edges to the top of the can. Have the lower point of the gauze about 2 inches above the bottom of the can. Punch a hole in the bottom of the can and solder on a piece of 1½" brass pipe, which can be inserted in engine supply tank filling hole. Be sure to use a new bright clean can free from rust or dirt. Keep the strainer away from dust and dirt when not in use and wash out frequently.

Fuel Oils

TO assist in obtaining the proper oil to be used as fuel in this engine, we transmit herewith our recommendations. These recommendations are the results of past experiments which have been conducted by us.

In purchasing the fuel oil to be used for this engine, you should advise the oil company that it will be used in a full type mechanical injection Diesel engine. We recommend that your first purchase be only a few hundred gallons rather than a large supply, in order to be sure that you obtain the proper kind of oil.

There are two characteristics of oil which are of **EQUAL IMPORTANCE**. First, its **GRAVITY**; and second, its **VISCOSITY**.

It has been found that low Gravity oils are not satisfactory for all year service as they congeal in cold weather. Similarly it has been found that high Gravity oils, or oils about 38° or higher do not function satisfactorily at all times, especially in the warmer temperatures.

Therefore, the results of the various tests conducted reveal the following:

1. It has been found that any oil of less than 24° Gravity Baume must be filtered and heated. While this oil may be satisfactorily used in certain localities, generally speaking it is unsatisfactory for the average installation where cold weather is encountered, on account of the difficulty in heating the oil.

2. That 24° to 28° Gravity Baume oil is usually clean and needs no heating or straining before reaching the filter provided on the engine except in extremely cold weather providing the oil has the proper Viscosity.

3. The conclusions reached with regard to engines that must be operated at zero temperatures are that during cold weather periods oils from 32° to 38° Gravity Baume should be used, but that at all other times the 24° to 28° Gravity Baume oil should be used.

The Viscosity should be from 40 to 50 seconds with a Saybolt test 100° Fahrenheit. If the Viscosity runs to any great degree higher than 50 seconds, you will find that the oil is too thick for use as it is liable to clog the strainers and pumps.

"Do not confuse Diesel fuel oil with ordinary boiler or furnace oil. The latter contain dirt and sediment, which make them unsuitable for operation in a Diesel engine."

Therefore, specifications for the oil best suited for this engine are as follows:

Gravity—24° to 28° Baume.

Caloric value—18,500 B. T. U's.

Percentage of Sulphur—Less than 1/2 of one per cent.

Flash Point—Not lower than 150° Fahrenheit.



Viscosity—40 to 50 seconds, Saybolt test 100° Fahrenheit.

Irrespective of what oil is used, it is necessary that the oil be refined to the extent that all water, sand and grit be removed.

You will note from the above that the fuel oil most suitable is one from 24 to 28 degrees gravity.

This is the oil which we ordinarily use to test the engine at our plant. It is known as Fuel Oil or Diesel Fuel Oil and it is sometimes incorrectly called Crude Oil.

For temperatures from zero to 15° Fahrenheit above zero it would probably be best to use 32° Baume Gravity Oil, but for sub-zero temperatures you would have to use a 36° Baume to 38° Baume Gravity Oil.




FUEL PUMP

Fuel Pump

796	High pressure fuel discharge fitting	Fuel pump cross head guide cap screw
796A	High pressure fuel discharge fitting split ring	831 Fuel pump crosshead
797	High pressure fuel discharge fitting nut	831A Fuel pump crosshead nut
800	Fuel pump body	831B Fuel pump crosshead button
800A	Fuel pump body nut	831C Fuel pump crosshead bushing
801	Fuel pump suction valve	831D Fuel pump crosshead oil guard
802	Fuel pump suction valve cage	846 Fuel pump housing
802A	Fuel pump suction union nut	846A Fuel pump housing stud
802B	Fuel pump suction union sleeve	Fuel pump housing stud nut
805	Fuel pump plunger	847 Fuel pump housing cover
805A	Fuel pump plunger spring	Fuel pump housing cover hinge
806	Fuel pump packing	Fuel pump housing cover hinge screw
808	Fuel pump gland	1173 Fuel pump bleeder connection
809	Fuel pump gland nut	1176 High pressure fuel union nut
809A	Fuel pump gland lock nut	1178 High pressure fuel union sleeve
810	Fuel pump plunger head	1178 High pressure fuel union sleeve, blind end
810B	Fuel pump plunger nut	G1274 Priming pump only; Part Nos. 1275, 1276.
811	Fuel pump discharge valve	1275 Priming pump cylinder
817	Fuel pump plate	1276 Priming pump plunger
	Fuel pump plate steel cover (front)	1276A Priming pump plunger nut
	Fuel pump plate steel cover (top)	1278 Priming pump cap
	Fuel pump plate steel cover screw (large or small)	1279 Priming pump plunger eye
	Fuel pump plate and housing slotted cap screw	1279A Priming pump connecting rod link
822	Fuel pump crank	1279B Priming pump link eye
G823	Fuel pump connecting rod, assembled, Part Nos. 823, 824, 824A.	Priming pump link eye nut
823	Fuel pump connecting rod	1280 Priming pump connecting rod
824	Fuel pump connecting rod cap	1280A Priming pump connecting rod pin
824A	Fuel pump connecting rod cap bolt	1281 Priming pump handle
	Fuel pump connecting rod cap bolt nut	1284 Priming pump handle push rod
828C	Fuel pump cross head pin	1284A Priming pump handle push rod fulcrum
829	Fuel pump cross head guide	

Always Give Part Name, Part Number and ENGINE NUMBER

Cut No. 101




SPRAY VALVE

- | | | | |
|------|---|------|-----------------------------------|
| G849 | Spray valve, complete ; Part Nos. 850, 851, 853, 856, 857, 858, 859, 860, 864, 865, 866, 867, 878, 878A, 1201, 1202, 1204 | 865 | Spray valve gland nut |
| 850 | Spray valve stem | 866 | Spray valve packing seat |
| 851 | Spray valve body | 867 | Spray valve horseshoe collar |
| 853 | Spray valve spring casing | 877 | Spray valve stem lock nut |
| 856 | Spray valve seat nut | 878 | Spray valve stem nut |
| 857 | Spray valve spring plug | 878A | Spray valve stem lock nut |
| 858 | Spray valve spring | 895 | Spray valve testing outfit |
| 859 | Spray valve spring ball bearing | 896 | Spray valve cleaning needles |
| 860 | Spray valve gasket | 897 | Spray valve tip or nozzle remover |
| 864 | Spray valve nozzle or tip | 898 | Spray valve tip cleaner plunger |
| | | 1201 | Fuel strainer body |
| | | 1202 | Fuel strainer stem |
| | | 1204 | Fuel strainer gasket |

Always Give Part Name, Part Number and ENGINE NUMBER

Fuel oils lighter than distillate, such as kerosene, etc., are not suitable for this engine. It is possible that you may be able to adjust the engine so it will function satisfactorily for a short period, but the engine is not intended for such oils and if used trouble probably must be expected later, as such fuels will damage the valves and pumps. This is equally true of any other Diesel or Semi-Diesel engine.

Fuel and lubricating oils are filtered by means of a strainer located on the base or on the fuel lifter housing, and fastened by brackets which are made suitable for the different sizes of engines.



FUEL RELIEF VALVE, REMOTE CONTROL

Fuel Relief Valve

1117	Handle		1236	Spring
1118	Pawl		1237	Spring cage
1124	Pawl spring		1238	Handle bearing
1125	Pawl spring screw		1238A	Handle bearing pin
G1230	Valve, complete	Part Nos.	1239	Handle adjusting screw
	1117, 1118, 1124, 1125, 1230,		1240	Handle plug, lower
	1231, 1232, 1233, 1234, 1236,		1242	Fuel fitting
	1237, 1238, 1238A, 1239, 1240,	G1243	Handle, complete; Part Nos.	
	1242, 1243, 1244, 1245, 1249.		1117, 1118, 1124, 1125, 1243,	
			1249.	
1230	Body		1243	Handle
1231	Gland		1244	Handle section
1231A	Gland packing ring		1245	Spring plug, top
1232	Stud		1249	Handle screw
1233	Stem			
1234	Seat			

THE fuel relief, is a spring loaded valve connected directly to the high pressure fuel pumps by means of steel tubing, and is equipped with an adjustable spring tension. The purpose of this valve is to regulate the pressure of fuel delivered to the spray nozzles. It is essential that the pressure be kept to about 3500 pounds when the engine is working under normal loads. An increased pressure causes an excess amount of oil to enter the cylinder, thereby increasing the heat. The normal initial temperature at the time of ignition when the engine is developing its rated horse-power is approximately 1200 degrees Fahrenheit. Additional fuel pressure makes it possible to raise this temperature up to 2400 degrees Fahrenheit.

The increase in pressure will increase the power to some extent but not in proportion to the increase in pressure or heat produced.


The high momentary temperature has a tendency to destroy the metal in the cylinder heads as well as in the top of the piston. The quick changing of temperature from high flash to cold intake period will eventually start minute surface cracks which in time increases in depth as well as in area. This is likely to cause cracked piston heads and cylinder heads. This clings to the cylinder head and valves causing the valves to leak.

With the increased pressure on the fuel line, more oil is injected into the cylinder than can be used, and consequently it will leave a carbon deposit.


It will be readily understood that the higher the pressure on the fuel line the greater will be the quantity of fuel admitted to the cylinders during a given period of spray valve opening. If the engine is idling, the pressure should be reduced to about 1000 pounds. The altering of pressure is accomplished by manipulating the handle on top of the fuel relief valve.

When the engine has been adjusted to a certain pressure of fuel suitable for a fixed load, then it is essential that this pressure be maintained uniformly. This valve is so constructed that any quantity of oil over and above that which goes through the spray nozzles at the fixed pressure will be by-passed and let back into the fuel tank. In this way this fuel relief valve automatically maintains the pressure and takes care of the surplus fuel pumped by the high pressure fuel pumps.

If the fuel relief valve leaks, make sure that valve stem is working freely and not stuck or sluggish in packing; if this is found to be all right then the valve is leaking at seat and should be reground with a very fine abrasive.




ROTARY PUMP—CLAMP STYLE



ROTARY PUMP—FOOT STYLE

- | | | | |
|------|---|------|--|
| 692 | Centerframe door (round) | 1341 | Rotary pump gear and shaft driver for $\frac{1}{4}$ " outlet pump |
| 692A | Centerframe door gasket | 1342 | Rotary pump gear and shaft driven for $\frac{1}{4}$ " outlet pump |
| 692D | Centerframe cover cap screw | 1351 | Rotary pump felt washer |
| 693 | Rotary pump door | 1352 | Rotary pump gear, driven |
| | Rotary pump door cap screw | 1353 | Rotary pump gear driver on cam shaft coupling |
| | Rotary pump door gasket | 1354 | Rotary pump ball bearing |
| 693A | Rotary pump door bearing cap | 1355 | Rotary pump drive shaft |
| 693B | Rotary pump door ball bearing retainer | 1371 | Rotary pump gear and shaft for $\frac{1}{4}$ " outlet pump. Driver |
| | Rotary pump door ball bearing retainer screw | 1372 | Rotary pump gear and shaft driven for $\frac{1}{4}$ " outlet pump |
| 693C | Rotary pump door clamp cap | 1378 | Rotary pump, complete; $\frac{1}{2}$ " outlet |
| 693D | Rotary pump door clamp cap screw | | Rotary pump holding down cap screw |
| 693E | Rotary pump door cap—cap screw | | |
| 1338 | Rotary pump, complete; $\frac{1}{4}$ " outlet | | |



DAY TANK


- | | | | |
|-------|--|-------|--|
| G1295 | Day tank, complete, Part
Nos. 1295, 1296, 1297,
1297A, 1297B, 1298, 1299 | 1297B | Day tank casing collar
wing nut |
| 1295 | Day tank casing | | Day tank casing collar eye
bolt pin |
| 1296 | Day tank cover | 1298 | Day tank casing collar bot-
tom |
| | Day tank cover pipe plug | | Day tank casing collar bot-
tom clamp cap screw |
| | Day tank cover holding
down cap screw | 1299 | Day tank strainer |
| 1297 | Day tank casing collar | | |
| 1297A | Day tank casing collar eye
bolt | | |

Always Give Part Name, Part Number and ENGINE NUMBER

Lubricating Oil Sump Pump

THE lubricating oil sump is located at the center of the engine underneath the base, and is provided with angular draining trough from all of the crank pits so that the circulating oil finds its way to the bottom of the crank pits and drains into the sump. The proper level of lubricating oil in the sump is shown in cut of engine and indicated by dotted line marked "Oil Level." Within this sump is a strainer which prevents the carbon deposits from entering the lubricating oil pump.

The lubricating oil pump receives the oil from the bottom of the oil reservoir or sump and delivers it to the distributing manifold, which connects to the bottom of each of the main bearings. The main bearings are fitted with bearing shell, very closely fitted around the entire crank shaft for the purpose of holding the lubricating oil. The clearance between the bearings and the shaft should only be sufficient to allow a good film of lubricating oil. If the bearings are scraped free at the joints, then the lubricating oil, which is pumped through the bearings, finds too ready an outlet and thereby makes it impossible for the oil pump to maintain a pressure on the oil sufficient to send it up through the connecting rod to the wrist pin bearings.



G1090	Valve, complete; Part Nos. 1090, 1091, 1092, 1093, 1095.
1090	Body
1091	Plunger
1092	Adjusting screw
1093	Spring
1095	Adjusting screw nut
1096	Check valve

PRESSURE LUBRICATING RELIEF VALVE


A pressure lubricating relief valve, used in connection with the lubricating oil sump and pressure pump, is used to maintain a constant and determined pressure of the lubricating oil on its course through the engine. To adjust the valve, first loosen the adjusting screw nut and then tighten or loosen the adjusting screw to suit requirements desired. Then tighten the adjusting screw nut back again.

ADJUSTMENT OF SAFETY VALVE:

If while the engine is running the safety valve should blow off (at ordinary running speed) and the spray valve is known to be tight, then it indicates that the safety valve spring is weak or seat of valve is pitted.

To remedy this, tap very lightly the end of the valve stem with a hammer and with a wrench on valve nut turn valve slowly while tapping. This will cause the valve to reseal itself; if blowing still continues increase tension of the valve spring by turning the adjusting nut until sufficient tension has been exerted on the the valve spring to cause the valve to cease from blowing.

Cylinder Relief Valve or Safety Valve



G1190 Valve, complete; Part Nos. 1190, 1191, 1192, 1193, 1194, 1195, 1199.


1190 Body
 1191 Stem
 1192 Seat
 1193 Spring
 1194 Spring collar

1195 Adjusting screw lock
 1196 Cylinder plug

G1197 Snifter valve, complete; Part Nos. 1197, 1198.

1197 Snifter valve body
 1198 Snifter valve stem
 1199 Adjusting screw


THE function of the cylinder relief valve is to safeguard against excessive pressure in case too much fuel has been admitted to any one cylinder or in case fuel is admitted and ignited before the engine obtains sufficient speed, in which case the pressure may rise excessively. Excess pressure escapes through these relief valves. It is just as essential to ascertain from time to time that these valves are in working order as it would be to ascertain at regular intervals that a safety valve on a boiler is in working order. At least once a week they should be tried out. By inserting a screw driver or some such instrument between the nut on the end of the valve stem and the spring tension gland you can raise the valve from its seat while the engine is running allowing a blast of air or fire to blow from the valve for one or two strokes only. If the valve appears to leak, tap the end of the valve stem lightly with the wrench which will make the valve seat itself again. Care must be taken not to allow these valves to leak as the heat would soon destroy the valve seat and make them useless. A small needle valve called the snifter valve, located on the cylinders, on the operating side of the engine, for the purpose of opening up, to see if the cylinders are functioning properly.



GOVERNOR

G1100	Governor, complete; Part Nos. 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1113	1105	Governor weight roller plate
1100	Governor body (always supplied with No. 1111 fitted on)	1106	Governor thrust quill bearing, small
1101	Governor weight	1107	Governor thrust quill ball bearing, large
1102	Governor weight pin	1108	Governor shaft
1103	Governor weight roller	1109	Governor body collar
1104	Governor weight roller pin	1110	Governor pinion
		1111	Governor thrust quill bushing

Always Give Part Name, Part Number and ENGINE NUMBER




GOVERNOR SPEED CONTROL

- | | | | |
|-------|---|-------|---|
| 1114 | Compression spring | 1122A | Speed control socket sector |
| G1117 | Control handle, complete;
Part Nos. 1117, 1118, 1119,
1124, 1125, 1249. | G1122 | Governor speed control
handle, complete; Part
Nos. 1117, 1118, 1119,
1120, 1121, 1122, 1122A,
1124, 1125, 1249. |
| 1117 | Control handle | 1123 | Governor control socket
bearing |
| 1118 | Control handle pawl | 1124 | Control handle pawl spring |
| 1119 | Control handle sector | 1125 | Control handle pawl spring
screw |
| 1120 | Rack for compression
spring | 1249 | Control handle screw |
| 1121 | Rack adjusting screw | | |
| 1122 | Speed control socket with
sector | | |

Always Give Part Name, Part Number and ENGINE NUMBER

VALVE LIFTERS AND GOVERNOR CONTROL




VALVE LIFTERS AND GOVERNOR CONTROL


525	Push rod, inlet or exhaust valve	706	Valve lifter guide housing cover
528	Lifter with roller and pin, inlet or exhaust valve	707	Valve lifter guide housing push rod tube
529	Lifter guide, inlet or exhaust valve	876	Spray valve push rod
	Lifter guide cap screw	880	Spray valve cam toe
530	Lifter roller		Spray valve cam toe cap screw
531	Lifter roller pin		Spray valve cam toe cap screw washer
532	Inlet and air starting cam	881	Spray valve cam disc
	Inlet and air starting cam key	883	Spray valve lifter with roller and pin
560	Exhaust cam	884	Spray valve lifter roller
	Exhaust cam key	885	Spray valve lifter roller pin
G570	Air starting handle, complete	887	Spray valve lifter guide
570	Air starting handle		Spray valve lifter guide cap screw
	Air starting handle top	888	Spray valve lifter guide spring
	Air starting handle clamp cap screw	889	Spray valve lifter push rod socket
593	Air starting valve push rod	1112	Governor bearing
594	Air starting valve lifter with roller and pin	1114	Governor compression spring
	Air starting valve lifter pin	1114A	Governor compression spring collar
594A	Air starting valve lifter collar	1114B	Governor compression spring quill
594B	Air starting valve lifter spring		Governor compression spring quill bushing screw
594C	Air starting valve lifter rod socket	1115	Governor compression spring block
594D	Air starting valve lifter wedge	1117	Governor control handle
	Air starting valve lifter wedge pin	1122	Speed control socket
594E	Air starting valve wedge fork	1122A	Speed control socket sector
	Air starting valve wedge fork pin	1122B	Speed control socket handle pin
594F	Air starting valve wedge fork bearing		Governor control socket bearing cap screw
	Air starting valve wedge fork bearing set screw		Governor control socket bearing clamp cap screw
594G	Air starting valve wedge shaft	1123	Governor control socket bearing
595	Air starting valve lifter roller		Governor control socket bearing cap screw
596	Air starting valve lifter roller pin	1127	Connecting rod between forks
599	Air starting valve lifter guide	1128	Governor fork
	Air starting valve lifter guide cap screw	1128A	Governor fork shaft
672	Cam shaft		Governor fork shaft clamp cap screw
680	Cam shaft bearing	1129	Lever on vertical shaft
685	Cam shaft bushing	1129A	Vertical shaft lever pin
690	Centerframe	1130	Fork on wedge shaft
691	Governor door		Fork cap screw
	Governor door cap screw	1131	Governor wedge fork
692	Centerframe door (round)	1132	Fuel control wedge
	Centerframe door cap screw	1132A	Fuel control wedge pin
705	Valve lifter guide housing	1133	Fuel control shaft
	Valve lifter guide housing stud	1134	Fuel control shaft bearing
	Valve lifter guide housing stud nut	1134A	Fuel control shaft bearing nut
705A	Valve lifter guide housing flat cover	1135	Governor fuel shaft tension spring
705B	Valve lifter housing end plate	1136	Governor fuel shaft tension spring clamp
		1138	Governor fuel shaft handle

Always Give Part Name, Part Number and ENGINE NUMBER

CHAIN IDLER ROLLER

1326	Chain idler roller	1327C	Chain idler roller shaft
1327	Chain idler roller ball bearing	1327D	Chain idler roller shaft cap screw
1327A	Chain idler roller ball bearing spacer	1327E	Chain idler roller shaft washer
1327B	Chain idler roller ball bearing collar	1327F	Chain idler roller shaft nut
		1328	Chain idler roller bearing






FAN SPINDLE AND BEARING

- | | | | |
|-------|--|-------|---------------------------------------|
| G1316 | Fan spindle bearing, complete; Part Nos. 1314, 1315, 1315A, 1315C, 1316, 1317, 1318, 1319, 1319A, 1321, 1322, 1323, 1323A. | 1319 | Fan spindle steel cover |
| 1313 | Silent chain | 1319A | Fan spindle steel cover screw |
| 1314 | Fan spindle silent chain adjusting screw | 1321 | Fan spindle spacer |
| | Fan spindle silent chain adjusting screw nut | 1322 | Fan spindle spacer washer |
| 1315 | Fan spindle | 1323 | Fan spindle felt washer |
| 1315A | Fan spindle nut | 1323A | Fan spindle felt washer retainer ring |
| 1315C | Fan spindle nut lock washer | | Fan spindle bearing stud |
| 1316 | Fan spindle bearing | | Fan spindle bearing stud nut |
| 1317 | Fan spindle chain sprocket | | Fan spindle bearing stud washer |
| 1318 | Fan spindle roller bearing | | Fan spindle sprocket key |
| | | | Fan spindle nut lock washer screw |

Always Give Part Name, Part Number and ENGINE NUMBER




SECTIONAL VIEW OF DUST PROOF TYPE ENGINE

Dustproof Type

508	Air suction pipe	727	Base—centerframe cylinder stud
577	Air starting pipe elbow	727A	Base centerframe cylinder stud washer
577A	Air starting pipe elbow gasket	727B	Base centerframe cylinder stud nut
577B	Air starting pipe, including pipes, elbows, tee, flanged union, petcock, gaskets	729	Base frame stud
600	Cylinder	730	Frame—cylinder stud
605	Cylinder clean out cover	731	Base frame, stud, air compressor end
605A	Cylinder clean out cover gasket	760	Exhaust elbow
	Cylinder clean out cover cap screw	761	Exhaust pipe
610	Cylinder water by pass pipe	764	Exhaust elbow stud
610A	Cylinder water by pass pipe gasket	764A	Exhaust elbow stud nut
G620	Piston with rings and pin	780	Water inlet pipe
620	Piston	780A	Water inlet pipe gasket
621	Piston pin		Water inlet pipe flange to compressor
622	Piston ring (double ring)		Water inlet drain cock
622A	Piston ring, ¼" double seal		Water inlet drain cock nipple
622B	Piston ring, ¼" step cut	789	Water inlet pipe cap screw
628	Piston pin bushing		Water outlet pipe
G630	Connecting rod with ball check and bushing		Water outlet pipe cap screw
630	Connecting rod, drilled	789A	Water outlet pipe gasket
G632	Connecting rod ball check, assembled	854	Spray valve clamp
632	Connecting rod ball check, complete	854A	Spray valve clamp stud
634	Connecting rod foot shims (state thickness)	855	Spray valve clamp bridge
G636	Crank pin box, assembled; Part Nos. 636, 637	855A	Spray valve clamp stud nut
636	Crank pin box, 2 halves	870	Spray valve rocker
637	Crank pin box bolt	872	Spray valve rocker stand
	Crank pin box bolt nut	873	Spray valve rocker stand pin
	Crank pin box cap screw and nut	876	Spray valve rocker push rod
640	Crank shaft	1067	Lubricating oil sump
706	Valve lifter guide housing door	1067A	Lubricating oil float guide flange
710	Base	1067B	Lubricating oil float guide stud
712	Base cap, flywheel end	1068	Lubricating oil strainer cage
713	Base cap, center	1087	Pressure lubricating oil gauge—30 lbs.
717	Base cap stud	1218	Fuel oil purulator
	Base cap stud nut	1229	Purulator bracket
718	Base lubricating oil strainer	1287	Lubricating oil purulator
719A	Base cap shim, flywheel end	1306	Chain sprocket, driver
720A	Base cap shim, center	1307	Chain sprocket, driven
722A	Base cap shim, opposite flywheel end	1308	Chain shield
724	Base oil pipe flange with pipes fitted in		Chain shield cap screw
	Base oil pipe flange cap screw	1309	Chain shield cap
		1310	Ball bearing container
		1311	Chain sprocket shaft
		1312	Chain sprocket shaft ball bearing
		1313	Silent chain

Always Give Part Name, Part Number and ENGINE NUMBER



NO. "0" AUXILIARY AIR COMPRESSOR

Always Give Part Name, Part Number and ENGINE NUMBER

AUXILIARY COMPRESSOR

In ordering all repair parts for compressor BE SURE and give BOTH the part name and number, also ENGINE NUMBER of auxiliary.

20	Spark plug	220	Air pump head
32	Engine cylinder head	220A	Air pump head valve stem bushing
33	Engine and pump cylinder head stud	221	Air pump piston
33A	Engine and pump cylinder head stud, long	222	Air pump piston ring
33B	Engine and pump cylinder head stud nut	224	Air pump inlet valve
37	Rocker pin	225	Air pump outlet valve
38	Rocker pin fork	225A	Air pump outlet valve adjusting screw
38A	Rocker pin fork stud	226	Air pump piston pin
38B	Rocker pin fork stud nut	227	Air pump connecting rod
100	Cylinder and frame	228	Air pump valve nut
110	Inlet or exhaust valve	228A	Air pump outlet valve cap
110A	Valve stem cup	229	Air pump inlet valve spring
110B	Valve stem cup lock	229A	Air pump inlet valve spring guide
112	Valve stem bushing	229B	Air pump inlet valve spring guide nut
114	Inlet valve spring	230	Air pump outlet valve spring
114A	Exhaust valve spring	230A	Air pump outlet valve spring guide
124	Exhaust rocker push rod	231	Air pump relief handle
124A	Exhaust rocker push rod bushing	234	Air pump outlet valve bushing
125	Engine piston	234A	Air pump outlet valve bushing cap
126	Engine piston pin	240	Carburetor
129	Engine piston ring	260	Rotary pump
133	Exhaust rocker with adjusting screw	260A	Rotary pump cap screw
133A	Exhaust rocker ball socket	272	Water outlet flange
136	Engine connecting rod	287	Flywheel
149	Crankshaft pinion	294	Magneto bracket
150	Crank shaft	296	Magneto
151	Crankshaft bushing	446	Magneto drive shaft
156	Crankshaft bearing	447	Magneto drive shaft bushing
159	Crankshaft bearing, fly-wheel end	G2441	Lubricator assembled
160	Crankshaft bearing cap screw	2441	Lubricator bottom with air pipe
163	Frame cover door	2441A	Lubricator valve
163A	Frame cover door clamp	2441B	Lubricator spring
163B	Frame cover door clamp wing nut	2441C	Lubricator washer and nut
163C	Frame cover door clamp stud	2442	Lubricator top with stem
166	Cam lifter	2442A	Lubricator clamp stud
174	Cam gear	2442B	Lubricator clamp stud nut
176	Cam gear pin	2443	Lubricator plug with stem
176A	Cam gear pin bushing	2443A	Lubricator glass
178	Exhaust cam and gear hub		
202	Breather pipe		

Always Give Part Name, Part Number and ENGINE NUMBER

METHOD OF CLEANING PUROLATORS

Stop engine and drain purolator.

Remove case of element, this is done by taking out nut on top of purolator.

Wash element thoroughly in gasoline or kerosene.

Drain element and replace.

Place shell over element, and push down over stand pit.

Replace nut and gasket and tighten.

High Pressure Fuel Pumps

THE fuel pumps are of the plunger type with $\frac{1}{2}$ -inch diameter, hardened and ground plungers. These pumps are required to pump the fuel up to the required pressure of 3500 pounds, and for that reason are very closely fitted. It is necessary to use care in packing these plungers. The packing glands should never be screwed down so hard as to make the gland absolutely tight. It is essential that a small amount of fuel oil be allowed to work up through the packing, and thereby lubricate the plunger.

A quantity of packing is furnished with each engine. If the packing gland is screwed down too tight the packing will become dry and hard, and thereby cause the plunger to wear. The lower ends of the suction valves extend sufficiently below the valve bodies so that they can be reached by hand, turned around and moved with the fingers, if they stick. If a valve should be too tight at the stem it can be polished off with fine emery cloth, care being observed not to take off too much. In most cases it can be loosened by moving it up and down and twisting it around with the fingers.

Radiator

USE only clean water in radiator. If necessary haul the water. Avoid water which when boiled will leave a hard deposit or scale as it will clog up and decrease the efficiency of the radiator and cooling jackets. Do not use fuel oil barrels or oily or greasy tanks to haul water in. Grease or oil, even in a very small quantity in the radiator water, decreases the efficiency and results in trouble.

For full efficiency of radiator it is also essential that the outside should be kept clean and free from oil and dirt as any foreign matter on the outside surfaces of the radiator seriously effects its efficiency. Keep the front of the radiator clean at all times so as to have no obstruction to hinder or block the fan. It is a good practice to clean the outside of the radiator at times by using a hose with compressed air.

Pure water should be used in the radiator in the summer time and in countries where the temperature does not drop below freezing.

In cold weather where the system is apt to freeze up a quantity of denatured alcohol should be added to the water to prevent freezing. The percentage of alcohol should be increased in accordance with the degree of temperature below freezing as indicated in table below.

DENATURED ALCOHOL	WATER	BEGINS TO FREEZE AT DEGREES FAHRNHEIT
10%	90%	7 above zero
20%	80%	19 above zero
30%	70%	10 above zero
40%	60%	-2 below zero
50%	50%	-18 below zero

TAKE SPECIAL NOTICE

1. A SMOKY ENGINE OR LOSS OF POWER IS DUE TO:

Fuel Valve: Leaks, stem is clogged, nozzle is worn out, tension on spring too close, or not timed properly, or all of the cylinders are not firing properly.

Exhaust Valves: Leaks, stem stuck in guide or not timed properly.

Intake Valve: Leaks, stem stuck in guide or not timed properly.

Loss of Compression: Leaky cylinder relief valve, cylinder head gasket leaking, too low a piston (extra clearance due to wear and adjustment of connecting rod brasses and main bearings, change to a higher altitude or piston rings stuck in their grooves.

Too low fuel oil pressure. Engine running at too slow a speed.

Too much lost motion in governor parts. Wrong kind of fuel oil.

2. BE SURE TO:

Oil all moving parts with regularity. Watch lubricating oil pressure.

Squirt a little coal oil (kerosene) on each exhaust and intake valve stem previous to each time engine is started. This is not necessary if the engine has just been stopped and is started soon again.

Always slow engine down while you are idling.

Keep correct amount of lubricating oil in sump or supply tank.

Change lubricating oil when necessary (usually from 250 to 300 hours engine running time). Clean oil strainer every two weeks—oftener if required.

Draw water off bottom fuel oil tank and strainers as often as required to keep water out of engine. Always keep the engine clean.

Be sure to examine various parts of the engine while it is running to make sure that none of the parts have become overheated. This is also a good test to see if the circulating water is circulating properly and the lubricating oil is o. k.

Stationary Plant Installation

INSTALLING of Diesel engines must be carefully done in order to obtain the best results; and our suggestion is, to begin with, that

AIR TANKS:

Should be made very strong, and should be tested at least 100 per cent above the ordinary working pressure. Tanks should be as near the engine as possible. Tanks should be so placed that the pipes leading in and out be connected above the center of the tank, so that the tank itself will form a settling chamber in which water and oil carried in the air will be deposited in the bottom of the tank. A reasonable size, say one inch (1"), clean out plug should be placed in the bottom of the tank at the lowest point and a drain valve of about 1/2-inch size screwed into the plug. This valve should be opened to allow water and oil to be drained from the tank at frequent intervals of at least twice a week when engine is running steadily.

AIR PIPING:

All air piping should be good grade iron pipe and should never be of smaller diameter than the opening in the air tanks, use heavy malleable fittings (no cast iron fittings). The piping should be done so that there is no trap or depression to the pipe which can fill up with oil or water.

The pipe should have a slight pitch either towards the tank or towards the compressor, preferably towards the tank. If pipe has a pitch toward compressor put in a drain at lowest point. After the pipes are cut to lengths, they should be thoroughly cleaned from cuttings, and ends of pipes reamed so as to remove all sharp edges and chips from ends of pipe. Pipes should be screwed together with shellac (use no white lead or red lead in air connections).

The air tank must be securely fastened so that it cannot move and thereby break the pipe connection. The pipes should be so connected as to allow a reasonable amount of spring without the possibility of pipes breaking. It must be remembered that the weakest part of the pipe is always where the threads are cut. All pipes should be securely fastened with pipe straps to prevent excessive vibration. The interior of air tanks should also be coated with shellac before installing; which is done in the following manner: Plug all holes except one. Pour a quantity of shellac into the tank and plug the last hole. Roll the tank around and stand the tank on one end, then on the other, until the shellac has thoroughly covered all interior surfaces of the tank. Then open one plug and allow the surplus shellac to be drained out thoroughly before tank is placed. A substantial heavy duty valve should be placed in the pipe line close to the tank. When the engine is shut down for the night this valve should be shut tight so as to hold air pressure for the next time the engine is to be started. This will eliminate using the auxiliary engine every day when starting.

TESTING AIR PIPING AND AIR TANKS:

After the tank and piping are in place, pump up air pressure with the auxiliary compressor; and see that all joints are positively tight. On stationary installations a good grade globe valve should also be placed on the air line between the hand air starting valve on the engine and the tank, so that when the engine is started no air can pass by the hand air starting valve, which being of the quick opening gate valve type is never to be relied upon as being exactly tight. It is impossible to maintain quick opening gate valves in absolute tight conditions.

INSTALLING OF FUEL TANK AND FUEL PIPING:

It is a well known fact that grit, scale and dirt in the fuel piping is one of the most annoying things that can happen to the Diesel engine; hence, the fuel tank and fuel piping should be made with as much care as we have recommended with the air piping. The fuel tank must be thoroughly cleaned, after which it must be shellaced on the inside in the same manner as the air tank. It must be remembered that the fuel carries a great deal of sulphur and for that reason it will attack the walls of the tank and cause scale to get into the piping.

The fuel tank must have a liberal size drain opening at the bottom for cleaning out, with valve or stop-cock. The feed pipe leading from tank to fuel pump on engine should be connected an inch or so above the bottom of the tank to prevent sediment from entering the feed pipe. A good globe valve should be placed right close to the tank so that the pipe may be disconnected for cleaning out without having to drain the tank. Ends of all pipes should be carefully reamed and all piping shellaced inside. All joints should be made with shellac (no white lead or red lead will do); and pipes should be carefully cleaned out before final connection.

On larger installations it is advantageous to install a trap at the extreme lower end of the fuel piping so that any sediment reaching there can be cleaned out. This can be made with a tee, and short drop pipe with plug in the bottom of the drop pipe.

LUBRICATING OIL TANKS AND PIPES:

Where a lubricating oil tank is being installed, same must also be clean and free from dirt, scale, etc. Piping for lubricating oil should be made preferably of brass or copper to prevent scale from peeling off the pipe and getting into the bearings. Connect up all lubricating oil piping with shellac.

CIRCULATING WATER PIPES:

Circulating water pipes should be carefully made to see that there are no leaks. Make pipe of ample size to avoid friction, and make provisions at the lowest point of pipes for drainage of the entire circulating system, both for the auxiliary engine, and for the main engine. This prevents freezing in cold weather and makes it possible to wash out any mud or sediment that may enter the circulating system.

ALIGNING ENGINE AND FLYWHEEL MAINTENANCE:

It is of vital importance to have the engine carefully lined up to its work, in order to have it run smoothly. When the engine is properly fastened to its foundations and lined up to its work and all pipe connections made and tested to see that they are tight, then see to it that the flywheel is tight on the shaft. It is very important that the flywheel be securely tightened to shaft. In order to accomplish this, the hub is split on one side, and massive bolts used to clamp the hub together with. These bolts must be tightened up as tight as it is possible to make them without stripping the threads.

It is a good practice to try the nuts on these bolts at regular intervals, say once a month, to make sure that they have not slackened in any way. If a flywheel should be slightly loose on the shaft it may sound as if every connecting rod is loose or the sound may be transferred to the gearing or other machinery attached to the engine. If a flywheel is allowed to be loose serious trouble may be encountered as it will soon become sufficiently loose to do great damage to the crankshaft, flywheel, and other parts of the engine.

STARTING LEVER:

The starting lever is located on the end of the centerframe on the flywheel end on the operating side. When the lever is leaning toward the exhaust side it is in running position. When the lever is leaning toward the operating side it is in starting position. The starting valve should be used only long enough to give engine a good start, that is just enough to turn engine over a few revolutions, and then released from action.

Preparing For Starting New Engine First Time After Installing

WHEN the engine has been installed and all pipe connections made and tested to see that they are tight and in order, the next thing is to pump up air pressure in the air starting tanks. To do this, start the little auxiliary engine and pump up the air pressure to approximately 200 pounds. Test the safety valve on the auxiliary engine to see that the safety valve on the main engine compressor is in order and will blow off at about the same pressure. (The time required to charge these air tanks depends on the size of the tanks but will average about 15 minutes to each tank.) See that the inside of the engine base is clean and free from foreign substances.

Fill lubricating oil sump with good Diesel engine cylinder oil up to its normal oil level.

Put fuel oil in fuel tank. Care should be taken that no grit or dirt enters the tank, and the fuel should be strained through a very fine gauze strainer, preferably using a large funnel with a fine gauze strainer in it. After enough fuel oil has been put in the tank drain small quantity off and fill small gravity tank with fuel oil. Open valve leading to fuel strainer on engine and see that the fuel oil flows freely to the strainer and to the high pressure fuel pumps.

See that there is sufficient oil in the cylinder force feed lubricator.

Oil all rockers and pins and see that everything is well oiled and free from dirt or grit. See that all oil holes are clean and free from dirt. Move governor speed control handle to half speed position. Bar flywheel over until pointer on engine corresponds to about 45 degrees past top center of any cylinder. (Flywheel is marked to indicate top center on any cylinder as well as marked for valve settings.)

It may be necessary to disconnect blind union on top of the fuel pump in order to eject all the air in the lines, then pump up the fuel pressure with hand pump until fuel gauge registers about 2000 pounds. See that all isolating valves on fuel manifold are open. See that everything is clear and free from obstruction.

See that the air starting lever is in running position. Open the globe valve in the air line near the tank. Then open the air globe valve on air starting manifold on engine and when ready to start the engine, merely pull the starting lever over from running position to air starting position. The engine will then start to run. As soon as the engine has made a couple of revolutions and has picked up speed enough, place the starting lever back into running position. It is important to do this as quickly as possible in order to save air. The globe valve on the air manifold should then be shut off tight and the small drain cock in air manifold should be opened to drain off any residue that might be in the pipe between the globe valve and air starting valves. It is important that this globe valve be shut off, as it will relieve any undue pressure on the air starting valves and also in case the air starting valve should leak slightly it would blow into the cylinders and cause loss of power.

When first starting a new engine there are many little things that may hinder the machine from starting readily, such as dirt from the pipes getting into the valves, etc.

Regulate the governor to the proper speed by speed control handle, No. 1117. Next adjust the fuel relief valve to the proper pressure which for normal load should be 3500 pounds, for light load a lesser pressure can be used, and for idling 1000 pounds pressure is quite sufficient.

On a cold morning when the lubricating oil is stiff and for that reason engine hard to turn over, it may be advisable to prime engine before starting. To do this, proceed as follows:

Pump up fuel pressure to about 1000 pounds pressure, then lift spray valve rocker by hand until oil pressure is relieved, thus allowing a small amount of fuel oil to enter the cylinder. Pump up fuel pressure again and lift the next spray rocker in the same manner and repeat until all cylinders are primed.

See that the engine is working on all cylinders. If one is not firing open up the small snifter valves (1198) one at a time and close them again to ascertain which cylinder is not firing. In order to start the missing cylinders to fire it may be necessary to raise the spray valve rockers slightly and quickly by means of a small pry, thus allowing an additional amount of fuel to the point of that particular nozzle. This gives it a chance to get rid of any air that may be lodged in the spray nozzle. As soon as engine is started see that the circulating water is running freely through the engine and that all cylinders and cylinder heads are maintained at a uniform temperature. In making this first start it is necessary to investigate and see that every part is functioning properly and that the fuel positively reaches each spray nozzle, that all valves are seating properly and do not allow any pipe connections to be leaky. It is advisable to run the engine at first idle for a short time until everything gets in good running order before applying the load.

When the main engine is running the main air compressor should be started so as to pump up pressure in the air tanks for the next time the engine is to be started. When the engine is cold it will require approximately 150 to 200 pounds pressure on the air in order to give the engine sufficient speed to start properly. If the engine has been shut down only for a short period and is still warm it will start on considerably less air. It is possible to start it on air as low as 30 pounds per square inch. If the operator is careful with his air and uses it economically in starting there should be no occasion to ever use the auxiliary engine again unless after piping had been taken apart for some reason or other or the air lost by valves being left open, as the air tanks are tight and when the engine is shut down the valves properly closed off, air pressure should remain in the tanks from one day to another sufficient to start the engine again without having to use the auxiliary engine. In many instances the auxiliary engine is not used oftener than once a month unless it is used for other purposes than compressing air for starting.


All engines are properly tested at the factory before shipping and all valves adjusted to the proper setting; this may become altered, however, in installing and if the engine does not run correctly when first started it may be that the valve setting should be gone over especially the opening and closing time of the spray valves which is very important. When the engine is running at normal load and all valves timed properly the exhaust should be almost clear. Black smoke indicates that either too much fuel is admitted into the cylinders or that the spray nozzle is not functioning properly. When starting a new engine it is possible that the holes in the

spray nozzles become clogged or partly clogged by particles of metal from the piping. When this happens the fuel oil is unequally distributed in the cylinder which causes smoky exhaust and vibration.

When starting a new engine use every precaution to see that the lubricating oil is flowing freely through the pumps and that the lubricating pump is maintaining at least 5 pounds pressure on the lubricating oil gauge.

After all adjustments are made and the engine runs smoothly and all parts functioning properly then it is a simple matter after that to operate the engine, start, stop, etc. When stopping the engine, first release the governor control handle to slow speed. Then pull fuel wedge lever which is located on the end of the fuel lifter housing on the flywheel end toward the operating side which cuts off the fuel to the engine, be sure to hold lever out till engine comes to dead stop. Quick stopping of the engine will come about due to the compression in the cylinders without fuel. Then shut off the fuel oil valve between the gravity (day) tank and the high pressure fuel pumps and close the valves on the air tanks tight to prevent loss of air pressure.

When starting the engine after they have been fully adjusted open the air valves on the tanks, turn on fuel from gravity tank and also from main tank to supply tank. Pump up about 200 pounds pressure with the small priming hand pump. Oil all rockers, etc., see that the flywheel is in proper position for starting, open gate valve on the air line, pull the starting lever over from running to starting position and as soon as the engine starts to turn over throw the starting lever back into running position. See that all cylinders start properly, shut gate valve off again, let air compressor on main engine pump up air pressure again so as to be prepared for the next start, see that circulating water is running properly and that lubricating oil pressure shows the proper amount on gauge. When the engine is first started it is possible that the exhaust will show smoky for a short time but after the engine has run from 10 to 15 minutes the exhaust should be nearly clear.



DIESEL GENERATOR SETS ARE MADE IN THREE, FOUR, AND SIX CYLINDER TYPE, EITHER DIRECT CONNECTED AS SHOWN ABOVE OR BELTED. IN HORSE POWERS RANGING FROM 30 H. P. TO 750 H. P.

PARTS LIST

Atlas Imperial Diesel Engine—Dust Proof Type.

INSTRUCTIONS

In ordering parts **BE SURE** to give the following information:

First—Name of Part Wanted.

Second—Number of Part Wanted.

Third—Engine Number (found on name plate on centerframe).

Fourth—Shop Number of machine on which Engine is mounted.

Fifth—Give Bore and Stroke of Engine.

IMPORTANT—RECHECK ALL NAMES AND NUMBERS TO BE SURE THAT THE CORRECT INFORMATION IS GIVEN.

The letter "G" in front of any number in the list indicates that that certain part comes in group or assembled form and contains **ONLY** those parts which are given.

Part No.	Part Name	Part No.	Part Name
G370	Centrifugal pump, complete; Part Nos. 370, 370B, 371, 371A, 371B, 372, 373, 373A, 373B, 374, 374A, 379, 381, 381A, 383, 386, 386A	374A	Centrifugal pump shaft flax packing
370	Centrifugal pump body	379	Centrifugal pump runner shaft
370F	Centrifugal pump body drain plug	381	Centrifugal pump steady bearing
370E	Centrifugal pump body drain cock nipple	381A	Centrifugal pump steady bearing cap screw
370A	Centrifugal pump inlet or outlet flange	381C	Centrifugal pump steady bearing clamp screw
370C	Centrifugal pump inlet or outlet flange gasket	383	Centrifugal pump radial thrust ball bearing
370B	Centrifugal pump grease cup	384	Centrifugal pump shaft coupling
370C	Centrifugal pump flange cap screw	386	Centrifugal pump ball bearing housing
370D	Centrifugal pump holding down cap screw		Centrifugal pump ball bearing housing clamp screw
371	Centrifugal pump cover	386A	Centrifugal pump ball bearing retainer
371A	Centrifugal pump cover screw		Centrifugal pump ball bearing retainer lock set screw
371B	Centrifugal pump inlet flange		Centrifugal pump shaft guard bracket
371C	Centrifugal pump cover gasket		Centrifugal pump shaft guard racket screw
	Centrifugal pump flange cap screw		Centrifugal pump shaft guard bracket cap screw
372	Centrifugal pump runner with shaft No. 379	G500	Cylinder head, complete; except spray valve
373	Centrifugal pump shaft gland	GA500	Cylinder head, with valves and springs only (no spray valve)
373A	Centrifugal pump shaft gland stud	500	Cylinder head
373B	Centrifugal pump shaft gland stud nut	501	Cylinder head stud
374	Centrifugal pump shaft bushing	501A	Cylinder head stud, special for lifting head
		501B	Cylinder head stud nut

See Instructions for Ordering on Page 56

Part No.	Part Name	Part No.	Part Name
502	Cylinder head gasket	586	Air starting valve balance bushing ring
505	Cylinder head dust proof cover	588	Air starting valve spring washer, bottom
505A	Cylinder head dust proof cover stud and handle	590	Air starting valve rocker, with roller, pins and bushings
509	Air suction pipe	590A	Air starting valve rocker bushings (set of 2)
510	Valve and stem, inlet or exhaust	590B	Air starting valve rocker button
512	Valve stem bushing	593	Air starting valve rocker push rod
513	Valve spring, inlet or exhaust	594	Air starting valve lifter with roller and pin
514	Valve spring bushing, inlet or exhaust; top	594A	Air starter valve lifter spring collar
514A	Valve spring bushing, inlet or exhaust; bottom	594B	Air starter valve lifter spring
514B	Valve stem nut	594C	Air starter valve lifter rod socket
520	Inlet rocker with bushing	594D	Air starter valve lifter wedge
520A	Inlet rocker bushings (set of 2)	594E	Air starter valve wedge fork and pin
525	Push rod, inlet or exhaust	594F	Air starter valve wedge fork bearing
526	Pushrod socket	594G	Air starter valve wedge fork shaft
526A	Pushrod socket nut	594H	Air starter wedge fork pin
527	Push rod button—Inlet, exhaust, air and fuel	595	Air starting valve lifter roller
528	Valve lifter, with roller and pin; inlet or exhaust	596	Air starting valve lifter roller pin
529	Valve lifter guide, inlet or exhaust	597	Air starting cam (see part No. 532)
530	Valve lifter roller, inlet or exhaust	599	Air starting valve lifter guide
531	Valve lifter roller pin, inlet or exhaust	600	Cylinder with studs
532	Inlet and air starting cam	605	Cylinder cleanout cover
550	Exhaust rocker with roller, pins and bushings	605A	Cylinder cleanout cover gasket
550A	Exhaust rocker bushings (set of 2)	605B	Cylinder cleanout cover cap-screw
560	Exhaust cam	610	Cylinder water passover pipe to head
565	Rocker shaft	610A	Cylinder water passover pipe rubber grammet
565A	Rocker shaft oil cup	611	Cylinder lubricating pipe through jacket
566	Rocker shaft bearing	612	Cylinder lubricating pipe gland
567	Rocker shaft bearing stud	613	Cylinder lubricating pipe packing
567A	Rocker shaft bearing stud nut, top	614	Cylinder lubricating pipe elbow
567B	Rocker shaft bearing stud lock nut	G620	Piston, complete; with rings and pin
567C	Rocker shaft bearing stud, long	620	Piston
577	Air starting elbow	621	Piston pin
577A	Air starting elbow gasket	622	Piston ring, 1/2" double seal
577B	Air starting manifold	622A	Piston ring, 1/4" double seal
578	Air starting globe valve	622B	Piston ring, 1/4" step cut
579	Air starting valve spring bushing	628	Piston pin bushing
G580	Air starting valve, complete: Part Nos. 579, 580, 582, 583, 584, 585, 586, 588	G630	Connecting rod, complete, with bushing and ball check
580	Air starting valve		
582	Air starting valve spring		
583	Air starting valve spring washer, top		
584	Air starting valve nut		
585	Air starting valve balance bushing		

See Instructions for Ordering on Page 56

Part No.	Part Name	Part No.	Part Name
630	Connecting rod, drilled	718	Base lubricating oil strainer
632	Connecting rod ball check	719A	Base cap shims, flywheel end
634	Connecting rod shims	720A	Base cap shims, center
G636	Crank pin box, two halves; complete with bolts	722A	Base cap shims, opposite end to flywheel
636	Crank pin box, two halves	724	Base oil pipe flange with pipe assembly
636A	Crank pin box shims	727	Base—frame—cylinder studs
637	Crank pin box bolts	727A	Base centerframe cylinder stud washer
640	Crank shaft and pinion	727B	Base centerframe cylinder stud nut
644	Crank shaft bushing, flywheel end	729	Base frame stud
646	Crank shaft bushing, center	730	Base frame stud
655	Crank shaft throw off oil ring	750	Flywheel
660	Crank shaft pinion	751	Flywheel coupling
664	Intermediate gear	752	Flywheel friction bolt
665	Intermediate gear pin	753	Flywheel hub clamp bolt
665A	Intermediate gear pin bolt	753A	Flywheel coupling bolt washer
666	Intermediate gear bearing	753B	Flywheel coupling bolt nut
666A	Intermediate gear bearing cap screw	754	Flywheel 1 3/4" wrench
666B	Intermediate gear bearing lock set screw	756	Flywheel pointer
670	Cam gear	760	Exhaust elbow
672	Cam shaft	760A	Exhaust elbow gasket
680	Cam shaft bearing, center	761	Exhaust pipe
683	Cam shaft bearing, fan spindle end	764	Exhaust elbow stud
685	Cam bushing	764A	Exhaust elbow stud nut
688	Cam shaft bushing, fan spindle end	780	Water inlet pipe on cylinder
690	Centerframe	789	Water outlet connecting pipe
691	Centerframe cover and governor shield	789A	Water outlet pipe gasket
691A	Governor door top cover	796	High pressure fuel pump discharge fitting
691B	Governor door front cover	796A	High pressure fuel pump discharge fitting
692	Centerframe door	797	High pressure fuel pump discharge fitting nut
692A	Centerframe door gasket	800	High pressure fuel pump body
692D	Centerframe door cap screw	800A	Fuel pump body nut
693	Centerframe and rotary pump cover	801	High pressure fuel pump suction valve
693A	Centerframe rotary pump door cap	802	High pressure fuel pump suction valve cage
693B	Rotary pump door ball retainer	802A	Fuel pump suction union nut
693C	Rotary pump clamp cap	802B	Fuel pump suction union sleeve
693D	Rotary pump cap stud	808	Jewett packing ring
693E	Rotary pump clamp cap stud	809	High pressure fuel pump gland
695	Centerframe cover, end of frame; top	809A	High pressure fuel pump gland nut
695A	Centerframe cover, end of frame; bottom	810	Fuel pump gland lock nut
696	Centerframe cover	810B	Fuel pump plunger head
705	Valve lifter housing	811	Fuel pump plunger nut
705A	Valve lifter housing steel plate cover	817	Fuel pump discharge valve
705B	Valve lifter housing end plate	817	Fuel pump plate
706	Valve lifter housing cover		Fuel pump plate steel cover (front)
707	Valve lifter guide push rod tube and nut		Fuel pump plate steel cover (top)
710	Base with caps and studs		Fuel pump plate steel cover screw (large or small)
712	Base cap, flywheel		
713	Base cap, center		
717	Base cap stud		

See Instructions for Ordering on Page 56

Part No.	Part Name	Part No.	Part Name
	Fuel pump plate and housing	867	Spray valve packing
	slotted cap screw	870	Spray valve rocker with pins
822	High pressure fuel pump	872	Spray valve rocker fulcrum
	crank shaft	873	Spray valve rocker fulcrum
822A	High pressure fuel pump		pin
	coupling	876	Spray valve rocker push rod
822B	High pressure fuel pump	877	Spray valve rocker horse shoe
	coupling bolts		collar
823	High pressure fuel pump	878	Spray valve rocker stem nut
	crank shaft connecting rod,	878A	Spray valve lock nut
	complete; Part Nos. 823,	880	Spray valve rocker cam toe
	824, 824A	881	Spray valve cam disc
824	High pressure fuel pump	881A	Spray valve disc toe washer
	crank shaft connecting rod	883	Spray valve lifter, with roller
	cap		and pins
824A	High pressure fuel pump	884	Spray valve lifter roller
	crank shaft connecting rod	885	Spray valve lifter roller pin
	bolts	887	Spray valve lifter guide
G828	High pressure fuel pump	888	Spray valve lifter guide
	connecting link and cross-		spring
	head, assembled; Part Nos.	889	Spray valve push rod socket
	828, 828A, 831	895	Spray valve testing outfit
828	High pressure fuel pump	896	Spray valve cleaning needles
	connecting link	897	Spray valve tip remover
828C	High pressure fuel pump	898	Spray valve tip cleaner
	connecting link pin	900	Air compressor cylinder
829	High pressure fuel pump	900A	Air compressor cylinder head
	crosshead guide		stud
831	High pressure fuel pump	900B	Air compressor oil splash
	crosshead		plates
831A	High pressure fuel pump	G901	Air compressor head, com-
	crosshead nut		plete; Part Nos. 901, 905,
831B	High pressure fuel pump		907, 908, 908A, 915, 915A,
	crosshead button		918, 918A, 919, 920, 922 922A,
831C	Fuel pump crosshead bushing		923, 924
831D	Fuel pump crosshead oil	901	Air compressor head
	guard	902	Air compressor stud
846	Fuel pump housing	905	Air compressor inlet valve
	Fuel pump housing stud	906	Air compressor grid
	Fuel pump housing stud nut	907	Air compressor inlet valve
847	Fuel pump housing cover		bushing
	Fuel pump housing cover	908	Air compressor inlet valve
	hinge		spring
	Fuel pump housing cover	908A	Air compressor inlet valve nut
	hinge screw	908B	Air compressor inlet valve
G849	Spray valve, complete; see		washer
	page 16 (?)	915	Air compressor discharge
850	Spray valve stem		valve
851	Spray valve body	915A	Air compressor discharge
853	Spray valve spring casing		valve adjusting screw
854	Spray valve clamp	918	Air compressor discharge
854A	Spray valve clamp stud		valve flange
855	Spray valve clamp bridge	918A	Air compressor discharge
855A	Spray valve clamp bridge nut		valve relief handle nut
856	Spray valve seat nut	918C	Air compressor discharge
857	Spray valve spring plug		valve flange stud
858	Spray valve spring	919	Air compressor discharge
859	Spray valve spring ball bear-		valve spring
	ing	920	Air compressor discharge
860	Spray valve gasket		valve guide
864	Spray valve nozzle	922	Air compressor discharge
865	Spray valve gland nut		valve cap nut
866	Spray valve gland		

See Instructions for Ordering on Page 56

922A	Air compressor discharge valve relief handle	1100	Governor body (always supplied with No. 1111 fitted on)
923	Air compressor discharge valve guide cap	1101	Governor weight
924	Air compressor discharge valve spring bushing	1102	Governor weight pin
925	Air compressor piston	1103	Governor weight roller
926	Air compressor piston ring	1104	Governor weight roller pin
927	Air compressor piston pin	1105	Governor weight roller plate
928	Air compressor connecting rod bushing	1106	Governor thrust quill
929	Air compressor connecting rod	1107	Governor thrust quill ball bearing, small
930	Air compressor eccentric strap	1108	Governor body ball bearing, large
932	Air compressor eccentric strap bolt and nut	1109	Governor shaft
933	Air compressor eccentric	1110	Governor body collar
936	Air compressor pass over pipe	1111	Governor pinion
936A	Air compressor pass over pipe gasket	1112	Governor bearing
937	Air compressor gauge 300 lbs.	1112A	Governor bearing cap
1060	Force feed lubricator	1113	Governor thrust quill bushing
1060A	Force feed lubricator drive arm	1114	Governor compression spring
1060B	Force feed lubricator connecting rod eye	1114A	Governor compression spring collar
1061	Force feed lubricator bracket	1114B	Governor compression spring quill
1063	Force feed lubricator oiler disc and cam shaft collar	1115	Governor compression spring block
1065	Force feed lubricator connecting rod	G1117	Control handle, complete; Part Nos. 1117, 1118, 1119, 1124, 1125, 1249
1065A	Force feed lubricator connecting rod pin	1117	Governor control handle
1067	Lubricating oil sump	1118	Governor control handle pawl
1067A	Lubricating oil float guide flange	1119	Governor control handle sector
1067B	Lubricating oil float guide stud	1120	Governor rack for compression spring
1068	Lubricating oil strainer cage	1121	Governor rack adjusting screw
1069B	Lubricating oil gauge float	1121A	Rack adjusting screw nut
1087	Pressure lubricating oil pump pressure gauge; 30 lbs.	1122	Governor speed control socket with sector
G1090	Pressure lubricating oil relief valve, complete; Part Nos. 1090, 1091, 1092, 1093, 1095.	1122A	Governor control socket
1090	Pressure lubricating oil relief valve body	1122B	Governor control socket screw
1091	Pressure lubricating oil relief valve plunger	1123	Governor control socket bearing
1092	Pressure lubricating oil relief valve adjusting screw	1124	Governor control handle pawl spring
1093	Pressure lubricating oil relief valve spring	1125	Governor control handle pawl spring screw
1095	Pressure lubricating oil relief valve adjusting screw nut	1127	Governor connecting rod between forks
1096	Pressure lubricating oil relief valve check valve	1128	Governor fork
G1100	Governor, complete; Part Nos. 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1113	1128A	Governor fork shaft
		1129	Governor lever on vertical shaft
		1129A	Governor lever pin
		1130	Governor fork on wedge shaft
		1131	Governor wedge fork
		1132	Governor fuel control wedge
		1132A	Governor fuel control wedge pin
		1133	Governor fuel control shaft

See Instructions for Ordering on Page 56

Part No.	Part Name	Part No.	Part Name
1134	Governor fuel control shaft bearing	1202	High pressure fuel strainer stem
1134A	Governor fuel control shaft bearing nut	1203	High pressure fuel rail clamp
1135	Governor fuel shaft end tension spring	1204	High pressure fuel strainer gasket
1136	Governor fuel shaft end tension spring clamp	1205	High pressure fuel isolating valve body
1138	Fuel control wedge shaft handle	1206	High pressure fuel isolating valve stem
1170	High pressure fuel union nipple	1207	High pressure fuel isolating valve gland
1171	High pressure fuel pipe connection through head	1208	High pressure fuel isolating valve gland nut
1173	Fuel pump bleeder connection	1214	Fuel oil receiver, end of line
1174	Fuel oil receiver drain connection	G1215	Fuel oil receiver valve, complete; Part Nos. 1206, 1208, 1215
1176	High pressure fuel union nut	1215	Fuel oil receiver valve body
1177	High pressure fuel union sleeve	1216	High pressure fuel oil gauge bracket, 10,000 lbs.
1178	High pressure fuel union sleeve, blind end	1217	Fuel oil pressure gauge, 10,000 lbs.
1183	Testing pipe-fuel rail to spray valve test clamp	1218	Fuel oil purolator.
1184	High pressure fuel pipe from fuel relief valve to pump suction	1229	Fuel oil purolator bracket
1185	High pressure fuel pipe from pump discharge to relief valve	G1230	Valve, complete; Part Nos. 1117, 1118, 1124, 1125, 1230, 1231, 1232, 1233, 1234, 1236, 1237, 1238, 1238A, 1239, 1240, 1242, 1243, 1244, 1245, 1249
1186	High pressure fuel pipe between pumps	1230	Body
1187	Fuel pump to fuel rail	1231	Gland
1188	High pressure fuel pipe from union in head to spray valve	1231A	Gland packing ring
1188A	High pressure fuel pipe from rail to union in head	1232	Stud
1189	Fuel pipe from fuel rail to fuel oil receiver	1233	Stem collar
1189A	High pressure fuel pipe from fuel receiver to gauge	1234	Seat
G1190	Safety valve, complete; Part Nos. 1190, 1191, 1192, 1193, 1195	1235	Stud collar
1190	Safety valve body	1236	Spring
1191	Safety valve stem	1237	Spring cage
1192	Safety valve seat	1238	Handle bearing
1193	Safety valve spring		Handle bearing lock screw
1194	Safety valve spring collar	1238A	Handle bearing pin
1195	Safety valve lock screw	1239	Handle adjusting screw
1196	Safety valve cylinder plug	1240	Handle plug, lower
G1197	Snifter valve, complete; Part Nos. 1197, 1198	1241	Stud cap nut
1197	Snifter valve body	1242	Fuel fitting
1198	Snifter valve stem	G1243	Handle, complete; Part Nos. 1117, 1118, 1124, 1125, 1243, 1249
1199	Safety valve adjusting screw	1243	Handle
G1200	High pressure fuel rail, complete	1244	Handle sector
1201	High pressure fuel strainer body.		Handle sector cap screw
		1245	Spring plug, top
		1247	Stud collar gasket
		1248	Stud gasket
		1249	Handle screw
		G1274	Packing ring
			Priming pump only; Part Nos. 1275, 1276, 1278
		1275	Priming pump cylinder
		1276	Priming pump plunger
		1276A	Priming pump plunger nut
		1278	Priming pump cap
		1279	Priming pump plunger eye

See Instructions for Ordering on Page 56

Part No.	Part Name	Part No.	Part Name
1279A	Priming pump connecting rod link	G1316	Fan spindle gearing, complete; Part Nos. 1314, 1315, 1315A, 1315C, 1316, 1317, 1318, 1319, 1319A, 1321, 1322, 1323, 1323A
1279B	Priming pump link eye	1316	Fan spindle bearing
1280	Priming pump link eye nut	1317	Fan spindle chain sprocket
1280	Priming pump connecting rod	1318	Fan spindle roller bearing and cup
1280A	Priming pump connecting rod pin	1319	Fan spindle steel cover
1281	Priming pump handle	1319A	Fan spindle steel cover screw
1284	Priming pump handle push rod	1321	Fan spindle spacer
1284A	Priming pump handle push rod fulcrum	1322	Fan spindle spacer washer
1287	Lubricating oil purolator	1323	Fan spindle felt washer
G1295	Day tank, complete; Part Nos. 1295, 1296, 1297, 1297A, 1297B, 1298, 1299	1323A	Fan spindle felt washer retainer ring
1295	Day tank casing		Fan spindle bearing stud
1296	Day tank cover		Fan spindle bearing stud nut
	Day tank cover pipe plug		Fan spindle bearing stud washer
	Day tank cover holding down cap screw		Fan spindle sprocket key
1297	Day tank casing collar		Fan spindle nut lock washer screw
1297A	Day tank casing collar eye bolt	1338	Rotary pump, complete, 1/4" outlet
1297B	Day tank casing collar wing nut	1341	Rotary pump gear and shaft driver for 1/4" outlet pump
	Day tank casing collar eye bolt pin	1342	Rotary pump gear and shaft driven for 1/4" outlet pump
1298	Day tank casing collar bottom clamp cap screw	1351	Rotary pump felt washer
1299	Day tank strainer	1352	Rotary pump gear, driven
1306	Chain sprocket, driver	1353	Rotary pump gear driver on cam shaft coupling
1307	Chain sprocket, driven	1354	Rotary pump ball bearing
1308	Chain shield	1355	Rotary pump drive shaft
	Chain shield cap screw	1356	Rotary pump ball bearing quill
1309	Chain shield cap	1371	Rotary pump gear and shaft for 1/2" outlet pump
1310	Ball bearing container	1372	Rotary pump gear and shaft driven for 1/2" outlet pump
1310A	Ball bearing container, shaft end	1378	Rotary pump, complete; 1/2" outlet
1311	Pinion shaft		Rotary pump holding down cap screw
1312	Ball bearing, with adapter	1533	Oil cup on air pump connecting rod
1313	Silent chain		
1314	Fan spindle silent chain adjusting screw		
1315	Fan spindle		
1315A	Fan spindle nut		
1315C	Fan spindle nut lock washer		

Liner Type

Part No.	Part Name	Part No.	Part Name
508	Air suction pipe	727	Base centerframe cylinder stud
577	Air starting pipe elbow	727A	Base centerframe cylinder stud washer
577A	Air starting pipe elbow gasket	727B	Base center frame cylinder stud nut
577B	Air starting pipe, including pipes, elbows, tee, flanged union, petcock, gaskets	729	Base frame stud
600	Cylinder	730	Frame cylinder stud
601	Cylinder liner	731	Base frame, stud, air compressor end
604	Cylinder liner rubber packing ring	760	Exhaust elbow
605	Cylinder clean out cover	761	Exhaust pipe
605A	Cylinder clean out cover gasket	764	Exhaust elbow stud
	Cylinder clean out cover cap screw	764A	Exhaust elbow stud nut
610	Cylinder water by pass pipe	780	Water inlet pipe
610A	Cylinder water by pass pipe gasket	780A	Water inlet pipe gasket
G620	Piston with rings and pin		Water inlet pipe flange to compressor
620	Piston		Water inlet drain cock
621	Piston pin		Water inlet drain cock nipple
622	Piston rings (double ring)		Water inlet pipe cap screw
622A	Piston ring, 1/4" double seal	789	Water outlet pipe
622B	Piston ring, 1/4" step cut		Water outlet pipe cap screw
628	Piston pin bushing	789A	Water outlet pipe gasket
G630	Connecting rod with ball check and bushing	854	Spray valve clamp
630	Connecting rod, drilled	854A	Spray valve clamp stud
G632	Connecting rod ball check, assembled	855	Spray valve clamp bridge
632	Connecting rod ball check, complete	855A	Spray valve clamp stud nut
634	Connecting rod foot shims (state thickness)	870	Spray valve rocker
G636	Crank pin box, assembled; Part Nos. 636, 637.	872	Spray valve rocker stand
636	Crank pin box, 2 halves	873	Spray valve rocker stand pin
637	Crank pin box bolt	876	Spray valve rocker push rod
	Crank pin box cap screw and nut	1067	Lubricating oil sump
640	Crank shaft	1067A	Lubricating oil float guide flange
710	Base	1067B	Lubricating oil float guide stud
712	Base cap, flywheel end	1068	Lubricating oil strainer cage
713	Base cap, center	1087	Pressure lubricating oil gauge—30 lbs.
717	Base cap stud	1218	Fuel oil purolator
	Base cap stud nut		Purolator bracket
718	Base lubricating oil strainer	1287	Lubricating oil purolator
719A	Base cap shim, flywheel end	1306	Chain sprocket, driver
720A	Base cap shim, center	1307	Chain sprocket, driven
722A	Base cap shim, opposite flywheel end	1308	Chain shield
724	Base oil pipe flange with pipes fitted in		Chain shield cap screw
	Base oil pipe flange cap screw	1309	Chain shield cap
		1310	Ball bearing container
		1311	Chain sprocket shaft
		1312	Chain sprocket shaft ball bearing
		1313	Silent chain

