

*Revised Instructions 1944*

# INSTRUCTION BOOK

No. 27-12

FOR  
INSTALLING AND OPERATING

# ATLAS IMPERIAL

FOUR CYCLE  
MECHANICAL INJECTION  
DIESEL ENGINES

*CLYDE GAGNE*

*ATLAS ENG. CO.*

*HOME AL. 1909  
WE. 9446*

**ATLAS IMPERIAL DIESEL ENGINE CO.**

MAIN OFFICE AND FACTORY

OAKLAND, CALIFORNIA, U. S. A.

CABLE ADDRESS  
"ATGAS"

DESIGNED BY  
BENTLEY'S  
WESTERN UNION (UNIVERSAL EDITION)  
A. S. C. FIFTH EDITION  
PRIVATE

PRINTED IN THE U. S. A.

INSTRUCTION BOOK

No. 27-12

FOR

INSTALLING AND OPERATING

ATLAS IMPERIAL

FOUR CYCLE

MECHANICAL INJECTION

DIESEL ENGINES

*Gene Brock  
Huntington  
Hwy. 101  
No. 27-12*

ATLAS IMPERIAL DIESEL ENGINE CO.

1000 BROADWAY NEW YORK

OAKLAND, CALIFORNIA, U. S. A.

SOLE AGENTS  
WESTERN OIL & LOCAL SERVICE CO.  
A. D. 1717 LONDON  
ENGLAND

PRINTED IN THE U. S. A.

## Explanation of the Diesel Principle

### FACTS:

1. Air becomes hot by being compressed. The degree of heat depends on the amount of compression.
2. Three hundred and seventy-five pounds compression creates sufficient heat to ignite fuel when properly sprayed into the compression chamber at the proper time.
3. Fuel oil, if sufficiently atomized, will ignite when injected into a cylinder of compressed air, the temperature of which has been raised above the fire test of the fuel by means of compression.
4. The expansion of the burning fuel oil is the power-creating force within the cylinder of the engine.

The diesel engine differs from a gas engine from the fact that it is a constant pressure engine. That is, the injection of the fuel into the cylinder is timed and controlled to maintain constant pressure during its introduction, while in a gas engine a constant volume of mixture is taken into the cylinder and after compression same to a safe limit (about 50 pounds) the mixture is ignited by some auxiliary mechanism and the pressure is instantly raised in the nature of an explosion to a degree depending on the volume of the mixture.

While the terminal pressures are about the same in both types of engines, the efficiency of the diesel is twice that of the gas engine due to compressing the air to a high temperature before injecting the fuel, then controlling this injection so that combustion continues for a predetermined time, varying with the load.

This process enables the diesel engine to maintain a much higher mean effective pressure with a corresponding greater horsepower for the same cylinder dimensions.

In order to obtain perfect combustion within the cylinder it is necessary to inject the fuel oil in the form of a very fine spray which is done by the specially designed spray nozzle.

By understanding these fundamental requirements of a diesel engine it is readily seen that the mechanical injection diesel engine is very simple.

### CYCLE:

Atlas-Imperial Diesel Engines operate on the four cycle principle. The four cycle implies that the work in the cylinder is accomplished in four strokes of the piston, or two revolutions of the engine.

The function of each cycle or stroke of the piston is as follows:

#### 1. INTAKE STROKE:

When the piston goes down on the intake stroke, the intake valve being open, the cylinder becomes filled with air from the atmosphere.

#### 2. COMPRESSION STROKE:

On the upward stroke of the piston, the inlet valve is closed and the air in the cylinder is compressed to about 375 pounds pressure per square inch. At this pressure (as explained above) the temperature of the compressed air is raised sufficiently to ignite the fuel. A few degrees before the piston reaches the top of the compression stroke the fuel spray valve is opened by a cam and the fuel sprayed into the heated

# Explanation of the Diesel Principle

1. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

2. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

3. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

4. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

5. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

6. The piston is forced down on the intake stroke, the air is compressed in the cylinder. The degree of compression is such that the air is heated to a temperature of about 500 degrees Fahrenheit. At this point the piston is at the bottom of the cylinder and the pressure is about 100 pounds per square inch. The air is now ready to ignite the fuel.

air. A constant pressure of fuel oil is always maintained in the spray nozzles at all times by means of small plunger pumps which are more fully described later in the book.

### 3. EXPANSION STROKE:

The fuel oil burning and expanding in the cylinder maintains pressure on the piston during the downward stroke. Near the end of the power stroke the exhaust valve opens and allows the burned gases to escape.

### 4. SCAVENGING STROKE:

As the piston returns to the top of the cylinder with the exhaust valve open, the piston pushes all of the burned gases out of the cylinder through the exhaust valve. When the piston has reached the top, the exhaust valve is closed and the intake valve again opened.

This completes the four cycles or four strokes of the ATLAS-IMPERIAL MECHANICAL INJECTION DIESEL Engine and describes the method of its functioning.

It will be noted that while the sequence of the strokes forming this cycle is similar to that of the gas engine, the functions performed during the cycle (except on the exhaust stroke) are materially different.

On the first stroke, by taking into the cylinder pure air only, we are enabled to compress this charge sufficiently to secure a very high temperature which would be impossible with a charge of gas mixture, because of liability of preignition.

This high temperature secured allows the use of cheap, low grade fuel oils of high fire test which are safe to handle and increases both the thermal and commercial efficiency of the engine.

On the third stroke the fuel is introduced under absolute control, as to timing and quantity, the constant pressure in the column of fuel oil being sufficient so that when the valve opens the fuel is completely atomized and ready for instant firing at the moment it reaches the heated interior of the cylinder. No high pressure air is used to force this fuel oil in the cylinder.

With some methods (not true solid injection type) fuel is introduced under low pressure into a recessed casting, projecting into the firing chamber while there is no pressure, and on the up stroke of the piston the pressure increases until sufficient heat is developed to ignite the little cartridge of fuel (previously injected under no pressure) and when it ignites it blows the fuel oil out through small holes provided for that purpose. No control of the exact moment of firing is possible, as in our method where the fuel is mechanically injected into the cylinder at the proper time.

As stated above, this combustion is not in any sense an explosion, but takes place during a well defined, predetermined portion of the power stroke and at constant pressure, and because of the nature of its introduction into the cylinder and the large volume of pure air into which it is forced, the combustion is perfect within the range of cylinder power rating, hence the high thermal efficiency of the diesel engine on low grade fuel oils.

The foregoing description of the engine is, of course, general in character, intended to cover only the principles around which the physical construction is assembled.

## In General

**I**N issuing this instruction book we have tried to present to the reader the principal points to be observed in the care, operation and maintenance of the Atlas-Imperial Diesel Engine in a clear and concise manner.

This information is intended not only for use by the operator but also for those responsible for the performance of the engine. It is impractical to cover the exceptional conditions which might occur and therefore we have only covered those with which each operator should be thoroughly familiar.

Along these lines we offer as a satisfactory suggestion:

**WHEN THE ENGINE IS RUNNING SATISFACTORILY AND SMOOTHLY DO NOT CONTINUALLY TRY TO BETTER THE OPERATION WITH MINOR ADJUSTMENTS.**

### **FIRST: NEVER ALLOW YOUR ENGINE TO SMOKE:**

A diesel engine, oil engine, gas engine, kerosene lamp, or a candle perform the same operation, namely: Each burns a certain amount of fuel when mixed with proper proportions of air, and when the proportions are such that there is not enough air for the fuel to burn clean—in other words, too much fuel for the amount of available air—you will have smoke. Whether it be a candle, kerosene lamp, gas engine, oil engine, or diesel engine, smoke indicates that the proportions of air and fuel are not correct. These proportions must be adjusted to a point at which smoke is eliminated,—combustion perfect and exhaust clear.

In a diesel engine there are two things that will cause the engine to smoke; first, as above stated, too much fuel for the amount of air; and secondly, not the right distribution of broken up fuel in the combustion chamber. If the spray nozzle should be out of order or partly clogged, the fuel may enter the combustion chamber in a solid liquid form, in which case it does not properly mix with the air in the cylinders. When the exhaust from an engine is smoky it clearly indicates that combustion is not perfect and that the residue, in shape of smoke, is clinging to the oily surfaces of the cylinders, pistons, piston rings, valves, etc., and when this happens you are creating trouble for yourself and doing an injustice to the engine. Therefore, the first thing in consideration of the operation of a diesel engine is, **NOT TO ALLOW YOUR ENGINE TO SMOKE.**

### **SECOND: DO NOT OVERLOAD YOUR ENGINE:**

A diesel engine is unlike a gas engine in that it can be overloaded. You can continue increasing the power of a diesel engine to a great extent by admitting too much fuel which increases the heat, therefore increases the pressure in the cylinder. One cannot continually overload an engine any more than you can continually overload any other thing, thinking that you can go on successfully carrying the overload without bad results. Atlas-Imperial Diesel Engines are of such liberal dimensions that they will pull a considerable overload without smoking; but if one attempts to overload his engine too much it will naturally smoke.

and smoke means trouble. There is no harm in running the engine continually up to its full power as long as its exhaust is clear and the combustion perfect. Do not allow spray valves, air starting valves, inlet or exhaust valves to be leaky. If an engine has been allowed to smoke for some time, carbon will be deposited on the valve seats in spots and allow the valves to leak. As soon as a valve is leaky a blast of fire will pass through the leaky valve and start to cut the valve seats or valves, thereby causing trouble.

### **THIRD: LUBRICATION:**

Any piece of machinery needs proper lubrication and a diesel engine is not an exception. Always see that lubricating systems are always in proper working order. We have attempted to make the lubricating systems in our engines as near fool proof as possible, but it still remains for human intelligence to watch it from time to time to see that it functions in the way that it should.

The lubricating oil consumption is a variable factor, depending somewhat on the grade of oil used, but principally on the care given the engine in its operation, ordinarily about 750 to 1000 horse power hours per gallon.

### **CYLINDERS:**

Oil is supplied to the cylinder walls by means of the force feed lubricator through a small pipe connected to the inlet and exhaust side of the cylinder wall. It requires not more than 13 or 14 drops of oil to the cylinder wall per minute. It is very important that this lubrication be constant and does not vary in any way. This may be detected very readily by counting the drops as they drop past the sight glasses located on top of the oiler and should be checked at regular intervals.

### **BEARINGS:**

The lubrication of the main bearings is accomplished by means of a force feed system, so arranged that the oil is forced, by means of a pump at a pressure varying from five to ten pounds, according to that which has been regulated by the pressure lubricating oil relief valve. The oil is pumped from the oil reservoir or supply tank then through oil pipes in the base (on the exhaust side of the engine) to the bottom of the main bearings. This is not done through the top of the bearing caps, thus permitting a simple arrangement of the oil piping and obviating the necessity of breaking pipe connections, etc. The crank shaft revolving in the main bearing is provided with a hole drilled angular through to the crank pin, through which the oil is forced, thereby lubricating the connecting rod bearings or crank pins.

It is important that sufficient oil be always maintained in the oil reservoir to insure the proper function of the pumps so that the oil will circulate freely, unhampered by air bubbles. A pressure gauge is connected to the lubricating oil pipe line, which indicates the oil pressure on the bearings at all times. If no pressure is registered on this gauge, it will indicate one of three things: ONE—that there is not sufficient oil in the oil reservoir; TWO—that the lubricating oil pumps are

not functioning properly; or **THIRD**—that some bearing has become sufficiently loose to allow the lubricating oil to flow out too freely.

All the oil pumped through these bearings is collected in the crank pits, flows to a sump through a strainer, is pumped from the sump through a filtering tank, then back to the main bearings.

#### **WRIST PINS:**

In the top half of the crank bearing at the center of the groove is a hole for the oil to leave the crankbearing and enter the connecting rod. The connecting rod is drilled hollow and is fitted with a check valve at its lower end, (which checks any attempt of the oil to return back into the crank) so that the oil which is forced through the crankshaft and through the hole in the bearing will pass through the check valve and then up through the hollow connecting rod to lubricate the wrist pin in the piston. (See section drawing on next page.)

#### **OIL RETURN:**

During its course the oil is being gradually squeezed out, partly through the main bearings, partly through the crank bearings and the balance out through the wrist pin bearings, from where the oil returns by gravity to the sump in the bottom of the base.

The lubricating oil distributing pipe is provided with a spring-loaded relief valve, so arranged as to allow the surplus oil to be delivered back into the lubricating oil reservoir and thereby preventing the pressure from becoming excessive.

#### **CHOICE OF OIL:**

When the engine warms up after running for some time, the oil pressure may not register as high as when the engine was first started, due to the fact that the oil becomes thin with heat, and therefore flows more freely out through the sides of the bearings.

The choice of lubricating oil for the power cylinders and bearings of a diesel engine is a matter involving many operating factors of which the most important are the temperature and pressures within the power cylinders, the thoroughness of oil distribution over the working surfaces, the amount of carbon formation and the method of lubrication.

Fairly high temperatures and pressures are to be contended with in a diesel engine. The oil film formed, therefore, must have sufficient body to support the piston and piston rings, preventing metallic contact with the cylinder. Heat will naturally thin out the oil and therefore in the selection of the lubricant the body of the oil at the operating temperatures must be considered. High quality, correctly refined diesel engine cylinder oils retain their body better than the low grade, inferior oils.

Unsuitable or inferior oil fails to provide satisfactory lubrication. It chars freely, combines easily with fuel impurities the products of incomplete combustion and dust or dirt in the intake air, forming a hard crust-like deposit. In an attempt to supply lubrication with such an oil excessive feeds to the cylinders are generally employed. This aggravates the difficulties. The oil then works itself in between and behind






DIAGRAM SHOWING PATH (INDICATED BY ARROWS) OF LUBRICATING OIL THROUGH ENGINE

the piston rings where it gradually bakes and decomposes forming deposits that cause the rings to stick in their grooves.

The trade names of oils suitable for lubricating ATLAS-IMPERIAL DIESEL ENGINES and the names of the companies marketing them are far too numerous to mention in the limits of this book. We have found from our experience that a high grade oil of the following characteristics usually meets all the requirements when selected according to the following guide as to viscosity:

Engine Room Temp. °F	S & E Viscosity Number
Below 40	10
20-60	20
30-75	30
50-90	40
65-100	50
75-130	60
85 and over	70

In the selection of a lubricating oil it must be remembered that only oils of the highest grade should be used. In order to assure yourself on this point, deal with a reputable oil company. Most oil companies maintain lubricating engineers on their staffs and these men should be consulted freely as they can make recommendations on the ground with the full knowledge of the conditions under which the engine is to work.

### Fuel Oils

**T**O assist in obtaining the proper oil to be used as fuel in this engine, we transmit herewith our recommendations. These recommendations are the results of experiments which have been conducted in the past.

In purchasing the fuel oil to be used for this engine, you should advise the oil company that it will be used in a mechanical injection type diesel engine. We recommend that your first purchase be only a few hundred gallons rather than a large supply, in order to be sure that you obtain the proper kind of oil.

There are two characteristics of oil which are of *EQUAL IMPORTANCE*. First, its *GRAVITY*; and second, its *VISCOSITY*.

It has been found that low Gravity oils are not satisfactory for all year service as they congeal in cold weather. Similarly it has been found that high Gravity oils, or oils about 38° or higher do not function satisfactorily at all times, especially in the warmer temperatures.

Therefore, the results of the various tests conducted reveal the following:

1. It has been found that any oil of less than 24° Gravity Baume must be filtered and heated. While this oil may be satisfactorily used in certain localities, generally speaking it is unsatisfactory for the average installation where cold weather is encountered, on account of the difficulty in heating the oil.

2. That 24° to 28° Gravity Baume oil is usually clean and needs no heating or straining before reaching the filter provided on the engine except in extremely cold weather providing the oil has the proper Viscosity.

3. The conclusions reached with regard to engines that must be operated at zero temperatures are that during cold weather periods oil

from 32° to 38° Gravity Baume should be used, but that at all other times the 24° to 28° Gravity Baume oil should be used.

The Viscosity should be from 40 to 50 seconds with a Saybolt test 100° Fahrenheit. If the Viscosity runs to any great degree higher than 50 seconds, you will find that the oil is too thick for use as it is liable to clog the strainers and pumps.

Therefore, specifications for the oil best suited for this engine are as follows:

Gravity—24° to 28° Baume.

Calorific value—18,500 to 19,500 B.T.U.'s.


Irrespective of what oil is used, it is necessary that the oil be refined to the extent that all water, sand and grit has been removed.

You will note from the above that the fuel oil most suitable is one from 24 to 28 degrees gravity.

This is the oil which we ordinarily use to test the engine at our plant. It is known as Fuel Oil or Diesel Fuel Oil and it is sometimes incorrectly called Crude Oil.

For temperatures from zero to 15° Fahrenheit above zero it would probably be best to use 32° Baume Gravity Oil, but for sub-zero temperatures you would have to use a 36° Baume to 38° Baume Gravity Oil.

Fuel oils lighter than distillate, such as kerosene, etc., are not suitable for this engine. It is possible that you may be able to adjust the engine so it will function satisfactorily for a short period, but the engine is not intended for such oils and if used trouble probably must be expected later, as such fuels will damage the valves and pumps. This is equally true of any other diesel or semi-diesel engine.



#### EXHAUST AND INLET VALVE CAGE TYPE

- G515 Valve and cage complete. Parts 510, 513, 514, 515 and valve nuts.
- 510 Exhaust or inlet valve.
- 512 Exhaust or inlet valve cage bushing (only in 11" bore engines and larger)
- 513 Exhaust or inlet valve spring.
- 514 Exhaust or inlet valve spring bushing—top
- 515 Exhaust or inlet valve cage.
- 517 Exhaust or inlet valve cage flange.
- 518 Exhaust or inlet valve cage gasket.
- 519 Exhaust or inlet valve cage ring.

## Fuel Oil

Theoretically, a Diesel engine should burn any petroleum product if properly prepared. However, there are certain impurities in almost all fuel oils which determine to a large extent the suitability of those oils for operation in a Diesel engine. The following brief description of the various impurities, with their effect upon the engine, is given to guide the purchaser and the oil supplier in the selection of a proper fuel oil.

### GRAVITY

Specific gravity is in itself no indication of the suitability of a Diesel fuel oil.

### VISCOSITY

The viscosity of a fuel oil will determine its suitability by the effect that it has on the flow of the fuel oil through the pipes, valves and so forth. An oil of high viscosity that may be in all other respects satisfactory will require heating to enable it to flow satisfactorily through the fuel lines, valves and so forth. Another effect of high viscosity is the resistance that it offers to vaporization, requiring variation in the size of the burner tips.

### MECHANICAL IMPURITIES

Under this heading come such elements as dirt, grit, fiber and water. The small holes in the spray valve tips, strainers and so forth are liable to become clogged if there is too large an amount of mechanical impurities. Besides this, they have the effect of cutting out the seats of the valves.

### CARBON RESIDUE

This is a characteristic of fuel oil which has only recently received attention, at least in Diesel fuel oil specifications, and one which has quite an effect on the operation of an engine. This carbon residue (Conradson carbon) is a measure of the proportion of carbon deposits that are likely to occur on the piston, cylinder head, valves and so forth. A high percentage of Conradson carbon is usually associated with carbon formation within the cylinders, as well as gumming up of the valves and stems.

### LUBRICATING VALUE

All petroleum products have a certain amount of oiliness and the higher this oiliness is in a fuel oil the less wear will be noticed on the pump plungers, spray valve stems and such similar parts. Very light oils, such as kerosene, contain little or no lubricating value and therefore their use will usually result in excessive wear on the pump plungers, spray valve stems and so forth.

The following are the general characteristics of a suitable Diesel fuel:

Viscosity (Saybolt Universal) at 100° F. ...	35 to 60 seconds
Sulphur content .....	1.5% maximum
Conradson Carbon .....	1% maximum
Moisture and sediment .....	.5% maximum
Ash .....	.05% maximum

Legal regulations usually limit the flash to a minimum of 150° F.

Diesel fuels from California crudes are readily obtainable, meeting the above specifications in gravities between 24 and 30° API. Midcontinent fields produce so-called gas oils with gravities ranging from 32 to 36° API. European oils likewise come within this same range.

We cannot place too much emphasis upon the importance of getting oil which is free from impurities to avoid the clogging of valves, strainers, spray valve tips and so forth and upon the desirability of securing an oil with as much oiliness as possible to avoid wear on some of the vital parts of the engine.

**DO NOT CONFUSE DIESEL FUEL WITH ORDINARY BOILER OIL. THE LATTER CONTAIN DIRT AND SEDIMENT WHICH MAKE THEM UNSUITABLE FOR A DIESEL ENGINE.**

A heavy fuel oil thinned down by the addition of a lighter oil is not a satisfactory fuel, as the lighter oils in such a mixture burn off rapidly and leave the heavier oil to gum up piston rings and valves and cause excessive cylinder wear. Insist on getting a straight run distillate for your fuel.

#### CARE OF FUEL OIL


The best fuel oil can be ruined if not properly handled. Store and transport your fuel in clean container and use your containers for fuel oil only. Flush out the container frequently to remove any dirt, rust or scale that may accumulate.

Keep your containers closed to prevent dust, dirt and water getting in the fuel oil, as these impurities in the fuel are bound to cause you more trouble and annoyance than required to keep your fuel clean. Provide means in your storage tanks for draining off any water that may be present.



Draw fuel from storage tank through a pipe inserted in top of tank. Be sure the lower end of suction pipe is 3 or 4 inches above the bottom of tank. This allows dirt and water to settle to bottom of tank where they can be occasionally drawn off.

An engine supply tank should be provided big enough to hold at least a day's supply of fuel.

Strain the fuel oil when transferring it from storage tanks to engine supply tank. A good strainer can be made from a five-gallon can by cutting off the top and inserting therein a conical strainer made from 150-inch bronze gauze. Cut the gauze into 4 triangles and solder the upper edges to the top of the can. Have the lower point of the gauze about 2 inches above the bottom of the can. Punch a hole in the bottom of the can and solder on a piece of 1½" brass pipe, which can be inserted in engine supply tank filling hole. Be sure to use a new bright clean can free from rust or dirt. Keep the strainer away from dust and dirt when not in use and wash out frequently.



FOR PART NAME SEE PARTS LIST ON PAGES 60 TO 67




CYLINDER HEAD

## Cylinder Head

- G500** Cylinder head complete assembly (as shown on page 12) except spray valve G849 and horse shoe collar 877, the following parts are included, Nos. 500, 510, 512, 513, 514, 514A, G520, G550, 564, 564B, 565, 566, 567, 567A, 567B, 579, 580, 582, 583, 584, 585, 586, 588, G590, 764, 854, 854A, 855, 855A, G870, 872, 873.  
Specify whether handle or male connecting link is wanted with head. The following parts are also included if used: 515, 516, 517.
- GA500** Cylinder head with exhaust, inlet, air starting valves and springs only. Part Nos. 500, 510, 512, 513, 514, 514A, 564, 579, 580, 582, 583, 584, 585, 586, 588.
- 500** Cylinder head only with studs 567 and 764.
- 501** Cylinder head stud.
- 501A** Cylinder head stud, special for lifting head.
- 502** Cylinder head gasket.
- 510** Valve, inlet or exhaust. (Specify whether inlet or exhaust)
- 512** Valve stem bushing, inlet or exhaust.
- 513** Valve spring, inlet or exhaust.
- 514** Valve spring bushing, inlet or exhaust—top.
- 514A** Valve spring bushing, inlet or exhaust—bottom.
- 515** Valve cage, inlet or exhaust.
- 516** Valve cage stud.
- 517** Valve cage flange.
- 519** Exhaust or inlet valve cage ring.
- G520** Inlet rocker, with roller and Pin. Parts 520, 520A, 523, 524, G527A.
- 520A** Inlet rocker bushings (set of 2)
- 523** Rocker roller, for inlet, exhaust or air.
- 524** Rocker roller pin, for inlet, exhaust or air.
- 526** Push rod fork, for inlet, exhaust, air or fuel.
- 527** Fork pin, inlet, exhaust, air or fuel.
- G527A** Fork pin, ball lock.
- G550** Exhaust rocker with roller and pins. 550, 550A, 523, 524, G527A.
- 550A** Exhaust rocker bushings (set of 2)
- 564** Rocker shaft, connecting link (female).
- 564A** Rocker shaft connecting link (male).
- 564B** Rocker shaft connecting link pin.
- 565** Rocker shaft.
- 566** Rocker shaft bearing (state: with or without wings).
- 567** Rocker shaft bearing stud.
- 567A** Rocker shaft bearing stud nut; top.
- 567B** Rocker shaft bearing stud lock nut.
- G570** Air starting handle, complete: Part Nos. 570, 571, 571A, 572, 573.
- 570** Air starting handle.
- 571** Air starting handle pawl.
- 571A** Air starting handle pawl screw
- 572** Air starting handle pawl spring
- 573** Air starting handle sector.
- G580** Air starting valve complete. Cage type—Parts No. 580, 581, 581A, 582, 582A, 584, 585, 585A, 586. (See page 19 for drawing.)
- G590** Air starting rocker, with roller and pins. 523, 524, G527A. (590A when used).
- 590A** Air starting rocker bushings (set of 2).
- 764** Exhaust elbow stud.
- G849** Spray valve complete (see page 14 for parts).
- 854** Spray valve clamp.
- 854A** Spray valve clamp stud.
- 855** Spray valve clamp bridge.
- 855A** Spray valve clamp bridge nut.
- G870** Spray valve rocker. Spray valve rocker pin No. 527.
- Spray valve rocker fork No 526.
- Spray valve rocker fork pin lock No. 527A.
- 372** Spray valve rocker stand.
- 873** Spray valve rocker stand pin.
- 877** Spray valve horse shoe collar.



Cut No. 101



**SPRAY VALVE**

- |     |  |      |                                   |
|-----|--|------|-----------------------------------|
| 849 | Spray valve, complete; Part Nos. 850, 851, 853, 856, 857, 858, 859, 860, 864, 865, 866, 867, 878, 878A, 1201, 1202, 1204 | 865  | Spray valve gland nut             |
| 850 | Spray valve stem   | 866  | Spray valve gland                 |
| 851 | Spray valve body   | 867  | Spray valve packing seat          |
| 853 | Spray valve spring casing  | 877  | Spray valve horseshoe collar      |
| 856 | Spray valve seat nut   | 878  | Spray valve stem nut              |
| 857 | Spray valve spring plug  | 878A | Spray valve stem lock nut         |
| 858 | Spray valve spring   | 895  | Spray valve testing outfit        |
| 859 | Spray valve spring ball bearing  | 896  | Spray valve cleaning needles      |
| 860 | Spray valve gasket   | 897  | Spray valve tip or nozzle remover |
| 864 | Spray valve nozzle or tip  | 898  | Spray valve tip cleaner plunger   |
|     |  | 1201 | Fuel strainer body                |
|     |  | 1202 | Fuel strainer stem                |
|     |  | 1204 | Fuel strainer gasket              |

Always Give Part Name, Part Number and ENGINE NUMBER

## Spray Valve

### FUNCTION:

The function of the spray valve is to admit the fuel to the cylinders at the proper time and at the same time deliver the fuel oil in the form of a very finely atomized spray so that the fuel is readily ignited and properly burned within the cylinder. The spray valve is located in the center of the cylinder head and extends clear through the cylinder head, with the spray valve tip projecting slightly below the bottom of the cylinder head. It is provided with a needle valve held in position by a strong spring, the tension of which is slightly adjustable. The fuel oil is admitted below the stuffing box at a pressure of anywhere from 1000 to 3500 pounds per square inch (depending on the adjustment of the pressure regulating valve). This spray valve is held in position by a clamp arrangement having a single stud, thus making it easily removable for inspection or cleaning. It is operated by a lifting rocker arm which lifts the valve approximately 2/100 of an inch when the engine is pulling full load. The governor controls the lift of these valves so that when the engine is running idle the lift is very little and only sufficient to admit enough fuel to turn over the engine. As the load increases the governor causes these valves to raise more and consequently admit additional fuel in direct proportion to the power developed.

### SPRAY VALVE TIPS

Sizes used differ according to size of engine (bore and stroke) and are as follows:

6½ inch bore	8½ inch stroke	use size 8 tips with 5 holes.
7 inch bore	10 inch stroke	use size 8 tips with 5 holes.
7½ inch bore	10½ inch stroke	use size 8 tips with 5 holes.
8½ inch bore	12 inch stroke	use size 8 tips with 5 holes.
9 inch bore	12 inch stroke	use size 10 tips with 5 holes.
9½ inch bore	13 inch stroke	use size 10 tips with 5 holes.
10 inch bore	13 inch stroke	use size 11 tips with 5 holes.
11½ inch bore	15 inch stroke	use size 12 tips with 5 holes.
12 inch bore	16 inch stroke	use size 14 tips with 5 holes.
14 inch bore	18 inch stroke	use size 14 tips with 5 holes.

### CARE AND MAINTENANCE:

To insure proper functioning of the spray valve it is paramount that it be kept clean and the holes in the tips be absolutely clear. The packing on the stem should be screwed up just tight enough to hold the pressure, for if too tight it will cause excessive wear on the valve stem, thereby causing the valve to work in a very sluggish manner or to remain open allowing too much fuel to enter the cylinder. When such a condition exists the cylinder relief valve will begin to blow off due to the excessive pressure which arises in the cylinder under such conditions.

If any of the tips become clogged with dirt or any other matter the fuel is unable to enter the combustion chamber in its usual manner and will cause a reduction in the revolutions of the engine, also in power. This condition is more apt to occur in a new installation due to dirt

that is in the piping and the tips will have to be cleaned until this disappears or is worked out. If clean pure fuel is used the tips will only have to be cleaned on very few occasions.

When the valves have been disassembled to be cleaned care must be taken to readjust them properly when placing them in the cylinder heads. The maximum lift of the spray valve spindle should never be more than  $2/100$  of an inch in any case. Excessive lift will only be an unnecessary waste of the fuel while not sufficient lift will cause the lifters and cams to make excessive and unnecessary noise. The screw strainer on the side of the spray valve should be checked to see that it is not striking the spray valve stem and is also screwed in the strainer far enough to miss the nipple part of the union.

#### ADJUSTING AND TIMING OF SPRAY VALVES:

Put the governor control handle in full speed position; place the engine starting lever in running position. Close all isolating valves on fuel rail. Open all cylinder relief or snifter valves. Bar over flywheel in running direction until pointer on engine frame corresponds to a few degrees before mark on flywheel showing opening of spray valves. Then open isolating valve corresponding to cylinder you are timing. Be sure that the piston in that particular cylinder is nearing the top of compression stroke, which is easily ascertained by the fact that both inlet and exhaust valves remain closed on this stroke. CAUTION: NEVER ATTEMPT TO TURN THE FLYWHEEL WITH THE BAR UNLESS ALL CYLINDER SNIFFER VALVES ARE ENTIRELY OPENED.

Pump up fuel pressure by hand fuel pump to about two thousand (2000) pounds pressure. Then continue barring the flywheel over slowly until the pointer on the engine frame registers with mark on flywheel showing opening of the spray valve. (Referring to diagram A on page 21.) If at that point the fuel pressure on gauge does not release, then loosen jam nut under the push rod fork for that particular spray valve, and adjust the push rod by screwing it in or out as the case may be, until the pressure is released at that particular point. If the pressure is released before the flywheel is turned to the proper point indicated on the flywheel, then the rod is too long and must be shortened by screwing it into the fork slightly; and if the pressure does not release when the flywheel has been turned to the proper point as above referred to, then the rod should be unscrewed and thereby lengthened until it releases at the exact point.

When this has been accomplished lock the jam nut tight under the fork, turn the flywheel back again to see if the tightening of jam nut has slightly altered the timing, in which case it must be loosened again, and the rod screwed into the fork slightly farther, and the jam nut tightened again. Turn the flywheel backwards again a few degrees, then turn ahead very slowly to see that the pressure releases exactly at the desired point.

It will be necessary to pump up pressure with the hand pump each time.

In order to ascertain the time of closing the spray valve, turn the engine ahead until the mark on flywheel showing closing of spray valve

is past the pointer. Then pump up pressure, bar the flywheel backwards again until the pressure is released. This will determine the exact point on the flywheel where the spray valve closes.

If this varies a little from 18 degrees DO NOT change push rod, as time of opening of the valve is most important. If it closes earlier than 15 degrees or later than 20 degrees then the cam on the cam shaft must be turned away from you to make the closing come later and toward you to make the closing come earlier. After moving the cam the push rod must again be adjusted. Changing the location of the cam should only be necessary at very infrequent intervals.

Once a week the timing should be checked over and the valves corrected.

Proceed in this same manner with the spray valves on each cylinder on which valve timing needs checking up. It is important that the valve timing of the spray valves be correct on all cylinders in order that they all may be working equal when the engine is running.

In timing the spray valves a certain amount of oil enters the cylinder when the fuel pressure is released. In order to clear the cylinders of the excess oil ALWAYS TURN THE ENGINE OVER ON AIR WITH THE SNIFFER VALVES OPEN, being sure of course that the isolating valves are closed, before starting on fuel.

If black smoke issues from the exhaust pipe ascertain which cylinder is smoking, the cause of the smoke being either due to too much fuel entering that cylinder, or that some of the spray tips are partly plugged up, spreading the fuel unequally into the cylinder, or admitting so little fuel to some of the cylinders that an excessive load is put on some one individual cylinder; or, that the spray valve may be leaking either at the valve seat or at the joint between spray tip and spray valve body. It is of utmost importance that the spray valve be absolutely tight so that no fuel can enter the cylinder at any other time excepting during the period when the valve is opened by the spray cam, which should be at all times kept in proper adjustment.

Whenever a spray valve is removed from the head for the purpose of cleaning, grinding, or adjusting, then upon replacing the spray valve the timing of that spray valve must be checked up again as a slight alteration may be caused by the replacement:

#### **SPRAY VALVE TEST CLAMP:**

There is a connection located on the high pressure rail for the purpose of testing out the spray valves after cleaning them, to see that the holes are clean.

Two tapped holes are located directly beneath this connection on the center frame to which a stand is attached for holding the spray valve, and also has a lever for lifting the valve in the same manner as the rocker.

#### **HOW TO USE TEST CLAMP:**

First close all the isolating valves on the fuel rail. Then after spray valve has been fastened in the stand attached to the centerframe connect the spray valve, with its connection, to the connection on the fuel rail. After all connections have been inspected and made tight, pump

up the fuel pressure by the hand priming pump. Then open the valve by hitting the end of the test stand handle with a quick short tap. Watch closely to ascertain if a fine spray of fuel comes out of EACH separate hole in the tip.

When assembling the spray valve make sure that all of the parts have been put together tight and DO NOT LEAK, for a leaky spray valve is one of the greatest reasons why the engine will not run properly.

Care should be taken not to forget to close the isolating valves on all of the cylinder heads for if they are left open a large amount of oil will gather on the top of the piston head and when the engine is started is liable to cause trouble, due to the excessive oil being compressed in the cylinder.

#### TAKE SPECIAL NOTICE

##### 1. A SMOKY ENGINE OR LOSS OF POWER IS DUE TO:

*Fuel Valve:* Leaks, stem is clogged, nozzle is worn out, tension on spring too loose, or not timed properly, or all of the cylinders are not firing properly.

*Exhaust Valves:* Leaks, stem stuck in guide or not timed properly.

*Intake Valve:* Leaks, stem stuck in guide or not timed properly.

*Loss of Compression:* Leaky cylinder relief valve, cylinder head gasket leaking, too low a piston (extra clearance due to wear and adjustment of connecting rod brasses and main bearings), change to a higher altitude or piston rings stuck in their grooves.

Too low fuel oil pressure. Engine running at too slow a speed.

Too much lost motion in governor parts. Wrong kind of fuel oil.

##### 2. BE SURE TO:

Oil all moving parts with regularity. Watch lubricating oil pressure.

Squirt a small amount of kerosene mixed with lubricating oil (3 parts kerosene, 1 part lubricating oil) on each exhaust and intake valve stem previous to each time engine is started. This is not necessary if the engine has just been stopped and is started soon again.

Always slow engine down while idling.

Keep correct amount of lubricating oil in sump or supply tank.

Change lubricating oil when necessary (usually from 250 to 300 hours engine running time). Clean oil strainer every two weeks—oftener if required.


Draw water off bottom fuel oil tank and strainers as often as required to keep water out of engine. Always keep the engine clean.

Be sure to examine various parts of the engine while it is running to make sure that none of the parts have become overheated. This is also a good test to see if the circulating water is circulating properly and the lubricating oil still retains its lubricating value.


##### TIMING OF THE AIR STARTING VALVE:

To time the air starting valves, first open all of the cylinder snifter valves, then turn the flywheel in the direction of rotation until top cen-

## Air Starting Valve



AIR STARTING VALVE  
PLAIN TYPE



AIR STARTING VALVE  
CAGE TYPE

- 150 A.T.C.
- |  |  |
|--|--|
| <p>580 Air starting valve complete. Cage type—Parts No. 580, 582, 582A, 584, 585, 585A, 586.</p> <p>579 Air starting valve spring bushing.</p> <p>580 Air starting valve.</p> <p>581 Air starting valve cage.</p> <p>581A Air starting valve cage ring.</p> <p>581B Air starting valve cage gasket.</p> <p>582 Air starting valve spring.</p> <p>582A Air starting valve spring nut.</p> | <p>583 Air starting valve spring washer—top.</p> <p>584 Air starting valve nut.</p> <p>585 Air starting valve balance bushing.</p> <p>585A Air starting valve balance bushing nut.</p> <p>586 Air starting valve balance bushing ring.</p> <p>588 Air starting valve spring washer—bottom.</p> |
|--|--|

ter of No. 1 cylinder is opposite the pointer attached to the centerframe. Place the air starting valve handle in the starting position as shown in Figure A, page 20. Now adjust the starting valve push rod tight enough so that there is no play between the starting valve stem and the rocker arm roller (or button), then tighten the jam nut on the push rod. This adjustment will time the air starting valve to open at top center. The closing of the valve is taken care of in the shape of the cam. The above process must be repeated with each cylinder to properly time the air starting valve.

The air starting valve opens every other revolution and must be set when the piston is on that top center when both inlet and exhaust valves are closed.

### VALVE TIMING:

Referring to the diagrams (page 21):  
Diagram A shows the portion of the revolution relative to top center for the opening and closing of spray valves. Remember that this

valve setting is based on the governor being set at full speed position, which in turn will permit the maximum lift of the spray valve.

Diagram B has reference to the intake valve which admits air to the cylinders during the intake stroke. The diagram shows approximately the time that the intake valve should remain open. When the proper time for opening has been adjusted, which is  $5^{\circ}$  before top center, then the time of the closing of the intake valve will take care of itself, the same as the exhaust valve.

Diagram C—Exhaust valve—shows approximately the period that the exhaust valve should remain open. In timing the exhaust valve only pay attention to the closing time. If the cams are so set as to close the exhaust valve at approximately the correct position, which is  $5^{\circ}$  past top center, as shown on diagram, then the opening time will take care of itself, due to the size of the lobe of the cam.

It is not essential that the air intake and exhaust valve settings should be exactly on the degree as they may vary two or three degrees either way without interfering with either power, economy or running condition of the engine.

In adjusting the valve setting at any time do so by lengthening or shortening the valve lifter rods by screwing them in or out of the rocker fork which is attached to the outer end of the rockers.

#### ADJUSTMENT AND TIMING OF ALL THE VALVES:

When an engine is shipped from the factory all of the valve timings are adjusted properly for running. If, however, for any reason the engine has been partly dismantled during installation or shipment, or if some one has interfered with the valves settings, (while crating or shipping) then it may become necessary to retime the valves before starting the engine. The most important valve to have correctly timed is the spray or fuel valve, located in the center of the cylinder head.





FIGURE A

**FIRING ORDER OF THE ENGINES:**


Number ONE cylinder is the one located next to the flywheel (except on a special engine, or such where the flywheel is placed near the reverse gear and thrust bearing). The firing order for the three cylinder engine is 1-2-3, for the four cylinder engine is 1-2-4-3, and for the six cylinder engine is 1-5-3-6-2-4.

Turning the engine "towards you" means turning the flywheel counter clock wise, the flywheel being viewed from the flywheel end of the engine looking aft toward the stern of the boat.


On 4 cyl. 6 1/2 x 8 1/2 only.  
18° and 6°



**BOTTOM CENTER  
SPRAY VALVE TIMING  
DIAGRAM A**



**BOTTOM CENTER  
INLET VALVE TIMING  
DIAGRAM B**



**BOTTOM CENTER  
EXHAUST VALVE TIMING  
DIAGRAM C  
VALVE SETTING DIAGRAMS**



## Fuel Relief Valve--Marine Type

<p>G1230 Relief Valve, complete: Part Nos. 1117, 1118, 1124, 1125, 1230, 1231, 1232, 1233, 1234, 1236, 1237, 1238, 1238A, 1239, 1240, 1242, 1243, 1244, 1245, 1249.</p> <p>1230 Relief valve body.</p> <p>1231 Relief valve gland.</p> <p>1232 Relief valve stud.</p> <p>1233 Relief valve stem.</p> <p>1234 Relief valve seat.</p> <p>1235 Relief valve stud collar.</p> <p>1236 Relief valve spring.</p> <p>1237 Relief valve spring cage.</p> <p>1238 Relief valve handle bearing.</p> <p>1238A Relief valve handle bearing pin.</p> <p>1239 Relief valve handle adjusting screw.</p>	<p>1240 Relief valve handle plug, lower.</p> <p>1241 Relief valve cap nut.</p> <p>1242 Relief valve fuel fitting.</p> <p>1244 Relief valve handle sector.</p> <p>1245 Relief valve spring plug, top.</p> <p>G1243 Relief valve handle, complete: Part Nos. 1117, 1118, 1124, 1125, 1243, 1249.</p> <p>1117 Relief valve handle.</p> <p>1118 Relief valve pawl.</p> <p>1124 Relief valve pawl spring.</p> <p>1125 Relief valve pawl spring screw.</p> <p>1243 Relief valve handle cam.</p> <p>1247 Relief valve stud collar gasket.</p> <p>1248 Relief valve stud gasket.</p> <p>1249 Relief valve handle screw.</p>
--	---

**T**HE fuel relief, is a spring loaded valve connected directly to the high pressure fuel pumps by means of steel tubing, and is equipped with an adjustable spring tension. The purpose of this valve is to regulate the pressure of fuel delivered to the spray nozzles. It is essential that the pressure be kept to about 3800 pounds when the engine is working under normal loads. An increased pressure causes an excess amount of oil to enter the cylinder, thereby increasing the heat. The normal initial temperature at the time of ignition when the engine is developing its rated horse power is approximately 1200 degrees Fahrenheit. Additional fuel pressure makes it possible to raise this temperature up to 2400 degrees Fahrenheit.

The increase in pressure will increase the power to some extent but not in proportion to the increase in pressure or heat produced.


The high momentary temperature has a tendency to distort the metal in the cylinder heads as well as in the top of the piston. The quick changing of temperature from high flash to cold intake period will eventually start minute surface cracks which in time increase in depth as well as in area. This is likely to cause cracked piston heads and cylinder heads.

With the increased pressure on the fuel line, more oil is injected into the cylinder than can be used, and consequently it will leave a carbon deposit. This clings to the cylinder head and valves, causing the valves to leak.

It will be readily understood that the higher the pressure on the fuel line the greater will be the quantity of fuel admitted to the cylinders during a given period of spray valve opening. If the engine is idling, the pressure should be reduced to about 1000 pounds. The altering of pressure is accomplished by manipulating the handle on top of the fuel relief valve.


When the engine has been adjusted to a certain pressure of fuel suitable for a fixed load, then it is essential that this pressure be maintained uniformly. This valve is so constructed that any quantity of oil over and above that which goes through the spray nozzles at the fixed pressure will be by-passed and let back into the fuel suction line. In

this way this fuel relief valve automatically maintains the pressure and takes care of the surplus fuel pumped by the high pressure fuel pumps.  
 If the fuel relief valve leaks, make sure that valve stem is working freely and not stuck or sluggish in packing; if this is found to be all right then valve is leaking at seat and should be reground with a very fine abrasive.



SECTION THROUGH FUEL RELIEF VALVE. SEE PAGE 47  
 22-A



# Fuel Relief Valve---Remote Control Type



- 1117 Handle
- 1118 Pawl
- 1124 Pawl spring
- 1125 Pawl spring screw
- G1230 Valve, complete; Part Nos.  
1117, 1118, 1124, 1125, 1230,  
1231, 1232, 1233, 1234, 1236,  
1237, 1238, 1238A, 1239, 1240,  
1242, 1243, 1244, 1245, 1249.
- 1230 Body
- 1231 Gland
- 1231A Gland Packing ring

- 1232 Stud
- 1233 Stem
- 1234 Seat
- 1236 Spring
- 1237 Spring cage
- 1238 Handle bearing
- 1238A Handle bearing pin
- 1239 Handle adjusting screw
- 1240 Handle plug, lower
- 1242 Fuel fitting
- G1243 Handle, complete; Part Nos.  
1117, 1118, 1124, 1125, 1243,  
1249.
- 1243 Handle
- 1244 Handle sector
- 1245 Spring plug, top
- 1249 Handle screw

## Cylinder Relief Valves or Safety Valves





Cut No. 59

- |       |  |       |  |
|-------|--|-------|--|
| G1190 | Cylinder relief valve, complete: Part Nos. 1190, 1191, 1192, 1193, 1194, 1195, 1199. | 1195  | Cylinder relief valve adjusting screw lock.    |
| 1190  | Cylinder relief valve body.  | 1196  | Cylinder relief valve cylinder plug.           |
| 1191  | Cylinder relief valve stem.  | 1199  | Cylinder relief valve adjusting screw.         |
| 1192  | Cylinder relief valve sept.  | G1197 | Snifter valve, complete: Part Nos. 1197, 1198. |
| 1193  | Cylinder relief valve spring.  | 1197  | Snifter valve body.                            |
| 1194  | Cylinder relief valve spring collar.   | 1198  | Snifter valve stem.                            |

Three types of cylinder relief valves are used as shown in accompanying cuts.

**T**HE function of the cylinder relief valve is to safeguard against excessive pressure in case too much fuel has been admitted to any one cylinder or in case fuel is admitted and ignited before the engine obtains sufficient speed, in which case the pressure may rise excessively. These valves are set at the factory at 750 pounds per square inch and should not be tampered with. Excess pressure escapes through these relief valves. It is just as essential to ascertain from time to time that these valves are in working order as it would be to ascertain at regular intervals that a safety valve on a boiler is in working order. At least once a day they should be tried out. By inserting a screw driver or some such instrument between the nut on the end of the valve stem and the spring tension gland, you can raise the valve from its seat while the engine is running allowing a blast of air or fire to blow from the valve for one or two strokes only. If the valve appears to leak, tap the end of the valve stem lightly with a hammer and at the same time rotating the stem with a wrench on the nut, which will make the valve seat itself again. Care must be taken not to allow these valves to leak

as the heat would soon destroy the valve seat and make them useless. A small steel needle valve, called snifter valve, is attached to these safety valves for the purpose of opening up to see if the cylinders are functioning properly.




### ADJUSTMENT OF SAFETY VALVES:

If while the engine is running the safety valve should blow off (at ordinary running speed) and the spray valve is known to be tight and not sluggish, then it indicates that the safety valve spring is weak or seat of valve is pitted.


To remedy this, tap very lightly the end of the valve stem with a hammer and with a wrench on valve nut turn valve slowly while tapping. This will cause the valve to reseat itself; if blowing still continues increase tension of the valve spring by turning the adjusting nut until sufficient tension has been exerted on the valve spring to cause the valve to cease from blowing.

Don't tighten up too much or there is danger of setting up the valve spring beyond the safety point. **DO NOT TIGHTEN THE SPRING TO OVERCOME VALVE LEAKAGE.** If it becomes necessary to regrind the valve to overcome leakage, be sure to get the valve spring adjusting screw back in the same position so as to maintain a pressure of 750 pounds.

### Spray Valve Strainers



The Spray Valve Strainer is inserted in the fuel line directly before the spray valve. The function of the strainer is to remove any fine particles of sediment that may have passed through the main fuel strainers. The cleaning of the strainer's element should be required at very infrequent intervals. When it is necessary, the strainer should be removed from the spray valve and taken apart by unscrewing the two ends. The strainer element consists of a unit of laminated disks held together with a screw and nut. Wash the element off in gasoline before loosening the clamp screw. After all the dirt has been removed from the outside of element loosen the clamp screw about an eighth of an inch and rinse it out well in clean gasoline. Then thoroughly clean out the interior of the strainer body and reassemble. Be sure that all particles of dirt have been removed before reassembling, or clogging of spray valve tips will result.




SUMP PUMP

## Lubricating Oil Sump Pump

- 1066 Sump pump gland.
  - 1066A Sump pump gland stud.
  - 1069 Sump pump strainer.
  - G1070 Sump pump complete: 1070, 1066, 1066A, 1075, and packing.
  - 1070 Sump pump body.
  - 1073A Sump pump check valve; inlet.
  - 1073B Sump pump check valve; outlet.
  - 1075 Sump pump plunger.
  - 1076 Sump pump connecting rod.
  - 1076A Sump pump connecting rod pin.
  - 1079 Sump pump crank disc.
  - 1079A Sump pump crank washer.
- Some models use Rocker No. 1088 to drive sump pump in place of crank No. 1079, otherwise same part numbers apply.

**T**HE lubricating oil sump pump is located on the end on the center-frame and driven by means of a disc crank on the end of the cam shaft. The suction pipe extends down into the lubricating oil sump in the engine base drawing the lubricating oil through a sump strainer and maintaining the proper level of lubricating oil in the sump. The discharge from the pump is conducted to the lubricating oil service tank. Here the oil passes through another strainer settling into the bottom of the tank from which it is drawn by the high pressure lubricating oil pump.

For part names not given here refer to Parts List, pages 60 to 67



### PRESSURE LUBRICATING PUMP

- G1080 Pressure lubricating pump complete: Part Nos. 1080, 1081, 1082, 1083, and 1085.
- 1080 Pressure lub. pump cylinder.
- 1080A Pressure lub. pump suction check valve.
- 1080B Pressure lub. pump discharge check valve (spring loaded)
- 1081 Pressure lub. pump plunger.
- 1081A Pressure lub. pump plunger nut.
- 1082 Pressure lub. pump gland.

### FUEL OIL STRAINER

- G1218 Fuel strainer complete: Part Nos. 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1225A, 1225B, 1226.
- 1218 Fuel strainer body.
- 1219 Fuel strainer cover.
- 1220 Fuel strainer grid.
- 1221 Fuel strainer valve.

### HIGH PRESSURE FUEL PUMPS


- 796 H. P. Fuel discharge fitting.
- 796A H. P. Fuel discharge fitting split ring.
- 797 H.P. Fuel discharge fitting nut
- G800 H. P. Fuel pump complete: Part Nos. 800, 805, 806, 808, 809, 810, 810B.
- 800 H. P. Fuel pump body.
- G802 H. P. Fuel pump suction valve cage with No. 801, and 811.

- 1083 Pressure lub. pump gland nut
- 1085 Pressure lub. pump plunger eye.
- 1085A Pressure lub. pump plunger eye pin.
- 1086 Pressure lub. pump connecting link.
- 1087 Pressure lub. pump oil pressure gauge (30 lbs.)
- 1088 Pressure lub. pump rocker.
- 1088A Pressure lub. pump rocker pin.
- (See Page 30)
- 1222 Fuel strainer stuffing box.
- 1223 Fuel strainer gauze.
- 1224 Fuel strainer cover gasket.
- 1225 Fuel strainer cover clamp.
- 1225A Fuel strainer cover clamp cap screw.
- 1225B Fuel strainer cover clamp stud
- 1226 Fuel strainer grid spring.
- 801 H. P. Fuel pump suction valve
- 802 H. P. Fuel pump suction valve cage.
- 802A H. P. Fuel pump suction union nut.
- 802B H. P. Fuel pump suction union sleeve.
- 805 H. P. Fuel pump plunger.
- 805A H. P. Fuel pump plunger spring.



See Page 41, Cut No. 44, also  
Air Compressor Part Names.

See Page 44, Cut No. 90, giving  
more details of Pump Chain  
Drive.



### HIGH PRESSURE FUEL PUMPS

- |      |                                       |      |   |
|------|---------------------------------------|------|---|
| 806  | H. P. Fuel pump packing ring.         | 820D | Pump rocker shaft bearing cap stud.                                 |
| 808  | H. P. Fuel pump gland.                | 821  | Pump rocker shaft bearing cap.                                      |
| 809  | H. P. Fuel pump gland nut.            | 822A | Pump crank shaft coupling.  |
| 810  | H. P. Fuel pump plunger head          | 822  | Pump crank shaft.   |
| 810B | H. P. Fuel pump plunger nut.          | 822B | Pump crank shaft coupling bolts.                                    |
| 811  | H. P. Fuel pump discharge valve.      | 822C | Fuel pump crank shaft washer  |
| 817  | H. P. Fuel pump plate.                | 823  | Pump crank shaft connecting rod assembly; Part Nos. 823, 824, 824A. |
| 818  | Pump rocker—double.                   | 824A | Pump crank shaft connecting rod cap bolts.                          |
| 818A | Pump rocker pin—long.                 | 828  | Pump connecting link.   |
| 818B | Pump rocker—single.                   | 828A | Pump connecting link pin.   |
| 818D | Pump rocker bushing—bronze.           | 829  | Pump crosshead guide.   |
| 819  | Pump rocker shaft.                    | 831  | Pump crosshead.   |
| 819A | Pump rocker shaft sleeve—stud         | 831A | Pump crosshead nut.   |
| 820  | Pump rocker shaft bearing and caps.   | 831B | Pump crosshead button.  |
| 820A | Pump rocker shaft bearing stud—long.  |      |   |
| 820B | Pump rocker shaft bearing stud—short. |      |   |

FOR PART NAMES NOT GIVEN HERE REFER TO PARTS LIST, PAGES 60 TO 67

811 = C 9534

801 = S 579

## HIGH PRESSURE FUEL PIPES COMPLETE WITH UNIONS

In ordering fuel pipes or fuel pipe unions, specify outside diameter of pipe. Each pipe complete with parts No. 1176, 1177.

1183	Testing pipe—Fuel rail to test clamp.	1188	Fuel pipe from fuel rail to spray valve.
1184	Fuel pipe from fuel relief valve discharge to pump suction.	1189	Fuel pipe from fuel rail to fuel oil receiver.
1185	Fuel pipe from high pressure fuel pump discharge to fuel relief valve inlet.	1189A	Fuel pipe from fuel oil receiver to fuel pressure gauge.
1186	Fuel pipe from connecting pipe between H. P. fuel pumps (discharge).	1200	Fuel rail with isolating valves.
1187	Fuel pipe from fuel pump to fuel rail.	1170	High pressure union nipple.
		1176	High pressure fuel union nut.
		1177	High pressure fuel union sleeve.

## Fuel Oil Strainer

(Parts on Page 48)

**T**HE fuel oil strainer is composed of two compartments or chambers. In each of the chambers is located a built up strainer unit or cartridge, each having three layers of one hundred mesh bronze screen. These cartridges fit snugly into the chamber, and are held in position by means of spiral springs. The spiral springs are held down by the covers which are sealed with copper gaskets.

This strainer unit is provided with a passover valve with ports so constructed that by turning this valve in one position the fuel oil flows into one compartment of the strainer only, turning it in the other position permits the other strainer to be used. In this way one strainer can be shut off, taken apart and cleaned, while the other is in use, without interfering with the running of the engine.

It is important that these strainers be cleaned from time to time. The method of cleaning these strainer units or cartridges is by submerging them in a can of gasoline and washing them off thoroughly, remove all sediment in the bottom of the strainer chamber, and wipe all joints clean and free from grit and dirt before again assembling. Grit, dirt or impurities permitted to enter the fuel pump are apt to create trouble, and for that reason it is important to use as much care as possible in eliminating impurities from the fuel oil.


## FORCE FEED OILER

The force feed oiler used for oiling the cylinder walls of the engine is driven off the cam shaft by means of a crank disc.

Some models lub. drive off water pump connecting rod. Same part numbers apply.

- 1060 Force feed lubricator (see note)
- 1065 Force feed lubricator drive rod
- 1065A Force feed lubricator drive rod pin.



Note: When ordering new lubricator, state manufacturer, number of feeds, also type.




## Fuel Pump

796	High pressure fuel discharge fitting		Fuel pump cross head guide cap screw
796A	High pressure fuel discharge fitting split ring	831	Fuel pump crosshead
797	High pressure fuel discharge fitting nut	831A	Fuel pump crosshead nut
800	Fuel pump body	831B	Fuel pump crosshead button
800A	Fuel pump body nut	831C	Fuel pump crosshead bushing
801	Fuel pump suction valve	831D	Fuel pump crosshead oil guard
802	Fuel pump suction valve cage	846	Fuel pump housing
802A	Fuel pump suction union nut	846A	Fuel pump housing stud
802B	Fuel pump suction union sleeve		Fuel pump housing stud nut
805	Fuel pump plunger	847	Fuel pump housing cover
805A	Fuel pump plunger spring		Fuel pump housing cover hinge
806	Fuel pump packing		Fuel pump housing cover hinge screw
808	Fuel pump gland	1173	Fuel pump bleeder connection
809	Fuel pump gland nut	1176	High pressure fuel union nut
809A	Fuel pump gland lock nut	1178	High pressure fuel union sleeve
810	Fuel pump plunger head	1178	High pressure fuel union sleeve, blind end
810B	Fuel pump plunger nut	G1274	Priming pump only; Part Nos. 1275, 1276.
811	Fuel pump discharge valve	1275	Priming pump cylinder
817	Fuel pump plate	1276	Priming pump plunger
	Fuel pump plate steel cover (front)	1276A	Priming pump plunger nut
	Fuel pump plate steel cover (top)	1278	Priming pump cap
	Fuel pump plate steel cover screw (large or small)	1279	Priming pump plunger eye
	Fuel pump plate and housing slotted cap screw	1279A	Priming pump connecting rod link
822	Fuel pump crank	1279B	Priming pump link eye
G823	Fuel pump connecting rod, assembled, Part Nos. 823, 824, 824A.		Priming pump link eye nut
823	Fuel pump connecting rod	1280	Priming pump connecting rod
824	Fuel pump connecting rod cap	1280A	Priming pump connecting rod pin
824A	Fuel pump connecting rod cap bolt	1281	Priming pump handle
	Fuel pump connecting rod cap bolt nut	1284	Priming pump handle push rod
828C	Fuel pump cross head pin	1284A	Priming pump handle push rod fulcrum
829	Fuel pump cross head guide		

Always Give Part Name, Part Number and ENGINE NUMBER





FUEL PUMP



ATLAS Imperial


No 8251 - H.P. 110





**ATLAS  
IMPERIAL  
PAKLAND  
CAL. U.S.A.**


**ROTARY PUMP—CLAMP STYLE**



**ROTARY PUMP—FOOT STYLE**


- |      |  |      |   |
|------|--|------|---|
| 692  | Centerframe door (round)                     | 1341 | Rotary pump gear and shaft driver for 1/4" outlet pump  |
| 692A | Centerframe door gasket                      | 1342 | Rotary pump gear and shaft driven for 1/4" outlet pump  |
| 692D | Centerframe cover cap screw                  | 1351 | Rotary pump felt washer                                 |
| 693  | Rotary pump door                             | 1352 | Rotary pump gear, driven                                |
|      | Rotary pump door cap screw                   | 1353 | Rotary pump gear driver on cam shaft coupling           |
|      | Rotary pump door gasket                      | 1354 | Rotary pump ball bearing                                |
| 693A | Rotary pump door bearing cap                 | 1355 | Rotary pump drive shaft                                 |
| 693B | Rotary pump door ball bearing retainer       | 1371 | Rotary pump gear and shaft for 1/2" outlet pump, Driver |
|      | Rotary pump door ball bearing retainer screw | 1372 | Rotary pump gear and shaft driven for 1/2" outlet pump  |
| 693C | Rotary pump door clamp cap                   | 1378 | Rotary pump, complete; 1/4" outlet                      |
| 693D | Rotary pump door clamp cap screw             |      | Rotary pump holding down cap screw                      |
| 693E | Rotary pump door cap—cap screw               |      |   |
| 1338 | Rotary pump, complete; 1/4" outlet           |      |   |

## FUEL PUMP CRANK SHAFTS



THE ABOVE CUTS SHOW THE DIFFERENT CONSTRUCTION EMPLOYED IN FUEL PUMP CRANK SHAFTS. THE PART NUMBERS ARE THE SAME IRRESPECTIVE OF THE NUMBER OF CRANKS

- |      |  |       |                                      |
|------|--|-------|--------------------------------------|
| 684  | Centerframe cover—end of camshaft.           | 822   | Fuel pump crank shaft.               |
| 820  | Fuel pump rocker shaft bearing and caps.     | 822A  | Fuel pump crank shaft coupling.      |
| 820A | Fuel pump rocker shaft bearing stud (long).  | 822B  | Fuel pump crank shaft coupling bolt. |
| 820B | Fuel pump rocker shaft bearing stud (short). | 1079  | Lubricating sump pump crank disc.    |
| 821  | Fuel pump rocker shaft bearing cap.          | 1079A | Sump pump crank disc washer          |




### PRESSURE LUBRICATING RELIEF VALVE

- |       |  |      |  |
|-------|--|------|--|
| G1090 | Valve, complete: Part Nos. 1090, 1091, 1092, 1093, 1095, 1096. | 1092 | Lubricating relief valve adjusting screw.      |
| 1090  | Lubricating relief valve body cap.                             | 1093 | Lubricating relief valve spring                |
| 1091  | Lubricating relief valve plunger.                              | 1095 | Lubricating relief valve adjusting screw nut.  |
|       |  | 1096 | Lubricating relief valve check valve and body. |

### PRESSURE LUBRICATING RELIEF VALVE

A pressure lubricating relief valve, used in connection with the pressure lubricating oil pump, is used to maintain a constant and determined pressure of the lubricating oil on its course through the engine. To adjust the valve: first loosen the adjusting screw nut and then tighten or loosen the adjusting screw to suit requirements desired. Then tighten the adjusting screw nut.





## Piston Rings

**A**LL pistons are fitted with six piston rings, five above the pin and one below, as illustrated. All rings are step cut rings. The rings just above the pin and the ring below the pin are oil scraper rings. Care should be taken to have these rings properly fitted in the ring grooves as shown.


In fitting new rings a vertical clearance of .005" should be given all rings and it is also important that there be plenty of clearance under the rings and that the sides of the ring grooves be parallel in order to realize the full effect of the rings. If the grooves are worn or tapered it will be necessary to face the sides of the grooves a little wider.

The opening between ends of rings No. 1, 2 and 3 should be not less than .005" per inch of cylinder diameter, while No. 5 and No. 6 ring should be fitted with about .002" per inch of cylinder diameter.


All ring openings should be measured with the rings in the cylinder.

## Cylinder Lubricating Pipe

- 600 Cylinder.
- 611 Cylinder lubricating pipe through jacket.
- 612 Cylinder lubricating pipe gland.
- 613 Cylinder lubricating pipe packing.
- 614 Cylinder lubricating pipe elbow.



The cylinder lubricating oil pipe shown here for lubricating the piston and cylinder walls of engine requires but three or four drops of oil per minute. It is fed from a force feed oiler through a small copper pipe. A gland and packing keep the water from leaking out of the cylinder jacket.




### Valve Lifters

- |      |   |      |  |
|------|---|------|--|
| 525  | Push rod, inlet or exhaust.                             | 596  | Air starting valve lifter roller pin.    |
| G528 | Valve lifter, with roller and pin for inlet or exhaust. | 599  | Air starting valve lifter guide.         |
| 529  | Valve lifter guide, inlet or exhaust.                   | 672  | Cam shaft.                               |
| 530  | Valve lifter roller, for inlet or exhaust.              | G680 | Cam shaft bearing and bushing.           |
| 531  | Valve lifter roller pin, for inlet or exhaust.          | 685  | Cam shaft bushing.                       |
| 532  | Inlet and air starting cam.                             | 876  | Spray valve rocker push rod.             |
| 560  | Exhaust cam.  | 880  | Spray valve cam toe.                     |
| 593  | Push rod, air starting.                                 | 881  | Spray valve cam disc.                    |
| G594 | Air starting valve lifter, with roller and pin.         | G883 | Spray valve lifter, with roller and pin. |
| 594A | Air starting valve lifter collar.                       | 884  | Spray valve lifter roller.               |
| 594B | Air starting valve lifter spring.                       | 885  | Spray valve lifter roller pin.           |
| 595  | Air starting valve lifter roller.                       | 887  | Spray valve lifter guide.                |
|      |   | 888  | Spray valve lifter guide spring.         |
|      |   | 889  | Spray valve push rod socket.             |

## PRIMING PUMPS

A priming pump, No. 1275, connected directly to the high pressure fuel pump and equipped with a hand lever, No. 1281 (See pages 28 and 32). When starting the engine this pump is used for the purpose of exhausting any air from the fuel oil piping and to pump up pressure on the high pressure pipes and manifolds so that when the engine is started the fuel is already at the point of the spray nozzles ready to be admitted to the cylinder as quickly as the spray nozzles are opened by the spray can.



PRIMING PUMP

G1275	Priming pump, complete: Part Nos. 1275, 1276, 1276A, 1278 and packing.	1280A	Priming pump plunger pin.
1275	Priming pump cylinder.	1281	Priming pump handle.
1276	Priming pump plunger.	1282	Priming pump handle bracket.
1276A	Priming pump plunger nut.	1282A	Priming pump handle bracket spacer.
1278	Priming pump cap nut.	1282B	Priming pump handle bracket bar.
1279	Priming pump plunger eye.	1282C	Priming pump handle bracket lever pin.
1280	Priming pump plunger connecting rod.		

## DAY TANK PUMP

SEE PAGE 28 FOR DRAWING OF PUMPS

G1287	Day tank pump, complete: Part Nos. 1287, 1288, 1288A, 1289, 1291, 1292.	1289A	Day tank pump plunger eye pin.
1287	Day tank pump body.	1290	Day tank pump check valve.
1288	Day tank pump plunger.	1291	Day tank pump gland.
1288A	Day tank pump plunger nut.	1292	Day tank pump gland nut.
1289	Day tank pump plunger eye.	1293	Day tank pump connecting rod.

## High Pressure Fuel Pumps


**T**HE fuel pumps are of the plunger type with  $\frac{1}{2}$ -inch diameter, hardened and ground plungers. These pumps are to pump the fuel up to the required pressure, and for that reason are very closely fitted. It is necessary to use care in packing these plungers. The packing glands should never be screwed down so hard as to make the gland absolutely tight. It is essential that a small amount of fuel oil be allowed to work up through the packing and thereby lubricate the plunger.

A quantity of packing is furnished with each engine. If the packing gland is screwed down too tight the packing will become dry and hard, and thereby cause the plunger to wear. The lower ends of the suction valves extend sufficiently below the valve bodies so that they can be reached by hand, turned around and moved with the fingers. If a valve should be too tight at the stem it can be polished off with fine emery cloth, care being observed not to take off too much. In most cases it can be loosened by moving it up and down and twisting it around with the fingers.


## Air Compressor

**P**URPOSELY no provision has been made for continuous lubrication of this unit. It is intended that the operator should use a squirt can and give this a few drops of oil at the air intake when first starting the engine. After that it receives plenty of oil from the vapor within the base. If a continuous oil drip were used on the air compressor, the valves would carbon up very quickly and there would be danger of the vapor from the lubricating oil igniting, in which case the pipe or tanks would be carried away by an explosion. After the engine has run for a few hours, it will never need any more lubrication on the air compressor except what is received from vapor within the crank case.

- |      |   |      |  |
|------|---|------|--|
| 900  | Air compressor cylinder with 902.   | 918D | Air compressor inlet valve flange gasket.            |
| G901 | Air compressor head, complete: Part Nos. 901, 905, 907, 908, 908A, 915, 915A, 918, 918A, 919, 920, 922, 922A, 923, 924. | 919  | Air compressor discharge valve spring.               |
| 901  | Air compressor head with 907.   | 920  | Air compressor discharge valve guide.                |
| 902  | Air compressor cylinder head stud.  | 922  | Air compressor discharge valve cap nut.              |
| 905  | Air compressor inlet valve.   | 922A | Air compressor discharge valve relief handle.        |
| 906  | Air compressor grid.  | 923  | Air compressor discharge valve guide cap.            |
| 907  | Air compressor inlet valve bushing.   | 924  | Air compressor discharge valve spring bushing.       |
| 908  | Air compressor inlet valve spring.  | 925  | Air compressor piston.                               |
| 908A | Air compressor inlet valve nut.   | 926  | Air compressor piston ring.                          |
| 908B | Air compressor inlet valve washer.  | 927  | Air compressor piston pin.                           |
| 915  | Air compressor discharge valve  | 928  | Air compressor piston pin bushing.                   |
| 915A | Air compressor discharge valve adjusting screw.   | G929 | Air compressor piston connecting rod; bushed.        |
| 918  | Air compressor discharge valve nut.   | G930 | Air compressor eccentric strap (2 halves) and bolts. |
| 918A | Air compressor discharge valve relief handle nut.   | 932  | Air compressor eccentric strap bolts.                |
| 918B | Air compressor inlet valve cap nut stud.  | 933  | Air compressor eccentric.                            |
| 918C | Air compressor inlet valve flange stud.   | 935  | Air compressor relief valve.                         |
|      |   | 936  | Air compressor pass-over pipe.                       |
|      |   | 937  | Air compressor gauge; 300 lbs.                       |




SEE PAGE 27 FOR DRAWING OF AIR COMPRESSOR




### PLUNGER PUMP

- |      |   |       |  |
|------|---|-------|--|
| G260 | Plunger pump complete: Parts 260, 261, 262, 262A, 262B. | GA260 | Plunger pump body with 262A.                   |
| 214  | Plunger pump valve cage.                                | 261   | Plunger pump plunger.                          |
| 214A | Plunger pump valve cage center stud.                    | 262   | Plunger pump gland.                            |
| 215  | Plunger pump suction bonnet.                            | 262A  | Plunger pump gland stud.                       |
| 215A | Plunger pump bonnet copper asbestos gasket.             | 262B  | Plunger pump gland stud nut.                   |
| 215B | Plunger pump inlet flange.                              | G264  | Plunger pump connecting rod with 264A.         |
| 216  | Plunger pump discharge bonnet                           | 264A  | Plunger pump connecting rod pushing.           |
| 216A | Plunger pump bonnet connecting stud.                    | 264B  | Plunger pump connecting rod pin.               |
| 217  | Plunger pump valve guide stem                           | 266   | Plunger pump connecting rod crank disc.        |
| 218  | Plunger pump valve spring.                              | 266A  | Plunger pump connecting rod crank disc washer. |
| 219  | Plunger pump rubber disc valve                          |       |  |
| 219A | Plunger pump valve bushing.                             |       |  |



### INTERMEDIATE GEAR

- |      |                                    |      |   |
|------|------------------------------------|------|---|
| 640  | Crankshaft with 660 and 655.       | 665C | Intermediate gear pin washer.             |
| 660  | Crankshaft pinion.                 | 666  | Intermediate gear bearing.                |
| 664  | Intermediate gear (inc. 664A).     | 666A | Intermediate gear bearing cap screws.     |
| 665  | Intermediate gear pin.             | 666B | Intermediate gear bearing lock set screw. |
| 665A | Intermediate gear pin bolt.        |      |   |
| 665B | Intermediate gear pin bolt washer. |      |   |




### Centrifugal Pump

G370	Centrifugal pump, complete: Part Nos. 370, 371, 371A, 372, 373, 373A, 374, 379, 381, 381A, 382, 383.	373	Centrifugal pump gland.
GA370	Centrifugal pump body with 374.	373A	Centrifugal pump gland stud.
370A	Centrifugal pump outlet flange.	374	Centrifugal pump shaft bushing.
371	Centrifugal pump cover.	379	Centrifugal pump shaft.
371A	Centrifugal pump cover screws.	381	Centrifugal pump steady bearing.
371B	Centrifugal pump inlet flange.	381A	Centrifugal pump steady bearing cap screw.
G372	Centrifugal pump runner with shaft.	382	Centrifugal pump collar.
		383	Centrifugal pump ball bearing.
		384	Centrifugal pump coupling.

**T**HE centrifugal pump drive is by means of a silent chain from the crankshaft to the centrifugal pump shaft. With continued use, a slight amount of wear in the links will allow the silent chain to stretch and provision is made for taking up this stretch by means of a chain-adjusting spindle, as shown next page. Occasionally it is well to inspect the chain and take up apparent slackness. This is done by loosening the idler spindle bearing nuts and tightening up on the chain adjusting screws, No. 1314. When the proper tension has been obtained tighten the bearing bracket bolts again and secure them with wire to prevent from becoming loose. Tighten the lock nut on the chain tension adjusting screw. The chain must never be too tight. When properly adjusted there should be sufficient slack in the middle of the span between the pump sprocket and idler sprocket so that it can be lifted up and down with the fingers, about one inch.


Do not allow the chain to become too slack as there is danger of the chain riding over the teeth on the sprocket which would ruin both the sprocket and the chain. Watch the chain tension and take up when necessary.



### CENTRIFUGAL PUMP CHAIN DRIVE

1306	Chain sprocket (driver on crank shaft).	1315	Idler spindle.
1307	Chain sprocket (driven on pump shaft).	1315A	Idler spindle lock nut.
1308	Chain shield.	1316	Idler spindle split ring.
1309	Chain shield cap.	1317	Idler spindle bearing housing.
1310	Ball bearing container (blind end).	1318	Idler spindle chain sprocket.
1310A	Ball bearing container (shaft end).	1318	Idler spindle roller bearing (complete).
1311	Driven chain sprocket shaft.	1319	Idler spindle steel cover.
1312	Driven chain sprocket ball bearing.	1319A	Idler spindle steel cover screw.
1313	Silent chain.	1320	Idler spindle roller bearing spacer.
1314	Silent chain adjusting screw.	1321	Idler spindle spacer.
		1322	Idler spindle spacer washer.
		1323	Idler spindle felt washer.


For Drawing showing Parts No. 1306, 1307, 1308, 1309, 1311, 1313, 1317, see page 29.



### OIL COOLER

775	Oil cooler core.	779	Oil cooler gland.
777	Oil cooler head.	780	Oil cooler inlet pipe.
778	Oil cooler pipe.		






GOVERNOR AND SPEED CONTROL CONNECTIONS

## Governor

- |        |  |        |   |
|--------|--|--------|---|
| 691    | Governor shield.   | 1114A  | Governor compression spring collar.   |
| 691A   | Governor shield gasket.  | 1114B  | Governor compression spring collar.   |
| G1100  | Governor assembly: Part Nos. 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1113. | 1115   | Governor compression spring block.  |
| GA1100 | Governor body (always supplied with 1111 fitted on).   | G1117  | Governor control handle, complete: Part Nos. 1117, 1118, 1119, 1124, 1125, 1249.  |
| 1101   | Governor weight.   | 1117   | Governor control handle.  |
| 1102   | Governor weight pin.   | 1118   | Governor control handle pawl.   |
| 1103   | Governor weight roller.  | 1119   | Governor control handle sector.   |
| 1104   | Governor weight roller pin.  | 1120   | Governor rack for compression spring.   |
| 1105   | Governor weight roller plate.  | 1121   | Governor rack adjusting screw.  |
| 1106   | Governor thrust quill.   | GA1122 | Governor speed control socket with sector 1122A.  |
| 1107   | Governor thrust quill ball bearing, small.   | 1122A  | Governor speed control socket sector.   |
| 1108   | Governor, body ball bearing, large.  | G1122  | Governor speed control socket and handle complete: Part Nos. 1117, 1118, 1119, 1120, 1121, 1122, 1122A, 1124, 1125, 1249. |
| 1109   | Governor shaft.  |        |   |
| 1110   | Governor body collar.  |        |   |
| 1111   | Governor pinion.   |        |   |
| 1112   | Governor bearing.  |        |   |
| 1113   | Governor thrust quill bushing.   |        |   |
| 1114   | Governor compression spring.   |        |   |



GOVERNOR AND SPEED CONTROL, ETC.

- 1123 Governor control socket bearing.
- 1124 Governor control handle pawl spring.
- 1125 Governor control handle pawl spring screw.
- 1127 Governor connecting rod between forks.
- 1128 Governor fork.


- 1128A Governor vertical shaft.
- 1129 Governor lever on vertical shaft.
- 1129A Governor lever on vertical shaft pin.
- 1130 Governor fork on wedge shaft
- 1131 Governor wedge forks.
- 1132 Fuel control wedge.
- 1132A Fuel control wedge pin.
- 1133 Fuel control shaft.
- 1134 Fuel control shaft bearing.
- 1249 Governor control handle screw




1244




1243



1117



1116



1124




1125



1249



1238



G. 1230



1245



1237



String Packing



1231



1236



1248



1233



1240



1230



1247



1234



1239



1252



1242



1242




1241



1235

FUEL RELIEF VALVE. SEE PAGE 23



**DUPLEX FUEL STRAINER**

- |       |                         |      |                                   |
|-------|-------------------------|------|-----------------------------------|
| G1218 | Fuel strainer complete. | 1222 | Fuel strainer valve stuffing box. |
| 1218  | Fuel strainer body.     | 1223 | Fuel strainer gauze.              |
| 1219  | Fuel strainer cover.    | 1224 | Fuel strainer cover gasket.       |
| 1220  | Fuel strainer grid.     | 1225 | Fuel strainer cover clamp.        |
| 1221  | Fuel strainer valve.    | 1226 | Fuel strainer grid spring.        |


## Reverse Gear

The gears, in the drum, when reversing should be constantly running in compound. Fill the drum with a good grade of compound (generally done at first in the factory) when needed, through the plugged hole in the after end of the drum. It is good practice to put about one quart of good transmission oil in drum every few weeks.

The friction clutch is of the multiple-disc type. In case the clutch begins to slip, loosen one of the bolts holding the crowder collar together and turn collar slightly in clockwise direction, thereby tightening on the threads of the driver. Be sure to tighten all bolts again before attempting to run engine.



Plates should be oiled occasionally by pouring oil in the open end of the reverse gear drum.

If the brake shoes, Part No. 342, become too loose, so as not to hold drum stationary when reversing, tighten tie rod connecting brake posts. Be sure that brake shoes are entirely free of the drum when engine is going ahead.





- |      |   |      |  |
|------|---|------|--|
| 300  | Reverse gear drum with 319 and 318.   | 313A | Reverse gear cone pin.                               |
| 301  | Reverse gear thrust quill.  | 314  | Reverse gear crowder link.                           |
| 301A | Reverse gear thrust gear.   | 314A | Reverse gear crowder link pin.                       |
| 302  | Reverse gear center gear.   | 315  | Reverse gear crowder spring.                         |
| 303  | Reverse gear drum bushing.  | 316  | Reverse gear friction release thrust ring and pins.  |
| 304  | Reverse gear drum cover.  | 316A | Reverse gear friction release thrust ring spring.    |
| 305  | Reverse gear drum cover bushing.  | 317  | Reverse gear pinion spacing bushing.                 |
| 305A | Drum cover bushing ring.  | 318  | Reverse gear retainer ring bolt.                     |
| 306  | Reverse gear pinion (long).   | 319  | Reverse gear retainer ring.                          |
| 307  | Reverse gear pinion (short).  | 320  | Reverse gear friction plate (square hole).           |
| 308  | Reverse gear pinion pin.  | 321  | Reverse gear friction plate (round hole).            |
| 310  | Reverse gear driver.  | 321A | Reverse gear friction plate (round hole) fixed type. |
| 311  | Reverse gear driver plate.  | 323  | Reverse gear thrust quill bushing.                   |
| G312 | Reverse gear crowder collar and cone assembly, parts 312, 312A, 312B, 313, 313A, 314, 314A, 315, 330. | 324  | Reverse gear pinion bushing (long or short).         |
| 312  | Reverse gear crowder collar.  | 330  | Reverse gear cone.                                   |
| 312A | Reverse gear crowder collar bolt and nut.   | 333  | Reverse gear crowder collar bolt.                    |
| 312B | Reverse gear crowder collar pin.  |      |  |
| 313  | Reverse gear crowder.   |      |  |

## REVERSE GEAR CONTROLS




- 325 Reverse gear cone shifter stand—operator's side.
- 326 Reverse gear cone shifter.
- 326A Reverse gear cone shifter shaft.
- 327 Reverse gear cone shifter lever or wheel.
- 327A Reverse gear cone shifter wheel handle.
- 328 Reverse gear brake post crowder.
- 328A Reverse gear wedge roller block.
- 328B Reverse gear wedge roller.
- 328C Reverse gear wedge roller pin.
- 331 Reverse gear cone collar.
- 331A Reverse gear cone collar bolt.
- 335 Reverse gear cone shifter stand—exhaust side.
- 337 Reverse gear sector.
- 337A Reverse gear sector pinion.
- 337B Reverse gear sector pinion shaft.
- 340 Thrust bearing box.
- 341 Thrust bearing cap.
- 342 Reverse gear brake shoe.
- 342A Reverse gear brake shoe friction lining.
- 342B Reverse gear brake shoe pin.
- 343 Reverse gear brake post.
- 343A Reverse gear brake post pin (lower).
- 344 Reverse gear lever clamp.
- 344A Reverse gear brake post crowder link.
- 345 Reverse gear brake post swivel crowder.
- 345A Reverse gear brake post tie rod.
- 345B Reverse gear brake post tie rod spring.
- 346 Reverse gear brake post swivel.
- 347 Thrust bearing water pass-over pipe.






## PROPELLER AND SHAFTING



- |      |  |      |  |
|------|--|------|--|
| 339  | Reverse gear coupling.   | 357  | Stuffing box gland stud.                     |
| 351  | Propeller.   | 358  | Intermediate shaft coupling.                 |
| G352 | Propeller shaft complete with<br>Parts 359, 359A, 363, 364, 366. | 359A | Propeller shaft coupling bolt.               |
| G353 | Intermediate shaft complete<br>with Parts 339, 354, 358.         | 359  | Propeller shaft coupling.                    |
| 354  | Intermediate shaft coupling<br>bolt.                             | 360  | Stern bearing.                               |
| 355  | Stuffing box.  | 363  | Propeller shaft bushing (stuff-<br>ing box). |
| 356  | Stuffing box gland.  | 364  | Propeller shaft bushing (stern<br>bearing).  |
|      |  | 366  | Propeller nut and lock screw.                |




## VALVE AND CAGE REMOVER

The cut opposite shows the proper way to remove valve in cages from the cylinder head. First remove the flange that holds the cage down, then remove the top lock nut of the valve.

Screw the stud over the valve stem all the way down until it is tight against the valve stem nut, then screw the large nut in a clockwise motion, which will raise the valve and cage enough to permit it to be readily removed from the cylinder head without any undue strain.

- |       |                                |
|-------|--------------------------------|
| 3338  | Valve cage lifting yoke.       |
| 3338A | Valve cage lifting yoke screw. |





## Marine Installation

**T**HE condition of the boat, its length, breadth and the purpose for which it is intended to be used, will largely determine the location for the installation of the engine. Another point that must be considered in the selection of the engine location is that a suitable foundation must be arranged for. Just as the heavy duty gas engine requires a heavier hull construction and foundations than the light, high speed engine, so the diesel engine requires still heavier construction, because of its heavier power impulses, than the heavy duty gas engine.

It has been found from experience that engine timbers extending fore and aft as far as the lines of the boat will permit, are essential if satisfactory operation is to be obtained. We strongly recommend that these timbers be well fastened to the ribs and the keelson by means of through bolts and cross bolts. If the width of the engine base is such that in locating these foundation timbers a space is left between them and the keelson, this space should be filled in with solid timbers for at least two or three feet fore and aft of the engine base.

Provision should be made in the form of long, tapered wedges equal in length to the length of the engine base, for alignment of the engine. In small engines, lag screws are used for fastening the engine to the foundation timbers, but in large engines the engine should be secured to the hull or foundation timbers by through bolts in at least three points on each side of the engine base.

It is important that in lining the engine up the driving flange on the thrust shaft should be square with the flange on the propeller shafting. It is also desirable that the inclination of the engine to the water line be as small as possible. The hole through the deadwood is best made water-tight by means of a lead sleeve. This lead sleeve extends through the deadwood about 1" on either end. These extensions are flanged over to form a gasket under the stern bearing and stuffing box. The lead sleeve should be selected of such a diameter that it can be readily slipped through the hole in the deadwood, after which it is expanded tight against the deadwood by driving greased wooden plugs through it. After the lead sleeve has been expanded and flanged over, the stern bearing and stuffing box may be set in place after coating the flanges well with white lead and screwing up tight against the deadwood by means of lag screws furnished with the engine. After the propeller shaft and the engine are installed, it is important in determining the length of the intermediate shaft, that sufficient clearance be allowed between the hub of the propeller and the stern bearing to allow for a slight lengthening of the boat, due to the swelling after it is placed in the water. When installing the propeller, it is well to coat the tapered end of the propeller shaft and the threads with a good coating of white lead and machine oil. This will prevent salt water from getting in between and starting corrosion. Be sure that the propeller nut is put on tight.

### ALIGNMENT

When installing the engine, use great care in alignment, which can be best done by first installing the tail shaft, then lining up and bolting

the coupling of the intermediate shaft. Adjust the height and thwartship position of the engine so that the flanges of the engine and the intermediate shaft couplings are square with each other. The engine timbers should be set low enough to allow a soft, wooden shim about 1½" thick to be placed between the engine and engine timbers. After the engine is lined up, take measurements for the shims and cut them to fit snug. Check up the flanges of the engine and intermediate shafting couplings to make sure they are in perfect alignment before bolting up.

Base is tapped for jacking up screws for use in lining up engine.

#### EXHAUST PIPING

The exhaust piping should be of a size to correspond with the threaded flange on the end of the water-cooled exhaust pipe on the engine. We recommend that the exhaust pipe be run straight up, using as few elbows as possible and as direct as convenient to the exhaust stack. Where elbows must be used in the exhaust pipe, use 45° elbows in place of 90° elbows. The muffler furnished with the engine should be attached to the exhaust pipe at a point to come within the exhaust stack. Standard black iron pipe and fittings are recommended for exhaust piping. The exhaust stack, while not furnished with the engine, may be constructed of about No. 16 gauge galvanized sheet iron with an angle iron flange about 2" x 2" at the bottom for bolting to the deck of the boat. The top end of the stack should be re-inforced by heading over a ring or flanging. The exhaust stack dimensions should be such as to allow the muffler to pass readily up through the stack.

#### CIRCULATING WATER PIPING

All circulating water piping and fittings should be of brass of standard iron pipe sizes. The size of pipe to use is determined by the suction opening on the pumps. Locate and place the seacocks and flanges about 3 feet from the suction openings on the pump and run the pipes direct, with as few bends as possible, to the pumps. The sea fittings or flanges are installed on the ship's planking and securely fastened to same. The seacocks are to be attached to this fitting directly inside of the ship's planking and so located as to be readily accessible. The overboard discharge from the engine leads out from the forward end of the exhaust pipe and should be carried horizontally, if possible, to the side of the ship and there discharged overboard. The centrifugal pump is ordinarily used for circulating water, while the plunger pump is used as an auxiliary circulating pump and also for bilge pumping. The discharge from the plunger pump is connected up to the circulating system on the engine and a three-way cock is also provided which may be connected up to a separate overboard discharge for use when pumping the bilges and may also be used by connecting to a proper outlet for washing decks; fire or other general service. The suction from the plunger pump should be provided with a three-way cock, one opening of which is connected to a separate sea-cock and the other run down to the bilge and provided with a bilge strainer. It is important that all piping be kept out of the splash of the bilge water. We recommend that this piping be kept above the engine room floor.

### AIR RECEIVERS AND PIPING

The air receivers or air tanks should be installed as near as possible to the engine and connected to the starting air valve on the engine with a pipe of at least the size corresponding to the opening in the air tanks. Place the valve furnished with the engine directly on the air tank and provide an opening in this pipe for connecting up to the discharge of the auxiliary air compressor. The starting air pipe should be connected in the opening on the end of the air tank. The air compressor on the engine is connected to the air tank by means of a separate pipe. Air piping should be black pipe, preferably of Buyers brand. **USE NO GALVANIZED OR BRASS PIPING ON THE AIR LINE.**

See suggested installation plan, page 53.

### LUBRICATING OIL PIPING

On all, except the largest engines, the lubricating oil system and piping is attached to the engine proper and need not be interfered with in installing the engine. However, on the larger engines, where it is inconvenient to attach the lubricating oil service tank to the engine, it is furnished separate and intended to be supported on a bulkhead as close as possible to the engine. The discharge from the sump pump should be connected to the top of the lubricating oil service tank by means of 1" Buyers black pipe. The side connection from the lubricating oil tank should be connected by means of 1½" brass pipe to the lubricating oil pressure pump. The discharge from the pressure pump is in all cases connected up to the lubricating system on the engine.

### FUEL PIPING

The bottom of the main fuel tanks should be connected to the day tank pump with not less than ½" Buyers black iron pipe. Provide a settler in an accessible place and as close as possible to the fuel tanks. The fuel piping should be kept above the floor line if possible to prevent coming in contact with the bilge water. The discharge from the day tank pump should be connected up to the top opening of the day tank with ½" Buyers black iron pipe. The side opening of the day tank should be connected with the fuel oil strainer, using 1" brass pipe and reducing at the strainer. The overflow from the fuel day tank should be connected and run back to the main fuel tanks with ¾" black iron pipe. In the placing of the fuel tanks as well as air tanks, it is well to remember to arrange the seams on the inside and otherwise make the tanks as accessible as possible for inspection or repair. It is also important to keep them out of the splash of the bilge water.

## Auxiliary Engine

### EXHAUST

The exhaust pipe from the auxiliary engine is usually carried overboard together with the discharge circulating water. It is usual to provide a gooseneck or return bend extending upward to a point higher than the water line, then returning down to a point still above the water line and allowing the discharge water from the top of the cylinder head to enter the exhaust pipe beyond the gooseneck. In this way the exhaust from the engine is silenced and is cooled so as not to burn the side of the ship where it passes through. The exhaust piping should be covered where it comes close to any woodwork to prevent scorching.

### STATIONARY ENGINE INSTALLATIONS

The installation of stationary engines will vary so much with the service for which the engine is intended and the location, that it is hard to give more than a general description of the requirements.

### FOUNDATION

The foundation in all cases should be sufficient to absorb the natural vibrations of the engine. The size of the foundations will depend entirely upon the soil conditions. Under ordinary circumstances, when the foundation is made of concrete, brick or masonry, it may be 5 to 8 ft. deep, depending upon the size of the engine, and if it extends a foot beyond the edge of the engine base, it is usually sufficient. However, the condition of the soil on which the engine is mounted will determine, in a large measure, the size of the foundation. In silty sediment it frequently happens that concrete or brick cannot be used and timber cribbing must be resorted to.

### EXHAUST PIPING

Exhaust pipe can be of black iron pipe and may be run directly up and through the roof, using a muffler if desired. In many cases, it is desirable to run the exhaust pipe down under the floor and out through the side of the building. In any case, the exhaust pipe should be of the size of the flange furnished on the end of the exhaust pipe and should be as free as possible of bends, using 45° elbows wherever necessary. If the exhaust pipe is of any considerable length, it is well to increase the size.

### CIRCULATING WATER PIPE

The circulating pump furnished on the engine will determine the size of the suction pipe to be used. Connect up the pump suction with the source of supply with as short a pipe as possible and eliminate bends and elbows to the greatest extent. Where the cooling water supply is under pressure, it may be necessary to place a reducing valve in the line to prevent excessive pressures being placed upon the cylinder jackets. Pressure over 15 lbs. per sq. in. should be avoided. The discharge from the engine should be carried away in pipe of a size no smaller than the outlet water pipe on the engine. The cooling of the

engine may be effected by means of a circulating system, a cooling tower or a radiator. The circulating water piping may be wrought iron pipe, preferably galvanized, where a fresh water supply is available.

#### AIR PIPING

The air piping should be carried from the air tanks to the engine in as short a run as possible, avoiding elbows and short bends. The pipe size is determined by the opening in the air tanks and should be carried up directly to the air starting valve before reducing. Buyers black iron pipe is recommended for this service. Malleable iron fittings of extra heavy pattern should be used.

#### PREPARING THE ENGINE FOR STARTING

After the engine has been installed and all piping and connections have been properly made and tested, start the small air compressor and pump up the air starting tanks with a pressure of 200 lbs. per sq. in. When this pressure has been attained, test all of the safety valves and see that they are in proper working order. The time required to pump up the tanks varies with the size, but will average about 15 minutes.

Inspect the inside of the engine base to see that no tools have been left there to interfere with the operation of the engine. At the same time, it is well to see that all dirt, shavings, etc., left by workmen when installing, have been cleared out so as not to interfere with the proper lubrication of the engine. Pour sufficient lubricating oil into the engine base to submerge the suction valve on the sump pump. This requires about 2 or 3 inches of lubricating oil in the sump. Next fill the lubricating oil service tank about 2/3 full of lubricating oil and likewise fill up the sight feed pressure lubricator on the engine. See that all of the adjusting screws on the pressure lubricator are open so as to give an ample supply of lubricating oil to the cylinders. This can be tested by turning the hand crank on the pressure lubricator. After the engine has been run in for a while the adjustment on these lubricators can be attended to, giving each cylinder from 13 to 14 drops per minute. At this point it is well to go over the engine with an oil can, squirting a few drops into all oil holes on the rocker arms, fuel pump cranks, etc. Fill up the main fuel oil tanks with the proper grade of diesel fuel oil and put a small quantity into the fuel oil day tank.

Turn the engine over with the starting bar, being sure that all fuel isolating valves are closed and the cylinder snifter valves open. One turn of the engine in this manner will insure that everything is free and clear and that the engine can be safely turned over on air. Next pump up by means of the hand priming pump, about 2000 lbs. on the oil pressure gauge. This pumping should be done when all of the fuel valves are closed. To be sure of this, place the engine with the pointer about 25° past top center on the flywheel. *If any difficulty is experienced in pumping up pressure on the oil gauge, it probably indicates that there is air in the fuel lines. To relieve this air, loosen the union on the fuel rail which connects the pipe leading to the pressure gauge. It may be necessary also to relieve the air at the discharge union from the fuel*

pumps. After the fuel pressure has been pumped up, it is well to check the opening and closing of the spray valve (see instructions under Spray Valve Timing). After the timing has been found in order, the engine is ready to turn over a few turns under air pressure with the snifter valves open. This will clean out any accumulation of fuel oil in the cylinders and prevent excessive pressures when starting.

If everything is found in order, the engine is now ready to start. Bar the engine over to a point about 25° past top center, making sure that both the inlet and exhaust valves are closed on the particular cylinder indicated. Close the snifter valves and open the fuel isolating valves. Set the fuel pressure relief valve handle three or four notches up from the lowest position and pump up about 2000 lbs. on the gauge. Set the governor speed control handle in about medium position and see that the starting handle is in the running position. (See Fig. A, page 20.) Now open the air starting valve on the air manifold and the engine is ready to start. By pulling the starting handle over into the starting position, the engine will turn over and immediately start under its own power. The handle should then be quickly returned to the running position so as to save air and the starting valve on the air manifold closed.

It is well to pump up the tanks to their full pressure after each starting of the engine. To do this it is not necessary to start the auxiliary engine air compressor as the air tanks can be pumped with the compressor on the main engine. After the tanks have been pumped up, as indicated by the popping of the safety valves, the shut-off valves on the tanks themselves should be closed and the air compressor cut out by holding down the suction valve by means of the handle provided on the compressor cylinder head.

In pumping up the air tanks it is well to allow the safety valves to pop each time as this is a good check on the proper functioning of the valves.

Once a day, or each time the engine is started, it is well to squirt a mixture of cylinder oil and kerosene on the valve stems to prevent them from sticking.

# PARTS LIST

For Atlas Imperial Diesel Engines

## INSTRUCTIONS

In ordering parts BE SURE to give the following information:

First—Name of Part Wanted.

Second—Number of Part Wanted.

Third—ENGINE NUMBER (found on name plate on centerframe).

**IMPORTANT—RECHECK ALL NAMES AND NUMBERS TO BE SURE THAT THE CORRECT INFORMATION IS GIVEN.**

### CIRCULATING WATER

Part No.	Part Name	Part No.	Part Name
214	Plunger pump valve cage.	305A	Drum cover bushing ring.
214A	Plunger pump valve cage stud	306	Reverse gear pinion (long).
215	Plunger pump suction bonnet.	307	Reverse gear pinion (short).
215A	Plunger pump bonnet copper asbestos gasket.	308	Reverse gear pinion pin.
215B	Plunger pump suction bonnet flange.	310	Reverse gear driver.
216	Plunger pump discharge bonnet.	311	Reverse gear driver plate.
216A	Plunger pump discharge bonnet stud.	G312	Reverse gear crowder collar and cone assembly, Parts 312, 312A, 312B, 313, 313A, 314, 314A, 315, 330.
217	Plunger pump valve guide stem.	312	Reverse gear crowder collar.
218	Plunger pump valve spring.	312A	Reverse gear crowder collar bolt and nut.
219	Plunger pump valve (rubber)	312B	Reverse gear crowder collar pin.
219A	Plunger pump valve bushing.	313	Reverse gear crowder.
G260	Plunger pump complete: Parts 219A, 260, 261, 262, 262A, 262B.	313A	Reverse gear cone pin.
GA260	Plunger pump body with 262A.	314	Reverse gear crowder link.
261	Plunger pump plunger.	314A	Reverse gear crowder link pin.
262	Plunger pump gland.	315	Reverse gear crowder spring.
262A	Plunger pump gland stud.	316	Reverse gear friction release thrust ring and pins.
262B	Plunger pump gland stud nuts	316A	Reverse gear friction release thrust ring spring.
G264	Plunger pump connecting rod with 264A.	317	Reverse gear pinion spacing bushing.
264A	Plunger pump connecting rod bushing.	318	Reverse gear retainer ring bolt.
264B	Plunger pump connecting rod pin.	319	Reverse gear retainer ring.
266	Plunger pump crank disc.	320	Reverse gear friction plate (square hole).
266A	Plunger pump crank disc washer.	321	Reverse gear friction plate (round hole).
300	Reverse gear drum with 319 and 318.	321A	Reverse gear friction plate (round hole) fixed type.
301	Reverse gear thrust quill.	323	Reverse gear thrust quill bushing.
301A	Reverse gear thrust gear.	324	Reverse gear pinion bushing (long or short).
302	Reverse gear center gear.	325	Reverse gear cone shifter stand—operator's side.
303	Reverse gear drum bushing.	326	Reverse gear cone shifter.
304	Reverse gear drum cover.	326A	Reverse gear cone shifter shaft.
305	Reverse gear drum cover bushing.		



Part No.	Part Name
327	Reverse gear cone shifter lever or wheel.
327A	Reverse gear cone shifter wheel handle.
328	Reverse gear brake post crowder.
328A	Reverse gear wedge roller block.
328B	Reverse gear wedge roller.
328C	Reverse gear wedge roller pin
330	Reverse gear conc.
331	Reverse gear cone collar.
331A	Reverse gear cone collar bolt.
333	Reverse gear crowder collar bolt.
335	Reverse gear cone shifter stand—exhaust side.
337	Reverse gear sector.
337A	Reverse gear sector pinion.
337B	Reverse gear sector pinion shaft.
339	Reverse gear coupling.
339A	Reverse gear coupling bolt.
340	Thrust bearing box.
341	Thrust bearing cap.
342	Reverse gear brake shoe.
342A	Reverse gear brake shoe friction lining.
342B	Reverse gear brake shoe pin.
343	Reverse gear brake post.
343A	Reverse gear brake post pin (lower).
344	Reverse gear lever clamp.
344A	Reverse gear brake post crowder link.
345	Reverse gear brake post swivel crowder.
345A	Reverse gear brake post tie rod.
345B	Reverse gear brake post tie rod spring.
346	Reverse gear brake post swivel.
347	Thrust bearing water pass-over pipe.

**PROPELLER EQUIPMENT**

351	Propeller.
G352	Propeller shaft complete with Parts 359, 359A, 363, 364, 366.
G353	Intermediate shaft complete with 339, 354, 353.
354	Intermediate shaft coupling bolt.
355	Stuffing box.
356	Stuffing box gland.
357	Stuffing box gland stud.
358	Intermediate shaft coupling.
359	Propeller shaft coupling.
359A	Propeller shaft coupling bolts.
360	Stern bearing.
363	Propeller shaft bushing (stuffing box).
364	Propeller shaft bushing (stern bearings).
366	Propeller nut and lockscrew.

Part No.	Part Name
G370	Centrifugal pump complete: Parts 370, 371, 371A, 372, 373, 373A, 374, 379, 381, 381A, 382, 383.
GA370	Centrifugal pump body with 374.
370A	Centrifugal pump outlet flange
371	Centrifugal pump cover.
371A	Centrifugal pump cover screw
371B	Centrifugal pump inlet flange.
G372	Centrifugal pump runner and shaft.
373	Centrifugal pump gland.
373A	Centrifugal pump gland stud.
374	Centrifugal pump shaft bushing.
379	Centrifugal pump shaft.
381	Centrifugal pump steady bearing.
381A	Centrifugal pump steady bearing cap screw.
382	Centrifugal pump shaft collar
383	Centrifugal pump ball bearing
384	Centrifugal pump shaft coupling (complete).
G500	Cylinder head complete assembly (as shown on page 12), except spray valve G849, and horse shoe collar 877, the following parts are included, Nos. 500, 510, 512, 513, 514, 514A, G520, G527A, G550, 564, 564B, 565, 566, 567, 567A, 567B, 579, 580, 582, 583, 584, 585, 586, 588, G590, 764, 854, 854A, 855, 855A, G870, 872, 873.
	Specify whether handle or male connecting link is wanted with head. The following parts are also included if used: 515, 516, 517.
GA500	Cylinder head with exhaust inlet, air starting valves and springs only. Part Nos. 500, 510, 512, 513, 514, 514A, 564, 579, 580, 582, 583, 584, 585, 586, 588.
500	Cylinder head only with studs 567 and 764.
501	Cylinder head stud.
501A	Cylinder head stud, special for lifting head.
502	Cylinder head gasket.
510	Valve and stem, inlet or exhaust.
512	Valve stem bushing, inlet or exhaust.
513	Valve spring, inlet or exhaust
514	Valve spring bushing, inlet or exhaust—top.
514A	Valve spring bushing, inlet or exhaust—bottom.
G515	Inlet or exhaust valve and cage complete: Parts 510, 513, 514, and 515.

Part No.	Part Name	Part No.	Part Name
515	Valve cage, inlet or exhaust with 512 in engines 11" bore and larger.	578	Air starting pipe shut off valve (state whether globe, gate or quick opening valve).
516	Valve cage stud.	579	Air starting valve spring bushing.
517	Valve cage flange.	G580	Air starting valve complete. Cage type—Parts No. 580, 581, 581A, 582, 582A, 584, 585, 585A, 586. (See page 19 for drawing.)
518	Valve cage gasket.	580	Air starting valve.
519	Exhaust or inlet valve cage ring.	581	Air starting valve cage.
G520	Inlet rocker, with roller and pin. Parts 520, 520A, 523, 524, G527A.	581A	Air starting valve cage ring.
520	Inlet rocker only.	581B	Air starting valve cage gasket.
520A	Inlet rocker bushings (set of 2)	582	Air starting valve spring.
523	Rocker roller, for inlet, exhaust or air.	582A	Air starting valve spring nut.
524	Rocker roller pin, for inlet, exhaust or air.	583	Air starting valve spring washer—top.
525	Inlet or exhaust valve push rod.	584	Air starting valve nut.
526	Push rod fork, for inlet, exhaust, air or fuel.	585	Air starting valve balance bushing.
527	Fork pin, inlet, exhaust, air or fuel.	585A	Air starting valve balance bushing nut.
G527A	Fork pin, ball lock.	586	Air starting valve balance bushing ring.
G528	Inlet or exhaust valve lifter with roller and pin.	588	Air starting valve spring washer—bottom.
529	Exhaust or inlet valve lifter guide.	G590	Air starting rocker with roller and pins. 523, 524, G527A. (and 590A when used).
530	Exhaust or inlet valve lifter roller.		Air starting valve rocker roller. Part 523.
531	Exhaust or inlet valve lifter roller pin.		Air starting valve rocker roller pin. Part 524.
532	Inlet and air starting cam.	590A	Air starting valve rocker bushing (set of 2).
G550	Exhaust rocker with roller and pins, 550, 550A, 523, 524, G527A.		Air starting valve rocker fork. Part 526.
550A	Exhaust rocker bushings (set of 2).		Air starting valve rocker fork pin. Part 527.
560	Exhaust cam.		Air starting valve rocker fork pin lock. Part 527A.
564	Rocker shaft, connecting link (female).	593	Air starting valve push rod.
564A	Rocker shaft connecting link (male).	G594	Air starting valve lifter with roller and pin.
564B	Rocker shaft connecting link pin.	594A	Air starting valve lifter collar
565	Rocker shaft.	594B	Air starting valve lifter spring
566	Rocker shaft bearing (state: with or without wings).	595	Air starting valve lifter roller.
567	Rocker shaft bearing stud.	596	Air starting valve lifter roller pin.
567A	Rocker shaft bearing stud nut; top.	599	Air starting valve lifter guide.
567B	Rocker shaft bearing stud lock nut.	600	Cylinder.
G570	Air starting handle, complete: Part Nos. 570, 571, 571A, 572, 573.	605	Cylinder clean out cover.
570	Air starting handle.	610	Cylinder water by-pass (cast iron).
571	Air starting handle pawl.	610	Cylinder head water pipe (brass tube).
571A	Air starting handle pawl screw	610A	Cylinder head water pipe rubber gromet.
572	Air starting handle pawl spring.	611	Cylinder lubricating pipe.
573	Air starting handle sector.	612	Cylinder lubricating pipe gland
577	Air starting pipe elbow.	613	Cylinder lubricating pipe packing ring.
		614	Cylinder lubricating pipe elbow.

Part No.	Part Name	Part No.	Part Name
620	Piston.	722A	Base cap shim—after end.
G621	Piston pin.	727	Base to cylinder stud.
622	Piston ring.	729	Base to centerframe stud (cylinder).
628	Connecting rod bushing (piston pin).	730	Cylinder to centerframe stud.
630	Connecting rod.	731	Base to centerframe stud (air pump).
G632	Connecting rod check valve.	750	Flywheel with 753.
634	Connecting rod foot shims (state thickness).	753	Flywheel hub clamp bolt.
636	Crank pin bearing (2 halves) babbitted.	754	Flywheel hub clamp bolt wrench.
636A	Crank pin bearing shims (state thickness).	760	Exhaust elbow (on cylinder head).
637	Crank pin bearing bolts and nuts.	761	Exhaust pipe.
638	Crank pin bearing bolts locking strap.	763	Exhaust pipe blind flange.
640	Crankshaft with 660 and 655.	764	Exhaust elbow stud (on cylinder head).
644	Main bearing shells—flywheel end (2 halves).	765	Exhaust elbow (on end exhaust pipe).
646	Main bearing shells—center (2 halves).	766	Stud for exhaust elbow (on end exhaust pipe).
649	Main bearing shells—after end (2 halves).	767	Exhaust flange for elbow (on end exhaust pipe).
655	Crankshaft oil throw ring.	775	Lubricating oil cooler core.
660	Crankshaft pinion.	777	Lubricating oil cooler head.
664	Intermediate gear (including band 664A).	778	Lubricating oil cooler pipe.
665	Intermediate gear—pin.	779	Lubricating oil cooler gland.
665A	Intermediate gear—pin bolt.	780	Inlet water manifold (or oil cooler body).
665B	Intermediate gear—pin bolt washer.	784	Inlet water manifold end flange (threaded). State pipe size.
665C	Intermediate gear—pin washer	786	Inlet water manifold end flange (blind).
666	Intermediate gear bearing.	787	Inlet water manifold side flange (state pipe size).
666A	Intermediate gear bearing cap screw.	789	Outlet water manifold.
666G	Intermediate gear bearing lock set screw.	791	Outlet water pipe—outlet from manifold.
670	Cam shaft gear.	791A	Outlet water pipe flange.
672	Cam shaft.	792	Water passover pipe on exhaust pipe.
G680	Cam shaft bearing and bushing.	794	Outlet water pipe—manifold to exhaust pipe.
684	Centerframe blind flange—end of cam shaft.	795	Outlet water pipe gland for 794.
685	Cam shaft bushing.	796	High pressure fuel discharge fitting.
690	Centerframe.	796A	High pressure fuel discharge fitting split ring.
691	Centerframe cover and governor shield.	797	High pressure discharge fitting nut.
691A	Governor shield gasket.	G800	H. P. Fuel pump complete: Parts 800, 805, 806, 808, 809, 810, 810B
692	Centerframe cover—round.	800	High pressure fuel pump body
692A	Round centerframe cover gasket.	801	High pressure fuel pump suction valve.
693	Centerframe cover—air pump pit.	G802	H. P. Fuel pump suction valve cage with 801 and 811.
695	Centerframe cover—end of frame.	802	High pressure fuel pump suction valve cage.
710	Base with caps and studs.	802A	High pressure fuel pump suction union nut.
712	Base cap—flywheel end.	802B	High pressure fuel pump suction union sleeve.
713	Base cap—center.	805	High pressure fuel pump plunger.
715	Base cap—after end.		
717	Base cap studs.		
719	Base cap parting piece—flywheel end.		
719A	Base cap shim—flywheel end.		
720	Base cap parting piece—center		
720A	Base cap shim—center.		
722	Base cap parting piece—after end.		

Part No.	Part Name
805A	High pressure fuel pump plunger spring.
806	High pressure fuel pump plunger packing rings.
808	High pressure fuel pump gland
809	High pressure fuel pump gland nut.
810	High pressure fuel pump plunger head.
810B	High pressure fuel pump plunger nut.
811	High pressure fuel pump discharge valve.
817	High pressure fuel pump plate
818	High pressure fuel pump rocker (double).
818A	High pressure fuel pump rocker pin (long).
818B	High pressure fuel pump rocker (single).
818D	High pressure fuel pump rocker bushing (bronze).
819	High pressure fuel pump rocker shaft.
819A	High pressure fuel pump rocker shaft sleeve (steel).
G820	High pressure fuel pump rocker shaft bearing and caps.
820A	High pressure fuel pump rocker shaft bearing stud (long).
820B	High pressure fuel pump rocker shaft bearing stud (short).
820D	High pressure fuel pump rocker shaft bearing cap stud.
821	High pressure fuel pump rocker shaft bearing cap.
822	High pressure fuel pump crank shaft.
822A	High pressure fuel pump crank shaft coupling.
822B	High pressure fuel pump crank shaft coupling bolts.
822C	High pressure fuel pump crank shaft washer.
G823	H. P. Fuel pump crank shaft connecting rod assembly: Parts 823, 824, 824A.
824A	High pressure fuel pump crank shaft connecting rod cap bolts.
828	High pressure fuel pump connecting link.
	High pressure fuel pump connecting link pin.
	High pressure fuel pump guide.
	High pressure fuel pump nut.
	High pressure fuel pump button.
	High pressure fuel pump complete.

Part No.	Part Name
850	Spray valve stem.
851	Spray valve body.
853	Spray valve spring casing.
854	Spray valve clamp.
854A	Spray valve clamp stud.
855	Spray valve clamp bridge.
855A	Spray valve clamp stud nut.
856	Spray valve seat nut.
857	Spray valve spring plug.
858	Spray valve spring.
859	Spray valve ball bearing.
860	Spray valve gasket.
864	Spray valve nozzle or tip.
865	Spray valve gland nut.
866	Spray valve gland.
867	Spray valve packing seat.
870	Spray valve rocker.
	Spray valve rocker nin No. 527
	Spray valve rocker fork No. 526.
	Spray valve rocker fork pin lock No. 527A.
872	Spray valve rocker stand.
873	Spray valve rocker stand pin.
876	Spray valve push rod.
877	Spray valve horseshoe collar.
878	Spray valve stem nut.
878A	Spray valve stem lock nut.
880	Spray valve cam toe.
881	Spray valve cam disc.
G883	Spray valve lifter with roller and pin.
884	Spray valve lifter roller.
885	Spray valve lifter roller pin.
887	Spray valve lifter guide.
888	Spray valve lifter spring.
889	Spray valve push rod socket.

### AIR COMPRESSOR (on Engine)

900	Air compressor cylinder with 902.
G901	Air compressor head, complete: Parts 901, 905, 907, 908, 908A, 915, 915A, 918, 918A, 919, 920, 922, 922A, 923, 924.
901	Air compressor cylinder head with 907.
902	Air compressor cylinder head stud.
905	Air compressor inlet valve.
906	Air compressor valve grid.
907	Air compressor inlet valve bushing.
908	Air compressor inlet valve spring.
908A	Air compressor inlet valve nut.
908B	Air compressor inlet valve washer.
620	Piston.
G621	Piston pin.
622	Piston ring. Specify if plain, double seal or oil control. Also specify width.
628	Connecting rod bushing (piston pin).
630	Connecting rod.


Part No.	Part Name	Part No.	Part Name
915	Air compressor discharge valve.	1076A	Lubricating sump pump connecting rod pin.
915A	Air compressor discharge valve adjusting screw.	1079	Lubricating sump pump crank disc.
918	Air compressor discharge valve nut.	1079A	Lubricating sump pump crank disc washer.
918A	Air compressor discharge valve relief handle nut.	G1080	Pressure lubricating pump complete: Parts 1080, 1081, 1082, 1083, 1085.
918B	Air compressor inlet valve cap nut stud.	1080	Pressure lubricating pump cylinder.
918C	Air compressor inlet valve flange stud.	1080A	Pressure lubricating pump suction check valve.
918D	Air compressor inlet flange gasket.	1080B	Pressure lubricating pump discharge check valve.
919	Air compressor discharge valve spring.	1081	Pressure lubricating pump plunger.
920	Air compressor discharge valve guide.	1081A	Pressure lubricating pump plunger nut.
922	Air compressor discharge valve cap nut.	1082	Pressure lubricating pump gland.
922A	Air compressor discharge relief handle.	1083	Pressure lubricating pump gland nut.
923	Air compressor discharge valve guide cap.	1085	Pressure lubricating pump plunger eye.
924	Air compressor discharge valve spring bushing.	1085A	Pressure lubricating pump plunger eye pin.
925	Air compressor piston.	1086	Pressure lubricating pump connecting link.
926	Air compressor piston ring.	1087	Pressure lubricating pump oil pressure gauge (30 lbs.)
927	Air compressor piston pin.	1088	Pressure lubricating pump rocker.
928	Air compressor piston pin bushing.	1088A	Pressure lubricating pump rocker pin.
G929	Air compressor connecting rod bushed.	G1090	Pressure lubricating relief valve complete: Parts 1090, 1091, 1092, 1093, 1095, 1096.
G930	Air compressor eccentric strap (2 halves) and bolts.	1090	Lubricating oil pressure relief valve body cap.
932	Air compressor eccentric strap bolts.	1091	Lubricating oil pressure relief valve plunger.
933	Air compressor eccentric.	1092	Lubricating oil pressure relief valve adjusting screw.
935	Air compressor relief valve.	1093	Lubricating oil pressure relief valve spring.
936	Air compressor pass over pipe	1095	Lubricating oil pressure relief valve adjusting screw nut.
937	Air compressor gauge (300 pounds).	1096	Lubricating oil pressure relief check valve and body.
1060	Sight feed pressure lubricator. When ordering lubricator state manufacturer, number of feeds, also type.	G1100	Governor assembly: Parts 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1113.
1061	Sight feed pressure lubricator bracket.	1100	Governor No. 111.
1065	Sight feed pressure lubricator drive rod.	1101	Governor
1065A	Lubricator drive rod pin.	1102	Governor
1066	Lubricating sump pump gland	1103	Governor
1066A	Lubricating sump pump gland stud.	1104	Governor
1069	Lubricating sump pump strainer.	1105	Governor
G1070	Sump pump assembly.	1106	Governor
1070	Lubricating sump pump body.	1107	Governor bearing
1073A	Lubricating sump pump check valve—inlet.	1108	Governor (large)
1073B	Lubricating sump pump check valve—outlet.		
1075	Lubricating sump pump plunger.		
1076	Lubricating sump pump connecting rod.		

Part No.	Part Name
1109	Governor shaft.
1110	Governor body collar.
1111	Governor pinion.
1112	Governor bearing.
1113	Governor thrust quill bushing
1114	Governor compression spring.
1114A	Governor compression spring collar.
1114B	Governor compression spring collar.
1115	Governor compression spring block.
G1117	Governor control handle, complete: Parts 1117, 1118, 1119, 1124, 1125, 1249.
1117	Governor control handle.
1117	Fuel relief valve handle.
1118	Governor control handle pawl
1118	Fuel relief valve handle pawl.
1119	Governor control handle sector.
1120	Governor spring rack.
1121	Governor spring rack adjusting screw.
G1122	Governor speed control socket and handle complete: Parts 1117, 1118, 1119, 1120, 1121, 1122, 1122A, 1124, 1125, 1249.
GA1122	Governor speed control socket with sector. 1122A.
1122A	Governor speed control socket sector.
1123	Governor control socket bearing.
1124	Fuel relief valve handle pawl spring.
1124	Governor speed control pawl spring.
1125	Fuel relief valve handle pawl spring screw.
1125	Governor speed control pawl spring screw.
1127	Governor connecting rod between forks.
1128	Governor fork.
1128A	Governor vertical shaft.
1129	Vertical shaft lever.
1129A	Vertical shaft lever pin.
1130	Wedge shaft fork.
1131	Wedge fork.
	*When combined in one casting order Part No. 1130A.
1132	Fuel control wedge.
1132A	Fuel control wedge pin.
1133	Fuel control shaft.
1134	Fuel control shaft bearing.
1135	Fuel control shaft spring.
1136	Fuel control shaft spring clamp
1139	Guard rail.
1140	Guard rail bolt.
1141	Guard rail spacer.
1143	Fuel relief valve handle.
1149	Fuel relief valve handle screw
1170	High pressure union nipple.
1176	High pressure fuel union nut.
1177	High pressure fuel union sleeve.

Part No.	Part Name
<b>HIGH PRESSURE FUEL PIPES</b>	
Each pipe assembled with nuts and sleeves, Parts Nos. 1176, 1177.	
1183	Testing pipe—fuel rail—to spray valve test clamp.
1184	Fuel pipe from relief valve discharge—to pump suction.
1185	Fuel pipe from high pressure fuel pump discharge—to fuel relief valve.
1186	Connecting pipe between H. P. fuel pumps (discharge).
1187	Fuel pipe from fuel pump—to fuel rail.
1188	Fuel pipe from fuel rail—to spray valve.
1189	Fuel pipe from fuel rail—to fuel oil receiver.
1189A	Fuel pipe from fuel oil receiver — to fuel pressure gauge.
G1190	Cylinder relief valve complete: Parts 1190, 1191, 1192, 1193, 1194, 1195, 1199.
1190	Cylinder relief valve body.
1191	Cylinder relief valve stem.
1192	Cylinder relief valve seat.
1193	Cylinder relief valve spring.
1194	Cylinder relief valve spring collar.
1195	Cylinder relief valve adjusting screw lock.
1196	Cylinder relief valve plug.
G1197	Snifter valve complete: Parts 1197, 1198.
1197	Cylinder snifter valve body.
1198	Cylinder snifter valve stem.
1199	Cylinder relief valve adjusting screw.
1200	Fuel rail complete with isolating valves.
1201	Spray valve fuel strainer body
1202	Spray valve fuel strainer stem
1203	Fuel rail clamps.
1204	Spray valve fuel strainer gasket.
1205	Fuel rail isolating valve body.
1206	Fuel rail isolating valve stem.
1206	Fuel oil receiver valve stem.
1207	Fuel rail isolating valve gland
1207	Fuel oil receiver valve gland.
1208	Fuel rail isolating valve gland nut.
1208	Fuel oil receiver valve nut.
1214	Fuel oil receiver.
G1215	Fuel oil receiver valve complete.
1215	Fuel oil receiver valve body.
1216	High pressure fuel oil gauge bracket.
1217	High pressure fuel oil gauge.
G1218	Fuel oil strainer complete.
1218	Fuel oil strainer body.
1219	Fuel oil strainer cover.
1220	Fuel oil strainer grid.
1221	Fuel oil strainer valve.

Part No.	Part Name	Part No.	Part Name
1222	Fuel oil strainer stuffing box.	G1287	Day tank pump complete: Parts 1287, 1288, 1288A, 1289, 1291, 1292.
1223	Fuel oil strainer gauze.	1287	Day tank pump body.
1224	Fuel oil strainer cover gasket	1288	Day tank pump plunger.
1225	Fuel oil strainer cover clamp.	1288A	Day tank pump plunger nut.
1225A	Fuel oil strainer cover clamp capscrew.	1289	Day tank pump plunger eye.
1225B	Fuel oil strainer cover clamp stud.	1289A	Day tank pump plunger eye pin.
1226	Fuel oil strainer grid spring.	1290	Day tank pump check valve.
G1230	Fuel relief valve complete.	1291	Day tank pump gland.
1230	Fuel relief valve body.	1292	Day tank pump gland nut.
1231	Fuel relief valve gland.	1293	Day tank pump connecting rod.
1232	Fuel relief valve stud.	1295	Fuel day tank and flange.
1233	Fuel relief valve stem valve.	1297	Fuel day tank strainer cage and gauze.
1234	Fuel relief valve seat.	1306	Chain sprocket (driver on crank shaft).
1235	Fuel relief valve stud collar.	1307	Chain sprocket (driven on pump shaft).
1236	Fuel relief valve spring.	1308	Chain shield.
1237	Fuel relief valve spring cage.	1309	Chain shield cap.
1238	Fuel relief valve handle bearing.	1310	Ball bearing container—blind end.
1238A	Fuel relief valve handle bearing pin.	1310A	Ball bearing container—shaft end.
1239	Fuel relief valve handle adjusting screw.	1311	Driven chain sprocket shaft.
1240	Fuel relief valve handle plug (lower).	1312	Driven chain sprocket shaft ball bearing.
1241	Fuel relief valve stud capnut.	1313	Silent chain.
1242	Fuel relief valve fuel fitting.	1314	Silent chain adjusting screw.
G1243	Fuel relief valve handle complete.	1315	Idler spindle.
1243	Fuel relief valve handle cam.	1315A	Idler spindle lock nut.
1244	Fuel relief valve handle sector	1315B	Idler spindle split ring.
1245	Fuel relief valve spring plug (top).	1316	Idler spindle bearing housing.
1247	Fuel relief valve stud collar gasket.	1317	Idler spindle chain sprocket.
1248	Fuel relief valve stud gasket.	1318	Idler spindle roller bearing complete.
1249	Governor speed control handle screw.	1319	Idler spindle steel cover.
G1275	Priming pump complete: Parts 1275, 1276, 1276A, 1278 and packing.	1319A	Idler spindle steel cover screw
1275	Priming pump cylinder.	1320	Idler spindle roller bearing spacer.
1276	Priming pump plunger.	1321	Idler spindle spacer.
1276A	Priming pump plunger nut.	1322	Idler spindle spacer washer.
1278	Priming pump cap.	1323	Idler spindle felt washer.
1279	Priming pump plunger eye.	1357	Lubricating oil service tank with flanges.
1280	Priming pump plunger connecting rod.	1358	Lubricating oil service tank collar. Also for fuel day tank
1280A	Priming pump plunger pin.	1359	Lubricating oil service tank cover. Also for fuel day tank
1281	Priming pump plunger handle	1360	Lubricating oil service tank cover plug. Also for fuel day tank.
1282	Priming pump plunger handle bracket.	1362	Lubricating oil service tank strainer cage and gauze.
1282A	Priming pump plunger handle bracket spacer.		
1282B	Priming pump plunger handle bracket bar.		
1282C	Priming pump plunger handle bracket lever pin.		

When ordering parts be sure to furnish Engine Number, as well as Part Number



**NO. "0" AUXILIARY AIR COMPRESSOR**

**Always Give Part Name, Part Number and ENGINE NUMBER**



## AUXILIARY COMPRESSOR

In ordering all repair parts for compressor BE SURE and give BOTH the part name and number, also ENGINE NUMBER of auxiliary.

20	Spark plug	220	Air pump head
32	Engine cylinder head	220A	Air pump head valve stem bushing
33	Engine and pump cylinder head stud	221	Air pump piston
33A	Engine and pump cylinder head stud, long	222	Air pump piston ring
33B	Engine and pump cylinder head stud nut	224	Air pump inlet valve
37	Rocker pin	225	Air pump outlet valve
38	Rocker pin fork	225A	Air pump outlet valve adjusting screw
38A	Rocker pin fork stud	226	Air pump piston pin
38B	Rocker pin fork stud nut	227	Air pump connecting rod
100	Cylinder and frame	228	Air pump valve nut
110	Inlet or exhaust valve	228A	Air pump outlet valve cap
110A	Valve stem cup	229	Air pump inlet valve spring
110B	Valve stem cup lock	229A	Air pump inlet valve spring guide
112	Valve stem bushing	229B	Air pump inlet valve spring guide nut
114	Inlet valve spring	230	Air pump outlet valve spring
114A	Exhaust valve spring	230A	Air pump outlet valve spring guide
124	Exhaust rocker push rod	231	Air pump relief handle
124A	Exhaust rocker push rod bushing	234	Air pump outlet valve bushing
125	Engine piston	234A	Air pump outlet valve bushing cap
126	Engine piston pin	240	Carburetor
129	Engine piston ring	260	Rotary pump
133	Exhaust rocker with adjusting screw	260A	Rotary pump cap screw
133A	Exhaust rocker ball socket	272	Water outlet flange
136	Engine connecting rod	287	Flywheel
144	Crankshaft pinion	294	Magneto bracket
150	Crankshaft	296	Magneto
151	Crankshaft bushing	446	Magneto drive shaft
156	Crankshaft bearing	447	Magneto drive shaft bushing
159	Crankshaft bearing, fly-wheel end	G2441	Lubricator assembled
160	Crankshaft bearing cap screw	2441	Lubricator bottom with air pipe
163	Frame cover door	2441A	Lubricator valve
163A	Frame cover door clamp	2441B	Lubricator spring
163B	Frame cover door clamp wing nut	2441C	Lubricator washer and nut
163C	Frame cover door clamp stud	2442	Lubricator top with stem
166	Cam lifter	2442A	Lubricator clamp stud
174	Cam gear	2442B	Lubricator clamp stud nut
176	Cam gear pin	2443	Lubricator plug with stem
176A	Cam gear pin bushing	2443A	Lubricator glass
178	Exhaust cam and gear hub		
202	Rubber pipe		

Always Give Part Name, Part Number and ENGINE NUMBER